

WOR

1110 BROADWAY
NEW YORK 10, N. Y.

• WOR
OPERATING MANUAL

BOOK No. 15

P.E.-T&A.E. REF.
BOOK

W O R
OPERATING MANUAL

BOOK NO. (11.12)

Book No. 11.12 - Contents:-

<u>Section</u>	<u>Item</u>
"A"	High Frequency - Frequency Meter Monitor - Instructions.

DIAL READING

CALIBRATION CURVE
FOR
FREQUENCY METER-MONITOR

SERIAL NO. 2
MODEL BH72R

BAND 3
26.270 MC

LINK RADIO CORP.
125 W. 17 ST. N.Y.C.
10-18-50

BAND 4
26.370 MC

DIAL READING

