# MODEL ENGINEER and ELECTRICIAN.

PERCIVAL MARSHALL, A.I.Mech.E.

Published every Thursday. Price 2d. Post Free, 3d.

A Splendid Paper for Young Engineers, Apprentices, Students, and Amateurs interested in Mechanics and Electricity.

# **Special Features:**

Practical Articles by experienced writers on the construction and work up of model ramm gas, and on loggers, model locencity can alloway; model holters; model steam and sictic launches, and suing yachts; lattes and uncail and work working tools; pattern making, brass and root counding, forging, model dynamos and motors; electric bells, telephones, and batterse, accumulators; electric laghting; lifetneon enchouse; electrical experiment, etc., etc

Model Engineers and their Work-Hiustrated Interviews with prominent model engineers, describing their workshops, their methods of working, and some of the models they have made. These are most asteresting and instructive articles, and are fully illustrated from photographs

Our Beginners' Column.-A section devoted to elementary instruction on the use of tools, the making of simple apparatus and models, and the carrying out of easy electrical and other scientific experiments

Practical Letters from our Readers.—A correspondence column, wherein readers can describe workshop appliances or methods of their own invention, and discuss practical matters of mutual interest

News of the Tracto.-Under this heading short descriptions of new tools, apparatus, and materials are inserted, thus keeping the reader posted up in the latest improvements connected with his hobby

approximate sounds? On the law accurate Replice, hy which all readers of the journal regions information and aives on mechanical or electron subjects an obtain replice by post within a few days. All replice of general interest are published in the following sound of the poper, to that which the individual enquires can obtain the required assistance promptly, the remainder of the readers are not deprived of the interesting macellany which a "Querne and Reply Column" always affords

Original Working Drawings and high-class illustrations are a regular feature of the Journal

Prize Competitions, open to all readers, are announced from time to time, the subjects of which are sufficiently diverse in character to suit the tastes of both mechanical and electrical workers

Send 3d. for Specimen Copy.

PERCIVAL MARSHALL & CO., 26-29 Poppin's Court, Fleet St., LONDON, E.C. The Model Engineer Series No. 24

ENTS

STRUM

O

# Small Electrical Measuring Instruments

Price

A Practical Handbook describing the making and using of Galvanometers, Volumeters, Amperemeters, Wheatstome Bridges, and other Instruments for detecting and measuring Electric Currents

# FULLY ILLUSTRATED



PERCIVAL MARSHALL & CO., LONDON, E.C.

# MODEL ENGINEER and ELECTRICIAN.

PERCIVAL MARSHALL, A.I.Mech.E.

Published every Thursday. Price 2d. Post Free, 3d.

A Splendid Paper for Young Engineers, Apprentices, Students, and Amateurs interested in Mechanics and Electricity.

# **Special Features:**

Practical Articles by experienced writers on the construction and work up of model ramm gas, and on loggers, model locencity can always; model holters; model steam and sictic launches, and saining yachtis; lattes and metal and wood working tools; pattern making, brass and root counding, forging, model dynamics and motors; electric bells, telephones, and batterse, accumulators; electric lathing; liftureon enchouse; electrical experiment, etc., etc

Model Engineers and their Work-Hiustrated Interviews with prominent model engineers, describing their workshops, their methods of working, and some of the models they have made. These are most asteresting and instructive articles, and are fully illustrated from photographs

Our Beginners' Column.-A section devoted to elementary instruction on the use of tools, the making of simple apparatus and models, and the carrying out of easy electrical and other scientific experiments

Practical Letters from our Readers.—A correspondence column, wherein readers can describe workshop appliances or methods of their own invention, and discuss practical matters of mutual interest

News of the Tracto.-Under this heading short descriptions of new tools, apparatus, and materials are inserted, thus keeping the reader posted up in the latest improvements connected with his hobby

approximate sounds? On the law accurate Replice, hy which all readers of the journal regions information and aives on mechanical or electron subjects an obtain replice by post within a few days. All replice of general interest are published in the following sound of the poper, to that which the individual enquires can obtain the required assistance promptly, the remainder of the readers are not deprived of the interesting macellany which a "Querne and Reply Column" always affords

Original Working Drawings and high-class illustrations are a regular feature of the Journal

Prize Competitions, open to all readers, are announced from time to time, the subjects of which are sufficiently diverse in character to suit the tastes of both mechanical and electrical workers

Send 3d. for Specimen Copy.

PERCIVAL MARSHALL & CO., 26-29 Poppin's Court, Fleet St., LONDON, E.C. The Model Engineer Series No. 24

ENTS

STRUM


O

# Small Electrical Measuring Instruments

Price

A Practical Handbook describing the making and using of Galvanometers, Volumeters, Amperemeters, Wheatstome Bridges, and other Instruments for detecting and measuring Electric Currents

# FULLY ILLUSTRATED



PERCIVAL MARSHALL & CO., LONDON, E.C.

Cloth. Price TWO SHILLINGS NET. Crown Svo. Post Free, 25. 3d.

Containing 166 pages, with 193 original Illustrations,

Practical Lessons

# Metal Turning.

A Handbook for Young Engineers and Amateur Mechanics. SECOND EDITION.

By PERCIVAL MARSHALL

(Associate of the Institution of Mechanical Engineers ; First Honours in-Mechanical Engineering, Medallist in Metal Working Tools, and Mitchell Scholar, City and Guilds of London Institute dir. Edutor of The Model Engineer).

# CONTENTS

CHAPTER	L-TOOLS AND TOOL HOLDERS.
CHAPTER	IIMEASURING APPLIANCES.
CHAPTER	IIL-CHUCKS AND MANDRELS.
CHAPTER	IV,-HOW TO CENTRE WORK FOR THE
	LATHE.
CHAPTER	VDRIVING WORK BETWEEN CENTRES.
CHAPTER	VITURNING WORK BETWEEN CENTRES.
CHAPTER	VIL-CHUCK AND BACE DI ATE WODE

HUCK AND FACE PLATE WORK. CHAPTER VIIL-DRILLING AND BORING IN THE LATHE. CHAPTER IX .- SCREW CUTTING.

Every Amateur Mechanic and Engineering Apprentice should have this book

PERCIVAL MARSHALL & CO., 26-29 Poppin's Court, Fleet Street, LONDON, E.C. The "Model Engineer Series, No 12.

# Model Steamer Building.

A Prictical Handbell on the design and construction of Medel Steamer Hulls, Deck Fittings and other details 64 pages, 39 illustrations SYNDISIS OF CONTENTS -- Ceneral Hints on Designing and, Eulding Model Steamers-The Construction of a Model Steam Launch Hall Hew to build a M lel Steamship with Wooden Hull- The Construction of a Model Taipede Fant Destroyer-A M. lei Suldon Rassenger Fuddle Stamer-Filtings for Model Torpello Bosta

Fine 6d nes from al Becase low or 7d. for file for

PERCIVAL MARSHALL & CO., 26-29 Poppin's Court, Fleet Street, London, E.C.

# The ' Model Engineer Somes, No. . 3-

# Machinery for Model Steamers.

A Practical Handbook on the propositioning design and electronium of Engines and Follows for M del Steamer, with notes in the use of haud feel, etc. 64 145 - 44 Il stations SYNC SIS OF CONTINUS -Suggestions of the Improvement of Model Steamers -Supple Enders on Madel Stearers-Methods of Filling Enders, of Model Stear as-A Simple Doubl Cyurder Model Lauch Ener -S al-Cohnder Even is fit Drive Twin Sciev Steamers -Deable Collins Englass for Middl Type-Screw Sugmars-Mach nerv for Model Foddle Scatters-The Steeper of Freibes and Poilers for M. del Steaman.

Press 6d. net bes a sil Brikelia to at 7d. has ins point

PERCIVAL MARSHALL & CO., 26-29 Poppm's Court, Fleet Street, London, F.C.

# CONTENTS

·	FACT
СПАР	1.26.1
I INSTRUMENTS FOR TESTING THE FERSING	
OF AN LLEGIRIC CURRENT, DITECTORS,	
GALVANOULTERS,	7
II INSTRUMENTS FOR MEASURING THE PRESSURE	
OR QUANTITY OF AN FLECTLIC CURRENT,	
AMPERLMEIBES, VELIMITEES, .	23
TTT T	
III. INSTRUMENTS FOR MEASURING FLUCTERCAL	
RESISTANCE ; WHEATSTONE FFICE,	28
IV INSTRUMENTS FOR MEASURING STATIC	
EIFCTRICITY,	35
V PRACTICAL DELAILS OF CONSTRUCTION .	39
VI THE PRINCIPLES UPON WHICH ELECTRICAL	
MEASURING INSTRUMENTS WORK,	49
V I HOW TO USE EFFOREMAN MEASURED	
INSTRUMENTS.	61
VIII HOW TO CHOOSE ELECTRICAL MEASURING	

INSTRUMENT

# PREFACE

THE importance of a knowledge of the construction and use of measuring instruments to the worker in the ever-widening field of electrical engineering cannot be over estimated. He endeavours to contiol and bend to his will a class of appuratus or machine which to all appearance may be of perfect construction and yet refuses to work and fulfil the function for which it was designed. A leakage of electricity does not become, like steam, visible to the eye, or hiss like compressed an, the fault must be discovered by the aid of a suitable instrument which will indicate the presence or absence of an electric current, according to the particular circumstance of the case. The information in this book is intended for those who will require to make simple tests and measurements when building and using small power dynamos electro motors or similar machines and fitting up installations of electric bells, telephones and indicators, or constructing and working with induction coils and batteries

The designs and descriptions have been selected from a number which have appeared from time to

.

The wire used for the coils may be either No 28 or 30 SWG sitk covered. About 6 ins of the wire is passed through one of the holes in the ends of the reel, and this piece clamped with the thumb while the reel is wound continuously in the same direction until almost filled with the wire. Now pass the finishing end of the coil through the other hole in the reel and temporarily wrap the two only together. The reel should now be steeped for ten minutes in melted parafin wax, after which it should be lung. up to allow the wax to drip and set. The ends of the wrise should now be untwisted and straight ned out and then bared of their covering for a length of 1 in at the ends This bared portion of the wife must be made clean and bright by sand-papering or scraping with an old penknife.

The case is a piece of brass tubing, 3 ins. diameter and 2 ins long, it is placed upon the base with its edge resting in the groove cut to receive it.

The real is placed inside the case and secured to the base coils uppermost, by the aid of the little spring brass knees (fig 4). These are screwed to the base 1 m apart with their longest part vertical, and the real then forced between them. If the knees do not grasp the real firmly, their upright pieces must be pressed slightly inwards until they do so. Fig.5 is a sectional view showing how the real is hold by the spring knees.

The ends of the coils are passed through the holes in the base and then curried along the inside of the grooves in the under side of base, and finally well

# TO DEILCI THE PRESENCE OF A CURRENT 11 "

twisted round the shanks of the binding-screws The binding-screws should have lock-nuts for clamping the wires, and these nuts inust be removed to allow the wires to be twisted around the shanks of the binding screws, and then replaced and screwed up very tight. Neither these lock nuts nor any part of the shanks of the binding screws should reach to the level of the under surface of the base, and the groups to the wires and lock-nuts should be deep enough to allow these to sink about  $\frac{1}{3}$  in or more beneath the surface.

10 81

٩

The next part demanding our attention is the



graduated circle. This is a cardboard circle 3 ms diameter and divided into degrees in the order 0.9Q, 0.90, on either side of the zero line. This card is glued down upon a thin boxwood disc of the same diameter as the card  $\frac{1}{2}$  in thick


A needle point is fixed in the centre of the disc and our?, point upwards and should protrude about 4 in. Two small holes should be bored in the card and disc to take a couple of very small round head brass screws for fixing the disc and its card to the reel. These screws should enter the sides of the real at the middle of their length and thickness, and great care must be taken to avoid the screws

### 12 SMALL BITCIFICAL MEASUFING INSTRUMENTS

ð

coming into contact with the coils or their insulating covering. It should be observed that the zeroline of the graduated circle should be purallel to the length of the coils.

The magnetic needle is 2 ms. long, and should be provided at its centre with an agrite or brass cap with



Fiel 0 - Cass for a Longiorna 'e Galvanemeter-

which to pivot it on the needle point. The instrument should be covered with glass to preserve it from dust etc. if possible, the render should obtain a 3-in lens-mounting off a disused magic limitern or telescope, and fix a piece of 21 oz. glass in the place originally occupied by the lens. The mounting will be found to have screw threads cut upon it; similar threads should be cut on the inside of the

#### TO DETECT THE PRESENCE OF A CURRENT 13 .

brass case so that the glass top and its mounting can be screwed on.

The instrument will now be complete and ready for use. When using the instrument, always turn it round until the needle points to zero, the coils and the needle will then be in the inspectic meridian, and will not be affected by the earth's mignetism.

A SIMILE VERIEAL DETECTOR—The case is made of well-seasoned cedar,  $\frac{1}{2}$  in thick, and measures outside  $3\frac{1}{2}$  ins by 3 ins by 2 ins in depth. The sides may be doverabled tegather, or fixed by brass corner plates let in flush with the surface of the word (size fig-6). A piece of sheet brass,  $\frac{1}{3^2}$  in thick, is now cut to it inside the case. This is for the duil plate, and show the quite flat, as one side is to be-poliched. To fix this plate in the case we shall require a hole in each corner to take screws screwed into the four corner pieces shown in fig-6. The face of the dial should be  $\frac{3}{2}$  in below the level of the case.

The coils are wound on two formers made of thin sheet brass (see fig. 7) which, with all the other figures (evcept fig. 10, which is full size, is half size. The size of the hole through the formers is  $1\frac{2}{4}$  ins by one  $\frac{1}{4}$  in wide. One finge is  $\frac{1}{4}$  in wide all round and the other is  $\frac{1}{3}$  in deeper on one side, and also turned up to form a foot  $\frac{1}{4}$  in, wide, by which the coils are secured to the dial plate. These formers are built up with the soldering iron, and  $\frac{1}{2}$  int be neatly made, and all roughness in the heints, edges, and corners chemidly emosthed off

đ

4: 41

\$. T.


The formers should now be carefully insulated with thin silk, paying attention to the corners. A layer of thin brown paper, well shellac varnished, will do, if put on carefully.

The "quantity" wire should first be put on. It consists of two layers of No 22 S W G., silk-covered, and leaving 6 ins out at each end for connections Wind both formers exactly alike. A layer of silk, ribbon or thin brown paper is put over these coils. and on top of them are wound the fine wire coils. made up of seven or eight layers of No. 38 or 40 silk covered copper wire. As this wire is very fine and easily broken, it is best to solder about 10 ins. of thicker wire, say, 22 to it and neatly weap the joint with silk. Leave about 6 ms out for connections as before, and winding in the same direction, and starting in the same place as before, put on the seven or eight layers. When funshing off, selder a piece of thicker wire on, so that the last three or four turns are tal on up by the thicker wire leaving a length over for connections A layer of silk ribbon round the coils will give a better finish to the job, and also prevent the wire from being damaged.

The needle is made from a piece of high quality steel  $l_{\frac{1}{2}}$  ms long,  $\frac{1}{4}$  in wide, and  $\frac{1}{4}c$  in thick, filed to the shape shown in fig. 8 After being drilled with a  $\frac{1}{4}c$ -in hole in the centre, it is made a bright cherry red in the fire or blowpipe flame, and immediately quenched in cold water This hardening is necessary, or the needle would nor retain its magnetizem for any length of time. The needle is

#### TO DETECT THE PRESENCE OF A CURRENT. 15 .

now to be magnetised (see Chap. V) or should the maker know anyone who has charge of a motor or dynamo he will be able to get it done for "Ihank you," and 'While you wait." The pointer is now made to the shape she wan in the view of the dial front (fig. 9) It can be made of brass, ivory, bone, or aluminum; the lower portion must be heavier than the top, so that the pointer always hangs vertically



The spindle is made of  $\frac{1}{16}$  in drameter silver steel, long enough to fit between the brackets next to be described. One end of the spindle is fitted with a pair of nuts, both ends are planted and hardened.

18 23

We now require two brackets of  $\frac{1}{2}$  in sheet brass, or they may be cast, one made to the sizes and shape shown in fig 10, which is full size, and another exactly similar, except that it is only  $\frac{1}{70}$  m, high. A

g-in diameter steel screw is fitted in the centre of each bracket the ends of the series being countersunk by a drill, the cutting edges of which are at an angle of 60 degs to each other. The screws should also have a lock-nut, and be carefully hardened

The coils can now be fitted to the back of the dail plate,  $\frac{1}{2}$  m apart, and the brackets afterwards, the smaller one on the front and the deeper one over the coils on the back (see fig 11). The needle, pointer, and spindle are now out into place. The magnetized



 $\bar{r}_{1}$ . 10 —Prackets (Foll Scie),


needle is adjusted to swing in the certre of the cells, and the pointer just clear of the dial plate by means of nuts which are placed one on each sole of the peinter. The spindle is regulated by the surveys in the brackets to swing freely, but without shale, and fixed by the lock-nuts. The dial plate may either be engraved, or a scile may be fixed to it by serveys.

We now take the case again and fix three terminals in the top and then fix the dial plate with the coils etc in position. The starting ends of ene fine wire coil and one thick wire coil of the same bollan are to be connected to the outside terminals, one to

#### TO DETICI THE PRESENCE OF A CULKENT 17 .

each, and then finishing ends are to be joined respectively to the starting ends of the coils on the other bobbin; the remaining onds are to be both connected to the middle terminal. If you have any difficulty with these connections, or may have wound a coil in the wrong direction, they may be worked out experimentally with the aid of a battery, trying one coil at a time (see Chap VI. fig. 35). A glass

front and plain back are fixed to the case by countersunk screws let in flush with the face of the wood, and the case varnished or polished to suit the maker's taste or abilities. For a small outlay we have now a galvanometer which would cost up to a guinea in the shops. To use the instrument, the quantity coils are used when measuring heavy cur-



Fir. 11 - Cornections between Coils and Forminals

rents as battery cells, and the fine coils are used for detecting leakages or, line wires, etc. The instrument must net be used on large dynames or batteries of accumulators or the coils will be bunnt out.

A SENSITIVE GALVANOMELEE OF SIMPLE CONSTIUC-TION—Ihis is a useful galvanometer for use with a Wheatstone of metre bridge of is a leak detector or tester, it is sensitive enough to show a large deflection

If a carbon and zinc plate are held in either hand—the hands being damp, and the plates, of course, joined to the terminals of the instrument by two wires, or a considerable movement will be observed if a silver com is laid on the table, a drop of moisture is placed on it, and the head of a steel screw made to touch the moisture. It will show any of the usual experiments, such as induced currents, therme effects, etc.





FIG 12 -The Complete Instrument

The finished instrument is shown (fig 12), it essentially consists of a wooden frame with aluminium sides carrying 1000 turns of fine copper wine; in the centre of this frame is proted an agate centred magnetic needle, this needle carries a light pointer at ngit angles to it, which in turn carries a white paper aim at one end. This arm appears through one end of the central aperture, and shows the slightest movement of the magnetic needle upon a

#### TO DETECT THE PRESENCE OF A CURRENT. 19 "

scale The scale may be green or red paper, and then the pointer's movement can be distinctly seen at a considerable distance off

To construct, take a piece of  $\frac{1}{16}$ -in sheet aluminium (brass will do if lacquered after), cut two plates from it 4 by 1<sup>3</sup>/<sub>8</sub> and square the edges and round off the corners, from the centre cut two slots 1<sup>1</sup>/<sub>2</sub> by  $\frac{3}{8}$  (A, fig



13); these may be cut out with an ordinary fret saw and finished up with a smooth file A hardwood frame is now made the end pieces C being  $1\frac{1}{2}$  by  $\frac{2}{3}$ by 5, they must be dead true and square. This is best done with file and square as if metal was being worked, thus avoiding the use of inaccurate planes and chisels. The side pieces D may be cut from thm

evenly. Cut a light white paper pointer § in long by § in wide and stock it to the bent end of the aluminium pointer

A piece of cork is now coully in by  $\frac{1}{2}$  in by  $\frac{1}{2}$  in, and a fine needle point broken off  $\frac{1}{2}$  in long is pushed into the centre of the cork, see that it stands (fig. 16) central and upight, glue the cork in the contre of the wood frame, taking care to keep all glue and dirt off the needle point. Cut a piece of green or icd paper 14 ins by  $\frac{1}{2}$  in wide rule acentral line, and mark off similar lines every  $\frac{1}{2}$  in apart as at N. fig. 15. This is the scale and is stuck on the plate which carries the terminals (as fig. 12)

The needle may now be carefully mounted on its centre, and should move very freely. To use the instrument, it is advisable to keep it permanently on a shell or bracket made for it, and under a dusttight glass shade. Run two light wires from the terminals along the walls to our work bench or experimental bench. The pointer can be brought to zero (the centre line) by placing a weak horseshoe or bar magnet on the shelf it is advisable to set the galvanometer up about two yards from the table, and then there is no fear of any direct action of electromagnets, etc., upon the needle if we are experimenting with these.







CHAPTER II

INSTRUMENTS TO MEASURE THE PRESSURE OR QUANTITY OF AN ELECTRIC CURRENT VOLT-MEITRS AND AMERIMETERS

THE instrument here described may be made either as a voltmeter or as an amperemeter, the only difference being in the winding of the coil.

The voltmeter is intended to read to 20 volts and the amperemeter to 4 amperes.

The first part to be made is the base, which may be cut from a piece of mahogany board 1 in. thick, and turned in the lather to the shape shown in the drawings This could, however, be very easily made by using two thin pieces of wood, and cutting out one of them with a fret-saw, then screwing it to the other and finishing off nicely with a file and glass paper

The containing case C C (shown in figs 17 and 18) is a piece of large briss tube, 4 ms in diameter and 2 ms long. Hole's should be drilled around the circumference of this for the purpose of ventilation, and small countersunk holes for wood screw's at one end to fasten the tube to the timed part of baseboard.

The cover or cutside rim R R (fig. 17), which keeps the glass in position, is made from a length of  $\frac{1}{4}$  in brass tube, bent in a circle by hard, the two ends being soldered together. A strip of sheet brass is next procured  $\frac{1}{16}$  in, wide, and soldered around the edge of this tube, so as to be a sing fit on the cutside of containing case (see S S, fig 17). The glass front can be taken from an old alarum clock.





FIG 17 - A simply main Voltmater (Soutoral Plan.)

The bobbin is constructed in the following manner Two pieces of fretwood being obtained  $2\frac{1}{2}$  ins square with the corners cut off as in fig 18, for the ends, a hole is next cut out of the middle of each and a piper tube  $\frac{1}{16}$  in thick,  $1\frac{1}{16}$  ins diameter,  $1\frac{1}{5}$  ins long made and gaued in these holes so as to form a bobbin, and when dry this is wound for use as a voltmeter with No 36 cottern covered copper wire till nearly full. Pieces of wood are then cut to

### TO MEASURE THE PRESSUPE OF A CURRENT 25 .

fit, and glued in each corner of the bobbin as supports (see dotted lines in fig 13), the bobbin screwed on the base and an ordinary wire null (minus the head) driven into the base at right hand side of paper tube (inside) as shown at W, fig 18

The action is made from a piece of brass wire





about  $\frac{1}{2}$  in, thick and  $1\frac{3}{2}$  ms long in each end of which is drilled a small hole with a needle drill about  $\frac{1}{16}$  in, deep. An ordinary fine pin (without the head) is soldered in each end to act as straight pivots (fig. 17). It is very necessary to have a good working fit in the bearings, and yet no binding is, should the holes in bearings be a shade too large of too solall,

.

#### TO MEASURE ELECTRICAL RESISTANCE 29

to give 10 ohms resistance is  $l = \frac{10 \times 00164 \times 10^9}{42 \times 10^3 \times 30.48}$ = 12.8 ft.


And the various resistances used in the box are.

1 resistan	ce of	20	ohm	s	=	25.6	fί.
9 iesistan	ces "	10	,	each	1 ==	$115\ 2$	4
9 "	,,	1	7.	,,	-	11.52	
9. ,	,	-	1,	2/	-	1152	~
2		2	<b>y</b> .	"	=	512	e

Therefore the total length of wire is 158:92

The box is made from 1-in teak, and is 12 ms by 9

ms. by 3 ins, the top is 15 ins by 10 ins, by  $\frac{2}{8}$  in, thus overlapping and giving a better finish to the box. The other material required is as follows—Thittytwo brass study of the kind shown in fig 19, seven brass terminals (in this case of two different sizes, which is may be seen, adds to the appearance of the



be seen, adds to the Frg. 19 —Brass Study for Wheat this annearance of the Bridge

box although for all practical purposes they could equally well have all been of the same size) a piece of sheet brass, a length of brass wire, on which

# CHAPTER III

# INSTRUMENTS FOR MEASURING ELECTRICAL RESISTANCE. THE WHEATSTONE BRIDGE

THF range of the bridge to be described is from 1 to 909 ohms but it may be used merely as a variable resistance, the Simple Sensitive Galvanometer in Chapter I would be suitable for use with it

The wire used for the resistances which constitute the various arms of the bridge is No 26 S.W.G. manganin wire. The use of manganin reduces to a minimum any errors which may arise from changes of temperature, but the lengths of manganin given here must not be strictly adhered to, owing to slight variations in the composition of manganin. It will be necessary to get the specific resistance of the particular alloy used, when the length of wire necessary may be found from the formula  $l = \frac{RA}{\rho} 10^{\circ}$ , where R is the resistance, A the cross-sectional area of the wire used, and  $\rho$  the specific resistance, thus result being divided by 30.48 to bring to feet. Thus the specific resistance of the manganin used here is 4 2000. Therefore the length of No 26 wire necessary

to wind the resistances, a piece of ebonite from which to make the knobs for the keys and levers, and brass nuts for the terminals and studs.

The keys are made from  $\frac{1}{16}$ -in sheet brass, and are of the dimensions shown in fig 20. A hole is drilled and tapped through the terminal disc and key, into which a piece of brass wire is screwed, leaving about 1 in protructing from the under side This protructing piece is then sunk into the wood, thus





Fig 20 -- Detail of Key for Wheatstons Bridge

effectually preventing the key from turning when the terminal head is screwed down. All the other terminals are pinned down in the same manner. At the end of each key is fixed an ebonte knob by means of a small round headed screw nail, the head of the screw nail also serving as a contact. The other contacts for the keys are made by turning down a brass stud, until there is only about  $\frac{1}{16}$  in left to project above the top.

The pins for the levers (fig. 23) are made from pieces of  $\frac{1}{4}$ -in diam brass wire  $1\frac{1}{4}$  ins long, screwed


## TO MEASURE ELECTRICAL RESISTANCE 31 4

to take a nut at each end. On the end of the jun, which projects above the top, and just below the



thread, a piece of brass tubing is sweated, thus providing a shoulder to beau on a brass washer, otherwise a thicker piece of wire would be necessary,

and then it would require to be turned down. The pin passes through the above-mentioned washer, which has three holes dilled in it, to enable it to be screwed at the top and then through two brass wishers on the inside of the box—one a flat washer, and the other a spring washer, the former to prevent the spring washer from eating into the wood and the latter to press against the full to prevent it from turning when the lever is moved over the study.



The lever itself is made from  $\frac{1}{1c}$  in sheet brass, broad enough to span two studs, and having  $\frac{1}{2}$  in hole drilled at one end, through which the pin passes. The studs are hellow and are screwed both inside and out the inside throad to take a piece of brass wire about  $\frac{1}{1c}$  in diameter on which the resistances are wound

Fig. 2%, -Diagram showing Use of Wheatstone Builse


Having found the necessary length to give the required resistance, it must be wound non-inductively  $-\epsilon t$  it must be wound on the double as shown by fig. 10, one end being soldered to the wire on which it is wound and the other end connected to the next piece of brass wire. Shellac variash or parafin wax should be used unsparingly for the resistance coils.

For short-cucuiting either the 20 ohm or the

## TO MEASURE FLECIFICAL RESISTANCE 33 .

2-ohm resistance. So as to make the latto aims equal, or as 10 + 1, two pieces of sheet copper are made as shown in the drawing, and sweated to the ends of a short length of flexible cord.

To use the bridge, connect the battery, galvanometer, and the resistance to be measured, as shown in the diagram Make a rough estimate



of the unknown resistance, and place the levers accordingly afterwards moving them about until no deflection of the galvanometer is observed when both keys are tapped. Then if the 20-ohm resistance be short-circuited so that the ratio arms are equal the unknown resistance will be equal to the sum of the resistances in the various incostats. If the unknown resistance be estimated at over 100 ohms, short circuit the 2 ohm resistance, making the ratio

as 10 - 1 then the unknown resistance will be equal to ten times the sum of the constances in the various rheostats. It will thus be seen that for resistances over 100 ohms the degree of accuracy which can be attained is to 1 ohm, while for resistances less than 100 ohms a degree of accuracy can be attained to 1 ohm The reason why by making the ratio as 10 . 1, the range of the budge may be increased will be better understood by comparing the winng diagram (fig. 21) with the diagram (fig. 22) When there is no potential difference between the pts. C and D then there will be no tendency for a current to flow along the wine connecting the galvanometer with these points, and therefore there will be no deflection of the galvanoineter needle. This happens when a = b and a = R, or when a is in the same ratio to b as r is to R The connections are shown in the general arrangement, also the manner in which the resistances are connected although the resistances are only shown in one of the rhcostats still the other resistances are connected in the same way.

While making a test the galvenometer should if possible be placed on a separate table so as to be as free from vibration as possible; but before connecting it to box, the battery key should be tapped, and if any deflection is observed on the galvanometer it should be taken into account, or the wires leading to the galvanometer should be twisted together. Also, the battery key should be tapped before the galvanometer key.

61.5

# CHAPTER IV

INSTRUMENTS FOR MEASURING STATIC ELECTRICITY

GOLD LEAT ELECTROSCOPF —This instrument consists of the base (fig. 24), into which fits the glass bell jar shown in fig. 25. The top plate or table (fig. 26) is struck from sheet brass  $\frac{1}{2}$  in thick. This can be cut to shape as near as possible with a hack-saw, and having been fitted with the  $\frac{1}{2}$ -in brass wire

		4 <sup>3*</sup>	<u>بر معروم</u>	1
SECTION	Ø		Ø. <i>SHIMIMI MINI</i>	(H
	R.	<b>H</b>	SECTION	ЪТ.
54		37		//

#### FIG 24 - Date of Electroscope.

seen in fig 26, turned up in the lathe Or it may be trued up with a file and then fitted to the brass wrie by soldering. Soldering is an easy matter when done in the right way. Well clean the surfaces to be soldered together by filing until quite bright, heat over the spirit lamp or Bursen burner and use rosin as a flux, touch the centre of the brass plate with a stick of solder, and when the former is

1 8

of gum on the flat sides of the rod and hold your breath for a moment, whilst the strps are taken up on a needle point and set in place on the rod. The strps may be cut by placing the gold leaf between a sheet of clean notepaper and cutting the notepaper into  $\frac{1}{2}$  in strips. This, of course, will cut the leaf at the same time. Place the jar in the groove in the base, and all is complete. If properly made, this electroscore will kevery sensitive, and should possess an excellent appearance

# CHAPTER V

# PRACTICAL DETAILS OF CONSTRUCTION — MAGNETIS-ING NEEDLES, SUSPENSION, I EVELLING DEVICES, AND CALIFICATION

10 MAKE MAGNELIC NEEDLES -These are usually of lozenge shape and flat, not circular libe a sewingneedle though such a needle can be used it is advisable to keep to the recognised form The needle must be made of steel which can be hardened iron or tin will not do. Such material as steel watch and clock springs will do very well. If you take a piece of old spring anneal it first by making it ied hot and allowing it to cool slowly, if it is build in time or ashes it will cool more slowly than if exposed to the au When filed to shipe make the needle red not and plunge it into water to harden it, this hardening will make the steel very brittle so that care must be used in handling, but it is advisable to make the needle very hard because the harder it is the better will the magnetism be retimed, you can however, re-magnetise the needle any number of times should it become weak by loss of magnetism during use

6 63

needle upon one of the poles of a dynamo, in this instance the magnet would be, of course, fixed and the needle moved, but the method of stroking always in one direction must be adhered to

Supporting the needle —When supported on a point, the centre of gravity of the needle must be below the point's tip or it will not remain in position, this is managed by fitting a little briss cup into a hole in the centre of the needle as shown in fig 31, taking care that the point comes well through the needle, the cup is made with a slight shoulder, which is buried down over the needle after it has been slipped on

Note — it is of no use to attempt to magnetise a needle whilst it is red-hot, or to harden it after it has been magnetised, heating it destroys the magnetism.

IFVILLING SOLEWS.—For the purpose of setting a galvanometer truly level, so that the needle may swing freely, attachments known as levelling screws are often fitted. These consist of brass strips screwed to the base, each strip being drilled and tappe to receive a vertical milled head screw (fig. 32 shows such alevelling screw), three are always used because a body will rest firmly upon an uneven surface if supported upon three points, the brass strips should be fixed at three equally-spaced intervals as shown in the sketch (fig. 33), which represents a galvanometer base fitted with three levelling screws, the screws are placed with their points downwards, by screwing any one up or down the instrument will be tilted

# PRACTICAL DETAILS OF CONSTRUCTION. 43 -

at that place and very accurate levelling can be quickly attained, the dimensions are approximate, and may be altered to suit any particular requirements

WINDINGS OF INSTRUMENTS — These are not calculated with the accuracy required for windings of dynamos and motors, except in some very special case the exact gauge of wire or quantity does not matter, the gauge is selected so is to be appropriate for the current which the instrument has to cury but anythmg within several gauge numbers will do,

if the instrument is to measure small currents a fine gauge of wine is selected if it will be used to measure heavy currents a coarse while is selected, if the instrument is required for measuring both weak and heavy currents two or three windings are sometimes put on the same




instrument, as in the case of the vertical detector described in Chapter I. For very heavy currents insulated flat copper starp may take the place of wire, being iolled up into a coil this is especially useful for amperemeters. A coil of fine wire having a great number of turns and carrying a very weak current has practically the same power as a coil of similar size consisting of few turns of thick wire but carrying a strong current. If the coil does not have sufficient effect, wind on some more wire and try again. Silk covering is best for fine wires, but coton covering will do

instrument might be quite accurate enough for many purposes, especially as you would know the value of the readings Suppose you had graduated a voltmeter up to 10 volts by means of ten Daniell cells, you would know that each volt on your scale represented more than an actual volt, in fact, your 10 volt division would represent nearly eleven volts, and you would make allowance accordingly when reading the scale.

You will probably find that the needle moves a nuch greater distance for an addition of one volt when in the middle of the scale than when near either end; this is a peculiarity of certain types of instruments; the spaces from volt to volt can be divided up into divisions to show quarter and half volts by dividers, but the exact positions should bear some relation to the general characteri of the scale; in the middle of the scale the half volt will be about central between the volt divisions, but at the ends the half volt will be rither more to the right or left, according to the amount the scale generally is opening out or shutting up

AWPEREMEDTERS — The method of connection is shown in fig 35, and the instructions given for voltmeters apply to ampéremeters also, but whereas to calibrate a voltmeter you need a very small current and a large number of cells, to calibrate an ampéremetei you need only one or two cells, but they must be capable of giving a large current, as you must have the ampéres required by the highest réading you are going to mark on the scale. The PRACTICAL DETAILS OF CONSTRUCTION



6 3:

c



adjust the resistance until the standard instrument reads, say. 1 ampere then mark off your division on the scale under test, readjust the resistance until

the standard reads 2 amperes, and mark off the second division, and 20 on, intermediate divisions can be marked if you can get a sufficiently fine adjustment of the resistance

There is a method by which the standard ampèremeter can be dispensed with provided you have your voltmeter ready, and this is as follows · obtain a length of wire of known resistance, say 2 ohms, and of thick enough gauge to carry the largest current your ampelemetel is to take, connect it to a battery or dynamo so that it is in series with your amperemeter (see fig 36), and join your voltineter to its ends, a regulating resistance is required to vary the current By Ohm's Law the current flowing through the resistance will be equal to the volts applied to its ends divided by its resistance in ohms as you know what that resistance is, and can see what the volts are at any given instant by means of the voltmeter you can calculate the amperes flowing through the amperemeter. For instance, if the voltmeter reads 10 volts the current would be 10 volts divided by 2 ohms (if the previously mentioned wire was used)=5 amperes, you would therefore mark the ampere scale at the place where the pointer was standing as 5 amperes You do not need to know the volts of the battery exactly, but it is obvious that you must select your resistance to suit the current to be measured and the volts of your battery.

### CHAPTER V1

### IHF PRINCIPIES UFON WHICH ELECTRICAL MEASURING INSTRUMENTS WOFK

GALVANOMETERS -These instruments usually work by the attraction or repulsion of a magnetised needle placed near a wire carrying the electic current; sometimes a second wire, through which the current also passes, is used instead of the needle. The wire is wound into a coil to increase the effect. If you support a magnetised needle upon a pivot at its centre or suspendit by means of a fine thread so that it can freely turn round like a compass needle, and present one of the poles of a magnet to either end. that end will be attracted to or repelled from the magnet: like poles repel one another unlike poles attract one another. When an electric current passes through a ware that wire becomes a magnet. but its poles are at right angles to its length instead of in the direction of its length, as in the case of the magnetised needle or steel bar magnet, and these poles remain thus, no matter whether the wire is kept in a straight length or wound up into a circular or finttened coil Unlike the steel bai magnet how-

ever, the N. and S poles are not permanently fixed, but may be respectively on one side or the other of the wire according to which way the current is sent along it.

If such a coil of wire is fixed in position and a magnetised needle pivoted or suspended close to it so that one side of the coil can affect the needle when current is passed through the wire, such an arrangement will produce the same effect as the bar magnet referred to did upon the suspended magnetused needle, according to which end of the wire the current enters, so will the needle be attracted or repelled. If a light pointer is attached to the needle, the latter with the coil can be enclosed in a case, or the needle even placed inside the coil as its movement would be shown by the projecting end of the pointer It may be considered that any coil of wire currying a current is a magnet as long as the current flows. We shall now be able to understand the working of the galvanometers described in Chapter I

Taking firstly the simple Galvanoscope or Detector. In this instrument the magnet sed needle is supported on a prot directly over the coil of wire which curries the current, as soon as the current flows an invisible magnet is created by the lines of force set up by the current, as indicated in fig 37 by the dotted lines; the N pole of the needle is attracted by the S pole of the magnet and the S pole of the needle is attracted by the N pole of the magnet, and the peedle turns in the direction of the

# THE PRINCIPLES UPON WHICH INSTRUMENTS WORK 51

arrows, the movement being assisted by the repelling action between the like poles of needle and magnet respectively. If the current is sent through the call of wire in a reverse direction, that is allowed to enter at the other end of the wire, the invisible magnet will also be created with reverse poles, the N pole being where the S pole was in the first instance, consequently the needle will then move in the opposite direction, the greater the strength of the current the greater will be the movement of the needle from the zero point In this instrument the deflection of the needle is not strictly proportional to the strength of the current; if a current of half an ampore moves the needle through ten degrees, a movement of twenty degrees will not necessarily show that the current strength has increased to one ampere, it will only mean that a larger cuirent is flowing through the coil, but will not indicate the amount (see Chapter VIII)

In order that this instrument may work in this manner it is necessary that the needle rests in the position shown in fig 37, as it is a magnetic needle, it will like a compuss needle always endeavour to point noith and south, so that you must turn the case of the instrument round until the needle is in the correct position before sending current through the coil, if the needle hes across the coil you can readily see that the invisible magnet will merely hold it in that position, and no indication of the current will take place


VERTICAL DETECTOR .- A galvanometer which is

independent of the before-mentioned necessity of setting the needle in the zero position can be made by pivoting the needle vertically instead of horizontally, and this is attained in the Vertical Detector described in Chapter I. The principle on which it works is just the same as that applying to the Horizontal Galvanometer, instead, however, of relying upon the magnetism of the earth to retain the needle at the zero position, it is kept there by means of a weight arranged that so long as the instrument is placed on a level support the needle will point to zero when no current is flowing through the coils without the necessity of placing it in a position facing north or south or any particular direction. The needle is placed inside the coils of wire for convenience and as before must lie in the same direction as the wire, when an electric current is passed through the coils an invisible bar magnet is produced as before-see dotted lines in fig 58, m which the coils are shown further apart than actually used, to more clearly show the needle The needle will be attracted by the poles of the magnet in the direction indicated by the arrows, when the current is sent through the coils of wire in a reverse direction the poles of the magnet will be reversed and the needle will be deflected in the reverse direction

One coil only could be used and the action would be the same, but a better effect is produced by using a pair of coils one on each side of the needle. It will be seen from this that it is necessary to so wind the coils that they assist each other, and do not

# THE PHINCIPLES FION WHICH INSILUMENTS WORK 53

oppose, if they opposed each other they would each iry to create a magnet but having poles at opposite sides the result being that the two magnets would be trying the one to pull the needle one way and the second to pull it an opposite direction, so that no deflection would be obtained. This principle of opposing coils is used in an instrument termed the Differential Galvanometer, a separate current being sent through each coil the object being to ascertain if the two currents are equal in strength, if they



are so, the needle does not move but it one is stronger than the other, then it will overpower the weaker coil in propertion to the difference between them, and the needle will give a deflection in one direction or the other. Such an instrument is generally only used in idvanced work and for telegraph signalling, and except as an interesting example need not be considered by the elementary worker.

To return to our Vertical Detector the direction of winding is shown in fig. 38, if you should happen

to have wound one coil in the reverse direction there is no need to rewind it, but simply connect end B instead of end A to end C of the first coil It is not usual to attach a separaté balance weight for the purpose of luinging the needle to the zero position two methods are employed, either the needle is fixed so that the axle on which it turns does not piss exactly through its centre, in which case one end will be heavier than the other and always hing at the bottom, or the pointer is made with a weighted end (this is the better method), as shown in the illustration in Chapter I, which produces the same result. It is essential that both coils and needle are vertical; if the needle is horizontal and the coils vertical, no deflection will be obtained.

When two sets of coils are wound as described in Chapter L each set is quite independent of the other, and can be reguled as if the other set did not exist, current is only sent through one set of coils at the same time

The Simple Sensitive Galvanometer works in the same manner as the Detector shown in fig 1; the heedle is inside the coil instead of being on the top; it is again essential for the needle to he in the same direction as the coils and be preferably set N, and S; like a compass. However, as explained in the directions for making, as this is a very sensitive instrument, the needle can be brought to zero by the action of a weak magnet:


VOLIMFIELS AND AMPIREMETERS -The principle of the altraction and repulsion between poles of

#### THE PRINCIPLES UPON WHICH INSTRUMENTS WORK 55

magnets (a magnetised needle is simply a bar magnet on a small scale) is largely used for amperemeters and voltmeters these instruments being in reality galvariometers constructed for some definite kind of measurement, when made on this principle they are known as electromagnetic instruments. In the voltmeter and amperemeter described in Chapter II. the coil of wire attempts, as in the galvanometers previously referred to to produce an invisible magnet passing through its centie but as the two pieces of soft non W and F have been placed inside it the force of the coil is concentrated in them and they become two small bar magnets whenever a current passes through the coil, the N pole of W being at the same end as the N pole of F and the S pole of W being at the same end as the S pole of F As neither magnet can turn round, these poles repel one another, consequently the movable magnet F is thrust away from the fixed magnet W, the stronger the cutrent flowing in the coil the more powerful will be these magnets and the greater the repelling effect. It is to be noticed that the principle of attraction between magnetic poles is not used in these instruments, and that the earth's magnetism does not affect the moving magnet, so that to bring it back to zero it is necessary th add some means of control; this is usually dong by means of a spring or a weight In the in a ments described a small weight is attached to the spindle on which the indving magnet moves, so that the repelling force is compelled to lift the weight. It will be seen from

1. T. 4.

this that it is necessary to fix the instrument vertical and in one certain position only (see Chapter VII) Such an instrument is termed a gravity voltmeter or amptemeter because the force of gravity is used to control the movement of the needle. When a spring is used instead of a weight, it takes the form of a watch han sprin; threaded over the spindle to which the inner end of the spring is fixed the other end being attached to the bearing support (see fig. 39); the rotation of the spindle



te ids to wind up the spring Such an instrument can be used in any position and is termed a springcontrolled volumeter or ampletemeter, the spring should be made of a material which is not affected by magnetism, such as palladium or phosphor honze. There are other systems of movement in use for voltmeters and ampletemeters, one is known as the Hot Wire system, in which a thin wire is tightly stretched between a system of levers and the current passing through the wire heats it and causes it to expand in length, permitting one of the levers to move, this movement is transferred to the


# THE PRINCIPLES UPON WHICH INSTRUMENTS WORK 57

pointer by a link or gearing, the stronger the current the more the heat which is developed, resulting in greater expansion of the wire, and therefore a larger movement of the pointer. Another method is termed the Moving Coil system instruments of this class have a rectangular coil of very fine wine attached to the spindle, and arranged so that the edges of the coil purallel to the spindle move close to the poles of a powerful horseshoe steel magnet, the spindle is controlled by a han spring at each end The current to be measured is sent through one spring into the coil and leaves through the spring at the other end The movement forms practically a magneto electric moto, with a one coil armature which turns through a smaller or large angle according to the strength of the current flowing through the coil Both Hot Wire and Moving Coil instruments domand the highest class of workman ship, they may be considered as too difficult for an amateur to construct, but being largery used, are referred to as a matter of interest

There is yet another class of voltmeters called Electrostatic instruments; these depend for their action upon the attraction effect between plates of metal which are statically charged with electricity. The moving plates are in the form of vanes which move near to the fixed plates and have the indicating pointer fixed to them, the positive and negative poles of the source of current are attached to the fixed and moving plates, one pole to each, no current flows a static charge only being created, and in this

152-6


the insulated whe or metal, and one wire from the galvanometer to the metal which is in contact with the earth, by which is meant also in contact with any support to which the metal is fixed or on which it rests 'earth' does not necessarily mean the ground. If the galvanometer needle does not move, there is no leak, if it moves very slightly or gives only a faint indication of moving, the leak is only



partial, and is probably caused by moisture, so that, before unwinding the coil or removing any wires, an attempt should be made to dry up any moisture by waiming the coil, and then the test should be made again in order to ascertain if there is any improvement. If the needle moves quickly to one side and gives a large deflection, the leak is caused by metallic contact and is called a 'dead earth', no amount of drying will remedy it, but the place must be sought for and a repair made.

## HOW TO USE ELECTRICAL MEASURING INSTRUMENTS 63


To DETECT A BREAK IN A WIRE — Fig 41 shows the connections to be made when testing to find if a wire or coil of wire is without a bleak throughout its length In the illustration a field magnet coil is being tested, one wire from the battery is joined to one end of the coil of wire, and one wire from the galvanometer is joined to the other and, if the needle moves quickly and gives a large deflection it



is a sign that there is no break in the wire, but if there is no movement of the needle at all it shows that the wire is broken somewhere or if there is a very slight movement it shows that the break is partial, such as might be caused by a crack through the wire. This test is termed a continuity test, and may be generally used to ascertain if encuts through switchboards, instruments, arrangements of wires for highting etc. are complete

IDENTIFYING THE ENDS OF COILS, ETC. - The

principle of this test, which is really a continuity test, is illustrated in fig 42, which shows its application in sorting out the correct ends of a set of armature coils Imagine an armature which has been fitted with a new commutator, and that the disconnected ends have become mixed up so that you cannot tell by looking at them to which coil



they belong. Apply the continuity test by joining one wire from the battery to the end of one coil, then, taking the free wire from the detector galvanometer in your hand, touch the bared ends of all the other coils, one at a time, as soon as the needle moves you know you have found the other end of the coil to which the battery wire is joined.

TO DETERMINE THE POLARELY OF A BATIERY OR DYNAMO.—In the foregoing tests the direction in


#### HOW 10 USE ELECTRICAL MEASURING INSTRUMENTS 65 \*

which the needle moved did not affect the test, it was sufficient to note the absence or presence of the deflection, we did not require to note whether it moved to the right of the left hand, but in the test which we are now dealing with, it is the direction in which the needle moves which is going to tell us what we want to know According to which way a current is sent through the coils of a galvanometer, so will the needle move to the right or left hand Though there is no scientific reason to say that the current leaves any particular terminal of a primary battery it is agreed, as a matter of convenience, to always consider that the current leaves the battery from the terminal which is connected to the carbon or copper plate and to call that the positive terminal the zine connected terminal leing called the negative terminal The first thing to do therefore, is to con nect one of the terminals of the galvanometer, it does not matter which to the cubon or copper connected terminal of a battery (an accumulator will do if you know which is the positive terminal, it is generally marked with a + or a red mark) and mark it with some distinguishing sign then touching the other terminal with the wire which is connected to the negative terminal of the battery, note in which direction the needle moves, having done this, you have an instrument which will enable you to ascertain the polurity of any source of electric current, because when you connect the galvanometer to any terminals from which electric current can flow, if the needle moves in the direction in which it did when you


a faulty lamp or to want of volts; in this case the voltmeter becomes a shunt across the mains. It may be, however, that this last lamp is connected to the mains by very long wires in a branch circuit, and that though there is correct pressure in the mains the lamp burns dull, you therefore connect the voltmeter as shown in fig. 47 to find out if you have dropped too many volts in the branch circuit, the instrument is now connected as a shunt to the terminals of the lamp, and indicates the voltage at that point.

It may be that the current is supplied by a dynamo highting, say, 5 lamps in series, each requiring 50 volts, the voltage at the dyname terminals will therefore be 250 volts; the last lamp is burning dull, and you desire to know if it is receiving proper pressure, the voltmeter is to be connected as shown to the terminals of the lamp, and it will indicate the volts at that particular point from one terminal of the lamp to the other. Fig 48 shows a diagram of a 4-cell accumulator, and method of applying a voltmeter to test the voltage of one of the cells, the wrise from the voltmeter are pressed against the lead connecting strips at the ends of the positive and negative plates, scratching into the surface of the lad so as to get a good contact.

How TO USE AN AMITREMETER — This instrument is usually called an ammeter, the word being shorter and convenient to use. Its use is to measure the current flowing through a circuit and it is always connected directly in the circuit through which the



current is flowing. When used to measure the current taken by a motor, lump, or any piece of apparatus, the ammeter is always to be connected in series with it. As the instrument should interfere as hitle as possible with the existing conditions of the circuit, and should permit the current to pass freely without hindrance, its coils must have a very low resistance, on this account an immeter should never be connected to the terminals of a



primary battery or accumulator to ascentan how much current such a battery will give unless ycudesne to find out what the battery will do when short cir curted, as the ammeter, having

an exceedingly low resistance, will form a short circuit. A large primary battery of low resistance, such as a bichromate or Bunsen cell, would discharge a very heavy curient on short circuit and the coils of the ammeter would be probably burnt out if you made such a test and left the instrument in circuit for more than a second or two

Some examples of the use of an ammeter are, to measure the ampéres flowing through (1) a main account, (2) a branch encuit; (3) the normal working


#### HOW FO USF FLECIFICAL MEASURING INSTRUMENTS 73

current given by a dynamo or battery , (4) the total current taken by a motor , (5) the volts at the ends of a known resistance , (6) the resistance of a wire or coil of wire – Fig 49 shows an animeter connected in the main circuit of a dynamo lighting a number of lamps, the whole of the current passing to the lamps flows through the animeter, which thus indicates, not the current taken by one lamp or by any particular lamp, but total the current taken by them altogether.


In fig 50 the ammeter is shown as arranged to measure the current in a branch circuit which may consist of one or more lamps, or a motor etc., the instrument does not now take any notice of the current consumed by the lamps in the main circuit but only indicates how many amperes are passing through the branch cucuit, another example of the measurement of a branch circuit is given in fig 51 which shows the ammeter connected so as to measure the current which is flowing through the shunt field coils of a dynamo; as in the previous case, the mstrument does not take any notice of the main current which is flowing to the lamps, but only indicates how many amperes are passing into the field coils of the dynamo. Example No 3 is a case in which the conditions of the circuit must be adjusted to suit the nature of the test You do not, as a rule require to know what a battery or dynamo will do if short circuited, but you do require very often to know what current can be continually obtained as a working rate. To ascertain this the first thing to do is to apply a working load to the



battery or dynamo to be tested either in the form of




10 2




## HOW TO USE FIFCIRICAL MEASURING INSTRUMENTS 75

means that you must get some idea as to what the generator will stand in the way of current output unloss you care to run the iisk of damaging it through an overload Fig 52 shows the method of connecting the ammeter, the iesistance iopresenting the load you adjust the load until the ampères indicated by the instrument ispresent the amount



of current which the generator ought to give, and then continue the test as long as desired. When a wire resistance is used you will find that after a short time the current will fall, this may be owing to loss in the generator but it may also be caused by increase of resistance due to the passage of the current through the wire developing heat, so that before condemning the generator you should try and bring the current up to its full value again by

cutting out some of the wire, this decrease of the excess resistance permitting more current to flow



Mains

Frc. 53


Motor

Example No 4 to measure the total current taken by a motor. Connect the ammeter in series with the motor, as shown in fig 53; it does not matter whether

# HOW IO USE FLECTRICAL MEASURING INSTRUMENTS 77

you connect the ammeter to the positive or negative main

Example No 5 to measure the volts at the ends of a known resistance This method depends upon the principle had down by Ohm's law, that if you know the current in amperes which is flowing through a resistance whose vilue in ohms is known, then you can find out what are the volts at the ends of that resistance by the formula L = CR, that is the




unknown voltage is equal to the amperes multiplied by the resistance. For instance suppose a battery whose volts are unknown is capable of discharging a current of say, 4 or 5 amperes; connect the terminals in scrice with a resistance of which you know the value in ohms (let us suppose it is 2 ohms), and with the animeter: the animeter indicates say, 3 ampires, then  $2 \times 3 = 6$ , therefore the battery is giving 6 volts " As a rule, you know the voltage which a battery will give by knowing the type and

number of its cells, but this method may be very useful to find out the voltage which is at the ends of a coil of whe in a circuit which may also contain a number of other coils of wire, so that though you may know the volts at the ends of the circuit, you do not know the volts at any particular part. The value of the resistance of the coil of wire is obtained either by reference to a wire-maker's table or by means of a Wheatstone bridge, such as described m Chapter III It is important to have the connecting wires W of large section and as short as possible, so that they carry the current very easily, if they are small you will not get a true result, as some of the voltage will be absorbed before the current reaches the resistance. In any case there will be a loss of volts in the wires W W but if they are thick and short it will be so small that you can neglect it

Example 6 to measure the resistance of a coil of wree. The principle of Ohm's law is again applied here. If you send a current of which you know the value in ampcres through an unknown resistance, you can find the value of this resistance in ohms provided you know the volts at the ends of that resistance, because  $R = \frac{E}{C}$ , that is the volts divided by the ampères will tell you the ohms of the resistance. The connections are made as in fig. 55 Suppose the voltage is 100 volts and you find that a current of 2 amperes is flowing through the resistance, then 100 volts divided by 2 ampcres gives 50 ohms as the resistance of the coil of wire. As in the previous example, it HOW TO USE ELECTRICAL MEASURING INSTRUMENTS. 79

is important that the writes joining up the resistance and ammeter are of ample size.


Fig 56 shows a switchboard for use with a dynamo charging accumulators, the method of connecting the voltimeter and ammeter is shown, it will be seen that the voltimeter is connected as a shunt to the dynamo mains, and indicates the voltage where the cuirent enters the switchboard, and that the ammeter is in series with the accumulators, so that it will




measure the amperes passing into the cells. If a regulating resistance is used on the switchboard then you will probably prefer to know the voltage at the terminals of the cells, as it does not matter what voltage the dynamo is giving so long as the right voltage is at the accumulator terminals, in this case the voltmeter wires would be joined to terminals C.C. instead of to the terminals D.D.

It is sometimes desired to cut ammeters and voltmeters out of circuits without disturbing the


current flowing through the mains, this is accomplished in the following way —with in ammeter, by means of a short circuiting plug, and with a voltmeter, by means of an open-circuiting plug. There is a distinct difference between the two methods with an ammeter the plug acts as a by piss through which the current flows instead of going into the



instruments, with a voltmeter the plug opens the voltmeter encouts and cuts aff all current from the instrument. Figs 57 and 58 show the connections; fig 59 shows an enlarged view of the plug and block, which consists of a pair of brass blocks drilled with a taper hole into which fits a brass plug; when the plug is pushed into the hole the five blocks are connected together, when it is taken out they are disconnected from one another.



Ammeters and voltmeters must always be set so that their needles are pointing to zero before any current is passing through them  $\Lambda$  gravity-controlled instrument must be set upright—it will not indicate in any other but a vortical position, a springcontrolled instrument, on the contrary, can be used in any position (see Chapter VI) Many instruments



are very susceptible to outside influence of magnets or whice carrying currents so that it is well, as a general rule to keep your instruments away is far as possible from a dynamo or cable. If you have any doubt as to whether the instrument is giving a true reading cut off all current from it and see if the needle moves when the dynamo is at work, it is by no means unusual for an ammeter to indicate several amperes

#### HOW TO USE FLECTRICAL MEASURING INSTRUMENTS 83

without being connected to anything, merely because it was near the field magnet of a dynamo which was at work.

Some instruments only indicate when the positive pole of the mains is connected to a particular one of then terminals, which means that the current must always pass through the instrument in one direction; in such a case the terminal is generally marked +, but if, on trying an instrument, you find that it does not give a movement of the needle, or the needle moves the wrong way, by changing over the connections of your wires, so that the positive wire will be connected to the other terminal.

#### HOW TO CHOOSE INSTRUMENIS

delicate testing generally, the astatic pattern of galvanometer is required, in which the needle is suspended by means of a single thread of cocoon silk. There are various patterns of this instrument, that known as the Thompson Reflecting Galvanometer being a recognised type. In this instrument there is a very small mirror fastened to the needle, which reflects a beam of hight from a lamp upon a horizontal scale fixed about three feet or so in front of the instrument, when the needle moves the mirror moves also and the beam of light becomes really a long pointer having no weight and moving over the scale, the image of a wire in the beam forming the indicating point.

There is also another type of galvanometer suitable for very defactic work. In this class of instrument a needle fitted with a light pointer is proted middle a single coil of wire. The sensitive galvanometer described in Chapter I is of this type and may be considered as a sufficiently deficate instrument for all ordinary purposes. One objection to the deficate galvanometers just described is, that their needles swing very much before coming to rest at the zero mark—they are not what is called dead beat

Where rapid delicate testing is desired it is very desirable that the instrument should be dead beat There is a type of instrument in which the coil carrying the current is suspended by stretched delicate wires so that its sides move near the poles of a powerful steel horseshoe magnet. This kind of galvanometer is called a D'Arsonval pattern, after

# CHAPTER VIII

# How 10 Choose Electrical Measuring Instruments

In order that an instrument should be of maximum usefulness it should be selected with reference to the particular range or class of measurement in which you desire greatest accuracy. All instruments have their limitations; some are much better adapted for centum work than others, and the following limits will assist the reader to make his choice

GAIVANOMETELS — For rough work, such as detecting currents when making apparatus in the workshop, a simple horizontal pattern with pivoted needle and scale divided into degrees will suffice, but if the time taken up in testing is important, a vertical pattern detector galvanometer with weighted needle is better, is the needle of the horizontal pattern swings about a great deal, so that you may have to wait some little time before it comes to rest at the zero position , the vertical detector pittern is also more useful for out door work or testing wiring in a house, as it does not require setting to zero and is more portable. When very minute currents require to be detected, and for

84

methods employed a little vane moving in oil or an air cylinder may be attached to the spindle. But there is one class of instruments termed Moving Coil ammeters and voltmeters which are automatically dead bet by virtue of the principle on which they are constructed. In these instruments a small coil of whe attached to the pointer moves near the poles of a powerful steel magnet, they are very sensitive, not much affected by outside magnetic influence, and are suitable for very accurate measurements, but they can only be used for continuons jurient work

VOLIMFIERS FOR TESTING BALLERIES - High resistance batteries such as small div cells are not capable of giving a large current, if you desire to test such cells by measuring their volts it is necessary to use a voltmeter which has a comparatively high resist ance, or else the instrument will draw more current out of the cell than it gives in regular work consequently its voltage will fall and you do not get a fair test. You should therefore be careful to see that your voltmeter is adapted for this particular class of work if you wish to get accurate results, do not accept a casual test with any voltmeter as evidence of the condition of such a cell. Bitteries such as the Bichromate pattern or an accumulator may be safely tested with any ordinary voltmeter as they will give a fair amount of current

AITEPNATING CUPRING INSTRUMENTS --- Testing of insulation, the conductivity of wires and measurements of a similar character, are generally done with continuous current, in the case of alternating

#### HOW 10 CHOOSE INSTRUMENTS

current you require to measure amperes and volts. ie watts or electric power which in alternating current work is not always found by multiplying together the volts and amperes as in the case of continuous current, whenever the current is flowing through any apparatus having coils of whe or electromagnets in the circuit such as a motor or transformer. you would not get the watts by merely multiplying the amperes and volts together, though your result would be fairly correct in the case of alternating current lighting incandescent lamps. Whilst some types of ammeters and voltmeters are specially suitable for use with alterniting current, instruments of similar principle to those described in Chapter II can be used with either alternating or continuous current. When intended for use with alternating current they are tested with that kind of current and marked accordingly but if a continuous current instrument is used with alternating current it will probably, in the case of types as described in Chapter II, indicate about 10 per cent less than the true reading, especially if it is a voltmeter. Unless the instrument has been made with a view to use the alternating current it will get hot after a short time, so should only be used for a few moments at a stretch. In instruments designed for alternating current if the coil is wound on a metal bobbin the metal must be divided at one place by means of a saw, cut so that the centre and flanges do not form a complete ring

WATFMULERS are instruments for measuring electric power, and they automatically multiply the

7

"THE MODEL ENGINEER" SERIES NO. 3 EDITED BY PERCIVAL MARSHALL, A I MECH F

# Electric Bells SEVENTH EDITION and Alarms.

#### By F. E. POWELL

Illustrated with numerous Engravings and Original Drawings.

CONTENTS — Preface Chapter I — Electric Bells; Principles of their Construction, Various Types; Single Stroke, Continuous Runging, Incket; Magneto Bells III — Batteries Leclanche, Sealed; Carporcus; Agglomerate, Dry, How to Connect up the Cells, Wire III — Pushes; Switches & Burglar Alarms, Door Tragers, Indicators, Relays, IV – How to Install Electric Bells V — Examples of Special Bell Circuits; Connections to 'Earth' VI — Electric Clock Alarms VII — Faults and Repairs; Hinds on Testing; Battery and Bell; Current Detectors, How to keep the Battery moder.

"THE MODEL ENGINEER" SERIES NO. 4

# TELEPHONES AND MICROPHONES:

# HOW TO MAKE AND FIX THEM.

#### EDITED BY

PERCIVAL MARSHALL, AI Mech.E.

Fully Illustrated with Original Diagrams and Drawings

#### FIFTH EDITION.

CONTENTS — Preface Chapter I.— The Principles of Telephone Construction. II — Microphones and How to Make Them III — How to Make a Simple Telephone. IV — How to Make rule fix a Wall Telephone V — How to Make a Desk Telephone. VI — Telephone Circuits; Testing, Faults and Repairs, Batteries. Wires; Insultators, Euth Connections. VII — Modern Types of Domestic Telephones.

From all Agents for THE MODEL ENGINEER, price 6d. nett. or. post free, id. from PERCIVAL MARSHALL & CO., 26-29 Poppla's Court, Fleet Street, LONDON, E.C.

# - LIST OF -Cechnical Books

SUPPLIED BY

# Percival Marshall & Co.,

# 26-29, POPPIN'S COURT, FLEET STREET, LONDON, E.C.

Any Technical Book not in this List can be supplied to order. Inquiries are invited, and will be answered by post free of charge. Foreign and Colonial customers interested in special subjects may open deposit accounts, and have the latest works forwarded to them directly they are published.

# MECHANICAL ENGINEERING.

# Gas and Oil Engines, and Gas Fitting.

20

- The Gas and Oil Engine By D.guld Clevi, M.I.C.B. with 228 Hustonitions 8vo Postage 5d
- A Practical Treatise on Moder. Uns and Oil Engines. By Fred Grover A M.Inst C.B. Thurd Fritica. Hinstratol. With 372 pages. Postage 4d
- Activiene The Principles of its Generation and Use By F H. Leads, FIC FCS and W J Attenson Butterfield, MA, FIC FCS. With Dr. grams and Illustrations. Postage in 58. 0d.
- thas l'itting. By W Graften With 143 Illustr t ins Svo Postage 4d. 5s od-
- Gas and Oil Engine Management. By M. Powis Bale M I M.E. A handbook for users Being notes on Selection Construction and Working Crown Svo. Cloth. Postage 3d
- Gas and Petroleum Engine: A darted from the French of H De Graffigny, by A G Elliott. B So. A Usefel and Liementrary Treatse for Non Technicas Readers With S2 Illustrations. Portage 3d. 28, 6d.
- Fractical Gas Fitting By Paul N Hastick With 120 illustrations, 160 Pages Cloth Crown Svo Postage id. 28. 6d
- Gas Engines Their Advantages Action, and Application. By W A. Torkey Hintsto Purchasers Erectors and Attendants Postage 2d is Gd
- Oil Engines' Their Selection, Erection and Correction. By W A Tookey Hints to Purchasers Freedors and Attendants' Postage 2d is 0d.

tian Producers for Power Purposes By W A Tookey. For the use of Purphasers, Directors and Attendants Postage 23d. is 0d

- Gas and Oil Fngines Simply explained By W C Runciman An Elementary Instruction Book for Amateurs and Engine Attendants. Fully Illustrated Postage Id 6d
- Acetylene Gas How to Make and Use it By Cyril N Turner. A Practical Handbook on the Construction and Working of Small Lighting Plants. Fully illustrated Postage 1d

#### General Engineering.

- A Text Book of Mechanical Engineering. By Wilfrid J Lineham, M Inst.C.F. M I Mech E. M I F E Contains 1 000 pages with 920 Illustrations and 19 Folding Plates Postage 64
- Mechanical Movements Powers Devices, and Appliances. By D Hiscox Gardener For the use of Inventors Mechanics Engineers Draughtanten and all others interested in any way in Mechanics Illustrated by 1649 Engravings 402 pages 8vo Cloth Postage 5d 12a 64
- The Repair and Maintenance of Machinery, By I W Barber. With 417 Illustrations. 8vo. Pretage 5d 10s. 6d.
- An Advanced Text Book on Applied Mechanics By Professor Jamicson Vol 1 Comprising Part 1 The Principle of Work and its applications Test 64
- Part 2 Gearing Third Edition Postage 5d 7s. 6d. Vol. 2 Comprising Parts 3-6 Miction and Finerky Graphic Statics Strength of Materialis Hydraulics and Hydraulic Machinery Second Edulta-Postage 51 8s. 6d.
- Toothed Gearing By J. Horner A MIMP A Practical Handbook for Offices and Workshot, With 184 Ill strations. Crown 8vo. Cloth. Postace 1d.
- The Chemistry of Materials of Engineering. By A Humbold Sexton Crown 8vo Postage id 53 0d
- Flementary Manual of Applied Mechanics By Prof Jamieson. Specially arranged fr First Year Students Fifth Edition With Illustrations and Examination Papers. Crown 8vo Pestage 3d 35 6d
- Practical Notes on the Construction of Cranes and Lifting MacLinery. By Idwird C K Marks A M I C E., M I M.E. New and Enlarged Edition. Grown by O Patage 3d. 3s 60
- The Strength of Materials and Structures By Sir J Anderson, C.B. LL.D. F.R.S.D. Showing the strength of m-terisls as depending on their quality and as ascertained by testing apparatus. With 66 Illustrations 1 cp 8vo. Postage 8d. 35 6d.
- Mechanical Engineering Materials, By Edward C. R. Marks A. M. I C. B. M. I. M. F. Tostage 3d is 6d.

# Locomotives and Railways.

- Modern Locomotive Practice. By C. E. Wolf, B.Sc. A.M.I.M.E. A treat ise on the Design of Sterm Locomotives. With 150 Illustrations and 8 foldine Plates Postage 4d 108 6d
- British Locomotives. Then History Construction and Modern Development By C J Bewen Cooke With 150 illustrations Third Edition Thoroughly revised Crown Svc Postage 44
- The World's Locomotives. By C S Lake A Digest of the Latest Locomotive Practice in the Railway Countries of the World With 300 illustrations and 8 folding plates. Postage Great Breath. 6d. Foreign and Colonal 18 3d.
- The Model Locomotive. Its Design and Construction By Henry Greenly. 274 pages. 570 Illustrations and 9 Plates Demy Svo Postage 44. 68 0d

#### 26-29, POPPIN'S COURT, FLEET STREET, LONDON, & C.

- The Locomotives of the G N R By George Frederick Bird. A Chrono logical account of the Locomotive Stock of the G N R from its inception to the present day every type illustrated and described Posture 3d 5s. Od
- Lacomparises of the L B & S C R A complete history of all the locome trives of the L B & S C R form 1839 to the present day 144 illustrations from Drawings and Photographs every engine illustrated and described Postage 3d 58.0d
- Locomotive Engine Driving Bv Alichael Reynolds A Practical Manual for Engineers in charge of Locomotive Engines Eleventn edition In cluding a Key to the Locomotive Engine Crown Svo Cloth Postage 4d
- The Locomotive Engine and its Development. By Clement E, Stretton, C.B. A popular I resise on the Gradual Improvements made in Railway Engines between 1803 and 1903 Sixth Edition Revised and Indarged. With 130 Illustrations Crown 80% Cloth Postare 44 46
- Railway Appliances By Sit J Wolfe Barry KCB, FRS, etc. A Des cription of Rulway Construction subsequant to the completion of the Barthworks and Structures. With 21811Justrations. Feo. 8vo Postpace 3d As 6d.
- British Expresses An Album of Photograph Reproductions of Trains and Rolling Stool from photostal en in all parts of the world Postage 3d. 3s. 6d.
- The Locomotive Portfolio By F. Moore Contining 12 tea tifully executed Coloured Plates of Modern British Express Locon otives Postage 4d 35. Ed.
- Recent Developments in Locomotive Practice. Pv C. J. Bowen Cooke. With 82 Illustrations and 13 I clding, Plates Demy 8vo Clcth Fostage 3d. 25. 5d
- The Locometive of To-day. A thereagily practical Treatise on the British Locometives every detail carefully illustrated and described. Preside 8d. 28 dd
- Railway Views An Album containing Photo Engravings of Railway Subjects at Home and Abroad Postage 3d. 23, 3d
- Engine Driving 1 ife By Michael Reynolds Stirring Ad entures and Indi dents in the lives of Locomotive Lagine Drivers Third Edition Crown Syo. Cloth Postage 3d.
- How to Become a Locomotive Engineer By Randall McDonnell Advice to Young Mechanical Figureers passing through Locomotive Works. Crown Svo Clich limp Postage 4d
- The Locomotive Simply Explained By C S Lake. A First introduction to the Study of the Locomotive Engine. Fully Illustrated with Drawings and Photographs. Postage 1d. 66.

#### Machine Design and Drawing.

- Mathematical Drawing Instruments and Materials By A. G. Ihornton, Describes all Instruments and Materials used in Drawing, Tracing &c. Postage 4d. 33 6d.
- Machine Drawing By 1 Jones M I.M E and T G Jones M Sc. Wh Sc. Book 1 Seventh Edition Enlarged. General Details of Engines ard Machines 50 Plates (two coloured) Postage 4d 3s Od. Book 2 Machine Tcols Drilling Planing Slotting, and Shaping. 25 Plates
- (two ocloured) Postage 3d Book 2 Engine and Pimp Details. 44 Plates (four coloured) Postage 3d

The above three books handsomely bound in one volume Postage 6d. 10s. 6d.

- An Introduction to Machine Drawing and Design By David Allan Low. With 153 Illustrations and Diagrams Crown Svo. Postage 3d 25 64
- Sketches of Engine and Machino Details By Wallace Bentley, MIM.B. This book contains over 200 Detail Drawings fully dimensioned, from the latest practice and in-ludge drawings from Stationary Locomotive; and Marine Engines, Boilers. Gas and Oil Engines, Machine Tool, Electric Motors.eto. Third Fatton, enlarged Postage 34. . . . 28. 84

#### PERCIVAL MARSHALL & CO S BOOK LIST

- Ignition Devices. For Gas and Petrol Motors By S R Bottone A chapter treats specially of Structural Details, Choice and Management of Automobiles. 28 6d. Illustrated Postage 3d.
- Motor Ignition Appliances A practical treat se on the application of Electricity in the production of the Ignition Spark in Petrol Motors By T H 25 6d Hawley Postage 3d.
- The Autocar Handbook A Guide to the Motor Car How to Select, Maintan and Drive an Automobile Illustrated Postage 3d le 6d
- Cycle Building and Repairing. Prepared under the direction of P N Hasluck A Practical Manual with 142 Illustrations Cloth Postage 2d 18 Od Potrol Motors Simply Explained By T H Havley Describes the prin-
- ciples on which Petr I Motors work with hints on itiving Illustrated, Is, nd Postage 3d
- Practical Motor Car Repairing A Handbook for motor car owners and drivers illustrated Poetrage 3c is Od

Motor Cycles and How to Manage Them. Tenth edition Postage 2d. 18. 0d

#### Popular Books on Engineering and Science.

- Electricians and their Marveis. By W Jernard, Illustrated, 160 pages. Handst me cloth o wer. Crewn Svo Postage 31. 18 Bd.
- The Conquest of the Air. By John Alexander The Romance of Astral Nave gation With Preface by Sir Hiram S Maxim Illustrated 160 pages. to Ad Handsome cloth cover Crown 8vo P stage 3d.
- The Marvels of Metal By F M Helnes Illustrated with 100 pages. Hand some cl. h civer Grwn 8 o P singe 3d 15. Bd.
- Simple Scientific Experiments E Aorel De Patte Describes Forty six instructive Exceriments in Fleatricity Magnitism. Hydractics, Hydrastatics, Light and Acoustic Fully Idestrated Postage 14.

#### Pumps and Hydraulic Engineering.

- Water or Hydraulic Motors By P R Bibring With 206 Illustrations 99 0d Crown 8 o Postare 4d.
- Practical Handbook on Pump Construction. Ey P R Bjorling Second 5s. 0d. Edition 9 Plates. C. wn Svo. Postage 44.
- Centrifugal Pumps. Turbines and Water Meters. By Chas. H Innes. M.A. Including the Theory and Practice of Hedivalues (specially adapted for Engineers). Third Edition Crown Sin, Platage 4d. 48 6d.
- Notes on the Construction and Werking of Pumps. By Edward C. R. Marks A MICP. MIME Crown Svo. P. stage 3d. 3s. 6d.
- Pumps and Pumping. By M Pow's Bare MLMF A handbook for Pump Users. Being Nutes on Selection, Construction on Matagement. Fourth Edition. Crown Sv Clock Postage 34 3) 64

#### Reference and Pocket Books,

- Engineer's Sketch Book of Mechanical Movements By T W Barber Fourth Editi n, with 9 63311 strat as 18 pages 3 to Postage id 105. 6d.
- A Pocket Pook for Michanical Engineers By David Allan Low M.L.M.E. With over 1000 mediall ; eporal Illustrations For Set, Gilt edges 7. 64 rounded cor. 645 Fost 263.
- Lockwood's Dictionary of Mechanical Engineering Terms. By J. G Horner, AMI M.E. Company removed 55 6000 definitions. Third Botton revised with additions. Patterning done or unsatt in the Drawing Office Pattern Ship, Fanda, Little, Farring, Smithe and Bover Shipps, and the Graphic Comp. etc etc Crawn 8 : Cloth Posts, e 4d.
- Wannan's Marine Engineer's Pocket book. By A C Wannar, C.B. Containing latest Board of T ale Riles and Data the Marine Engineers Third Edit on, revised colorged and up to date Square 18ma, with Thumb Index. Leather. Postage 30. 5s 0d

#### 26-29. POPPINS COURT, FLEET STREET, LONDON, F C.

- The Mechanical Engineer's Pocket Book By D. Kinnear Clark M Inst C B. Fifth Edition thoroughly revised and enlarged by H H P Powles, A M I C E, M I M E Comprising Tables Formulae Rules and Data A handy book of reference for daily use in Engineering Plactice. 700 pages Bound in flexible leather cover, rounded corners Small 8vo Postage 6s od
- Wire and Sheet Gauges for the World By C A B Pfei'schmidt of Shef field, Paper. Postage ld is Od

#### Miscellaneous.

- Radium and other Radio-Active Flements. By L A Levy and H. G. Willis: A topular nocount of Radium treated experimentally. Crown 8vo Hilustrated with drawings and 20 full page plates Postage 3d 2s. 6d
- Patents Simply Explained A simple guide to the patenting of Inventions and registration of Trade Marks and Designs. Illustrated Postage Id #d
- Practical Kites and Aeropianes, How to make and work them By Frederick Walker C.R. A Practical Work on the Construction and Use of Kites and Accordines Illistrated Pestage 2d. 16 64
- Talking Machines and Records, A Hardbook for all who use them By S R Bottone Ille trated with examples of different types of instruments with full instructions for m long a straple phonograph. Postage 2d 15. 6d
- Suburban Houses Their Accessivies and Embeilishment. By J H Woolfitt A series of Practical A-ticles in the Making of Furniture and Fitments for Is 6d. the Hime Fistage 24
- What a Business Man ought to Know. Being the Daily Business Life in a Merchant's Office Post-ce 24. 18. Od
- Letters that pring Business. By the Author of What a Business Man ought Is nd. to Know Postage 2a
- Systematic Memory. Or How to Make a Bai Memory Cood and a Good Memory better By This Modarch. Postage 21 19. 0d.
- How to do More Business. Postage 2d is od.

#### Steam Engineering

- The Steam Turbine By Robert M. Neison Wh Ex. A.M.I.M.E. With 145 Illustratures Svo Pestage 4d 10s 8d
- Steam Engine Theory and Practice, By W Ripper, With 438 Illustra tions 8-: Postage 44. 98 Od
- A Text Book on Steam and Steam Engines. By Frif Jamieson Por the Usc of Students Prejaring for Competitive Examinations. With Soft pages Over 200 Hustrations & 6 failing Thate, and numerous Examination Papers I ourteenth Edition Kevised Pcs. Le 4d 10s 6d.
- The Engineers Pocket Dictionary, French-English By M. Lvoff, Pocket size Word, used in Mochanical and Electrical Engineering Motor Car and Cycle Fulding Postage 1d
- Stationary Engine Driving By Mchrael Reynolds A Practical Manual for Engineers in Charge of Stationary Engines. With Plates and Woodouts, Sxith Edition 8vc. Cleth. Postarge 3d. 38 6d.
- Stam Bolters Br R D Murro Showing their Defcrits Management, and Construction. Fourth Edition Fully fluw rated. Pestage 3d 45 6d. Steam Engineering Br W. W F Poller, WL Sc M IME A MICE A Treates on Bolters, Steam Car and Ol Engines and Supplementary Machinery with Instructions for Carrying at timerous experiments B50 pages 300 Illust ations P:stage 5d. 4s Od
- Elementary Manual of Steam and the Steam Engine By Prof. Jamieson For First year Students Ninth Edition kevised With Illustrations and Examinat on Papers. Postage 3d 3s Bd
- injectors Theory, Construction and Working By W P Pullen, Wh Sa AMICF Second Edition Revised and Enlarged. Crown 8vo. Postage 3d 38 64
- Steam By W. Ripper With 185 Illustrations Postage 34 28. 6d

#### Percival Marshall & Co s Book List

- Practical Dynamo and Motor Construction. By A. W Marshall, A.M.I.E.E. A Handbook of Constructve Details and Workshop Methods used in building small machines. Postage 3d 4 8 8 0d
- The A.B.C of Dynamo Design. By Alfred H Avery AIEE With 61 Illustrations and 103 pages Second Edition Postage 2d is Od
- How to Manage a Dynamo By S R Bottone A Handbook for Engineers, Electric Light Engineers, and Electro Platers Illustrated. Third Edition, revised and enlarged Post 800. Cloth Pocket size Postage 2d. 1s 0d.
- Care and Management of Electrical Machinery A hundbook for the use of power users and attendants Illustrated Postage 3d is Od.
- Small Dynamos and Motors How to Make Test and Repair Them. By F E Powell Contains Instructions and Drawings for Making Small Dynamos and Motors of various sizes from 10 to 500 watts including tables of suitable windings. Fully Illustrated Third Edition Postaçe 14. 64.
- Small Electric Motors, How to Make and Use Them By F E. Powell, Fully Illustrated with Original Diagrams and Drawings Postage 1d 6d.

#### Electric Lighting.

10

- Electric Ship Lighting, by J. W. Urqu'zet: A Handbook on the Practical Fitting and Rinning of Ships Electrical Plant Let he use of Shipowners and Buildits Marine Electricarys and Segman Bregmens in Charge Second Editron revised and extended With neurorus Illustrations Crawn Swo-Cloth Postage 4d
- Electric Wiring Fittings, Switches, and Lamps, By W. Perca Maycock, M I & E. A Practical Bock for Electric Light Engineers, Wiring and Fitting Contractors. Consulting, Engineers, Architects, Builders, Wiremen, and Students Third Elition revised Wirk 501 Ilbestations P. Stray, edd. 68. 04.
- Electric Lighting and Power Distribution. 57 W. Power Mayoork M IE E. An Elementer Maan if or Science, Fifth Educe, revised Vol I. With Bill Element and Postare 11 75 64 Vol. 11. With 100 Ployarbother Postare 11 75 64
- Practical Electric Light Fitting By F. C. Allsop, A Treatise or the Wiring and Fitting-tor fB. Hings deriving science from Control Station Mains, and the Laying down of Privite Installations. With 24 Illustrations. Fourth Bdition revised. Postage 3d. 58.04
- Electric Wiring By W C Clinton B So (Lond) A Primer for the use of Wiremen and Students With 80 Illustrations and a selection of Work Examples For 800 Postage 3d. 28 0d.
- Amateur Electrician's Workshop By S. R. Bettene. A Hundbook of Practical Instruction of the Making of Electrocal Models and Appliances. In Two yelumes. Postage 21 each Each S 64.
- Private House Electric Lighting By F H Taylor A M I E E Describes Modern Methods in Willing and Fitting, including a shipter on Small General ting Plants Postage 3d
- A Guide to Electric Lighting By S. R. Bettene. For Houseneiders and Ariateurs Peterrel covers. Postage id is Od
- Electric Lighting for Antateurs. Contains Instructions for fitting up small Electric Installations Fully Illustrated, Pestage Id. 64.

#### Electrical Apparatus.

- The Construction of Large Induction Coils By A T Hare. A Workshop Handbool With 35 Illustrations 152 pages Postage 4d . 6s. 0d
- Electrical influence Machines Their Development and Modern Forms, with instructions for Making Them. By J Gray B Sc. Second Edition. Revised. with 105 Illustrations. Postage 3d. 58. 0d.
- The liguetion Coll in Practical Work including Rontgen X-Rays. By Lewis Wright. With Illustrations Crown 8vo Postage 3d. 4s. 6d.

#### 26-29, POPPIN'S COURT FLEET STREET LONDON & C. 11

- Electric Instrument-Making for Amateurs By S R Bottone A Practical Handbook With 96 Illistrations Seventh Edition Revised and Enlayed Postace 3d 3s 6d
- Induction Coils. By G E. Bonney A Practical Manual for Amateur Coil makers Thud Edition Revised. With 101 Illustrations Postage 3d
- Dry Batteries How to Make and Use Them By a Dry Battery Expert With notes and 30 illistrations by Norman H Schneider Linp Cloth Postage 12d
- induction Coils for Amateurs How to Make and Use Them. Edited by Percival Marshall A I Mech B Contains Instructions for making a powerful Shocking Coil, etc. I ully Illastrated Postage Id. 6d.
- Simple Electrical Working Models How to Make and Use Them. Edited by Percy al Marshall A ( Mech E A Practical Handbook showing how to make Simple Models With 43 Illustrations Postage Id 6d.
- Small Accumulators How Made and Used Edited by Percival Marshall, A I M E Grees full Instructions for Making Charging and Using Small Accumulators with al Illistrations Seventh Edition Postage Id 6d.
- Electric Batteries How to Make and Use Them Edited by Percival Martinil A.I.Much P. A Practical Handbirk on the Construction and Uses of Primary Batteries. Fully Illustrated. Sath Edition Postage 1d 6d.
- Small Electrical Measuring Instruments: Describes the Malin; and Using Galvanometers, Voltmeters, Sc. Fully Illustrated Postage 1d. 6d.

### Elementary Text Books on

#### Electricity and Magnetism.

- Flementary Lessons in Electricity and Magnetism. By Sylvanus P Thompson D.Sc. FRS Illustrated, Fep. 8.c. Postage 3d. 48 64.
- Elementary Manual of Magnetism and Plectricity. By Prof Jamieson. For First Year Students F fit Fation With Illus rations and Examination Papers Creve Nov Prestace 3d 23 60-
- First Book of Electricity and Magnetism B, Perren Maycook M I.E.B. Second Edition revised and enlarged With 137 Illustrations Postage 3d 2s 6d.
- Magnetism and Electricity for Beginners. By H E Hadley, B.Sc (Lond.) Adapted to the Elementary Stage of the S. Kensington Syllabus Postage 3d 22 6d 20 6d 20
- Problems and Solutions in Elementary Electricity and Magnetism. By W. Singo and A. Bicker, With 98 Illustration, Cown 800, Postage 3d. 28 0d.
- Biectrical Engineering. By & R Ections Greeful construction I Details of all the ApJ/mace described and circle fly selected Guest parts, enabling the student to test his knowledge from time to time. Illustrict Postage 34. 25 04.
- The Study of Electricity for Beginners, By Nerman H. Schneider, Compring Electrents, of Electricity and Magnetism as applied to Dynamos, Motors, and Wiring to Il Bratches of Electricit Work Ling Cloth Pestage Id. 15 66
- Electrical Circuits and Diagrams. By Norman H. Schneider, Gives 217 Diagrams of Connections. Limp Cicth. Postage 131. 18. 6d

#### Miscellaneous Electrical Subjects.

Electric Traction By J. H. Riter MIEE, MICE With numerous Illustrations A Protical Handbeck on the Appl catton of Electricity as a Locomotive Power, Cickin Sov. Citch Postage 5d 128 6d.

The Alternating Current Circuit and Motor By W Perren Mayoock, M I.E.E. An Introductory and Non Mathematical Book for Engineers and Students Second Edition. Revised. With 160 Illustrations Postage3d 48 6d.

- PERCIVAL MARSHALL & CO'S BOOK LIST
- The Electro-Platers Handbook By G E Bonney A Practical Manual for Amateurs and Students in Electro Metallurgy. With full Index and 61 Illustrations Third Edition. Revised and Enlarged, with an Appendix on Nickel Plating for Cycles Postage 3d 38 Od.
- Electrical Experiments By G B Bonney A Manual of Instructive Amuse ment With 144 Illustrations Second Edition Postage 3d 2s 6d
- Simple Experiments in Static Electricity. A Series of Instructive and Entertaining Experiments for Students and Amateurs Fully Illustrated Postage 1d
- X Rays Simply Explained A Handbook on the Theory and Practice of Radio-graphy Fully Illustrated Postage 1d 6d
- Electric Power What it is and what it can do By A W Marshall, A M I C.B. Postage 1d

# Reference and Pocket Books.

- A Pocket Book of Flectrical Rules and Tables By J Munro C.B., and Prof Jamiesco. With numerous Diagrams Sixteenth Edition, theroughly revised and enlarged For the use of Electricians and Engineers Leather Pocket size Postage 3d
- A Guide to the Electrical Examinations By F H. Taylor A Handbook of Reference for Students and Feachers with an appendix of specimen Questions and Asswers Cloth \* Pestage 3d 15 6d. Ditto ditto Paper Postage 2d 18 04
- Whittaker's Electrical Engineer's Pocket Book. Edited by Kenelm Edgeumbe A.M.I.E.F. With 143 Illustrations Leather. Postage 3d 3s 6d.
- The Practical Engineer Electrical Pocket Book and Diary (Published annually ) Postage 3d Leather gilt edges with Pochet and Elastic Band. Postage 2d is 6d.
- Practical Electrician's Pocket-book and Diary: By H T. Crewe. M.I.M.E. Cloth Postage 2d is Od Leather Postage 2d. is 6d
- The Electrical Engineer's Packot Book By H R Kempe. MILB A MILE Consisting of Modern Kules, Formulas, Tables, and Data Second Lation, thoroughly reviewed with additions. With numerous Illustrations. Royal 32 no chlong Leather Pestige 3d 5s 0d
- The Handy Electrical Dictionary By W. L. Weber M. L. Gives several thousand definitions 224 piges. Pocket size Postage 1d Cloth. 15 0d. Leather Postage 1d. 15. 94

# Telephones, Telegraphy, and Bells.

- Telegraphy By Sir W H Procee K C B. F R S V P In. and Sir J Sive. wright, K C M,G. With 267 Illustrations Fep. 8vo Postage 4d 6s. 0d
- The Practical Telephone Handbook. By Joseph Foce, AIEE Wh Sc. With 473 Illustrations Third Edition revised and enlarged Postage 4d. 6s 0d
- Practical Electric Bell Fitting By F C Allsop. Tenth Edition 186 Illustrations Crown 8vo Postage 3d 38 6d.
- Telephones Their Construction and Fitting By F C. Allsop Sixth Edition 158 Illustrations Grown Svo Postage 4d 38 64
- Flectric Bells and All About Them By S R Bottone. A Practical Book for Practical Men With more than 100 Illustrations. Sixth Edition, revised and enlarged Postage 8d 36 04
- Wireless Telegraphy and Hertzian Waves By S. R Bottone Second Edition revised With 37 Illustrations Postage 3d 3s 0d
- Practical Telephony, By Jas Bell, A I E E and S. Wilson, A Simple and Practical Handbook for the use of Students and Employees Coprously Illus trated Postage 4d \_ 36 6d

#### 26-29. POPPIN'S COURT. FLEET STREET, LONDON, EC 13

- Telegraphists' Guide By Jas Bell AIEE and S Wilson A.MIEB Fifth Edition. 197 Cuts Postage 3d. 2s Od
- How to Instal Electric Bells Annunciators and Alarms By Norman H Schneider Gives some 59 Diagrams Limp Cloth Postage 12d Is 6d
- Telephone Troubles and How to Find Them By W. H Hyde A com plete Handbook for the Telephone Inspector, Postage Id 6d
- Electric Bells and Alarms By F E Powell Gives instructions for fitting same to any part of any ordinary building 51 Illustrations. Seventh edition Postage Id
- Telephones and Microphones rlow to Make and Use Them. Edited by Percival Marshall A 1 Mech B A Practical Handbook on the Making and Using of Sumple Forms of Telephones and Microphones. Fifth Editon. With 29 Illustrations Postage 1d

# WOODWORKING.

- Modern Practical Joinery, By G Eths With 1 000 Illustrations Imperial Svo Postage 5d. 128. 6d.
- Practical Stair Building and Handrailing By W H Wood Plates Crown 4to Postage 5d With 82 10s. 6d
- Handyman s Book of Tools Materials and Processes Employed in Woodworking By Paul N Hasluck. With about 2500 Illustrations and Working Drawings 768 pages Royal Swo Cloth Postage 54 98 00
- The Art and Craft of Cabinet Making. By D Dennin A Practical Handbook to the Construction of Cabinet Furnitare the Use Tools Forma-tion of Joints Hints on Designing and Setting Ott Work Veneering etc. With 219 Illustrations Postage 4d. 5a 0d

Historic Ornament By R Giazier, With 500 Illustrations Postage 4d 5s od Woodcarving C. G Leland With numerous Illustrations. Fourth Edition Fon 4to. Postace 4d

5s Od

Cabinet Making for Amateurs Being Clear Directions How to Construct many Useful Articles such -s Brackets, Sideboerds, Tables, Capboards, etc... Illustrated Cloth gift. Postage 3d

The Cabinet-Maker's Guide to the Entire Construction of Cabinet Work By Richard Bitmead Illustrated with Plans Sections and Work ing Drawings including Veneering Marcuetrie, Buhlwark Mosaid, Inlaying etc. Crown 8vo Cicth Postage 3d. 28 6d

- Carpentry and Joinery Workshop Practice By C. F and A G. Mitchell A Practical Illustrated Manual for the use of Students Cloth gilt. Pos tage 3d 25 6.4
- Circular Work in Carpentry and Joinery. By George Collings A Practi-cal Treatise on Circular Work of Single and Dauble Cirvature With Disgrams Third Edition I Zimo. Cloth? Postack 3d
- Practical Graining and Marbling. By Pa. I N Hashick With numerous Illustrations. 160 pages Crown 8vo Cloth P stage 32. 28 Ad.
- Practical Staircase Joinery By Paul N Hashck With numerous illustr-tions in the text 160 pages Crown 8vc Cioth. Pustage 3d 2a 0d
- French Polishing and Enameling By R. Bitmead. A Practical Work for Instruction Including Numerous Recipes for Making Polishes, Varnishes, Glaze Lacquers etc. Postage 2d. 18, 6d
- Cabinet Worker's Handybook. By Paul N. Hasluck A Practical Manual on the Tools Maternis Applinaces, and Processes Employed in Cobinet. Work With upwards of 109 Illustrations. 144 pages 8vo Clot Postage 3d Is of.

PERCIVAL MARSHALL & CO'S BOOK LIST

Wood-Carving for Amateurs By D Denning Full Instructions for Pro-ducing all the Different Varieties of Carvings Second Edition. In Paper Postare 2d is od

Hints on Chip Carving By E. Rowe. Postage 2d. 18 Od Hints on Wood Carving. By E Rowe Postage 2d .... is od.

A Guide to Poker Work By W D Thompson A Practical Manual for

- Amateurs containing a full description of the necessary Tools and Instructions for their Use Illustrated In Paper. Postage 2d ts nd
- Marquetrie Woodstaining for Amateurs By Eliza Turck A Practical Handbook to Marquetrie Woodstaining and Kindred Arts Profusely Illustrated. In Paper Postace 2d is od
- Mounting and Framing Pictures. Prepared under the direction of Paul N. Hasluck A Practical Manual with 240 Illustrations Cloth. Postage 2d 1s. 0d

Bamboo Work Prepared under the direction of P N Hasluck A Practical Manual with 177 Engravings and Diagrams Cloth Postage 2d Ic Od

Woodworker's Handybook By Paul N Hasluck Embracing Information on the Tools Material Appliances and Processes Employed in Woodworking With 104 Illustrations 144 pages 8vo Cloth Postage 3d. 10 0.1

Wood-Turner s Handybook By Paul N Hashack A Practical Manual for Workers at the Lathe with over 100 Ill carations 144 pages Grown Svo. Cloth Postage Sd 1s. 6d

The Beginner Guido to Carpentry By H. Jarvis. A Practical Hand, bolk for all Reginners in Carge (attry Illustrated with Drawings and Photos showing how Tor's should be used. Criwin Sex Postage 3d 18. Od

- Polishes and Stains for Woods. By David Denning A Complete Guide to Polishing Woodwork with directions f.r Stoning and full Information for making the Stains Polisles etc. In Paper Postage 21 18 0d
- House Decoration Comprising Whitewashing, Paperhanging, Paint-ing etc. By Paul N Hasluck A Practica Manual with 79 Illustrationa. Cloth Postage 2d. 10 0 0
- Soft Woods and Colonial Timbers A practical handbook on the selection and uses of Soft Woods and Colonia: Timbers, Fully illustrated Postage

Hardwoods English and Foreign Describes Hard and Fancy Woods used by curpenters and cab.net malers Illust atel. Postage 1d Sd

Woodwork Jeints. Hew to Make and Where to Use Them. By a Practical Jeiner. Contains full instructions for Maling Mortuse and Tenor Joints. Jeints used in Greular Work, and Devictail and other useful joints. Postace 1d

Veneering Marquetry and Inlay. A Fractical Cuide to these interesting methods of decorating wordwork, Fully illusersted Postage Id. 6d.

The Beginner's Guide to Fretwork Containing full instructions on Tools, Materials, and Methods of Working Six full size original Fretwork Designs are given with this work P:s-are lad

# PHOTOGRAPHIC BOOKS.

# "Photography" Bookshelf Series

Illustrated. Sixth Edition Cloth Postage 2d net 19, 0d No. L

- No 2. Practical Slide Making By G I. Harris, F R P.S. 134 pages Illustrated Cloth Postage 21 nct is Od
- No. 3. The Hand Camera and How to Use it. Illustrated Fifth Edition Cloth Pestage 2d (In the Press) net is 0d No 4. The Platinotype Process By W J Warren Cloth Postage
- net to Od No. 5. Photography in Colours By R Child Bayley F.R.P.S. Illustrated Second Edition Cloth Postage 2d net is 0d.
- No 6 Practical Enlarging. By John A. Hodges F R P S 142 pages Illustrated Sixth Edition Cloth. Postage 2d net is. 0d

#### 26-29. POPPIN'S COURT FLEET STREET, LONDON, E.C. 15

No. 7. Practical Collotype By A W Fithian Illustrated. Cloth. Post

nge 2d No. 8. Photographic Chemicals and How to Make Them. By W Taylor Illustrated Cloth Postage 2d net is 0d


- No. o Short Lessons in Photography. By G Ardaseer 134 pages. 30 Illustrations Cloth Postage 2d net is Od
- No. 10 Practical Retouching By Drinkwater Butt F R P S Illustrated Cloth Postage 2d
- No 11. Elementary Photomicrography. By Walter Bagshaw Fully Illustrated Cloth Postage 2d. net is 0d. No. 12 Practical Landscape Photography. By G T. Harris FRPS
- 124 pages Many Illustrations Cloth Postage 2d net is od
- No. 13 Photography by Rule By J Sterry 130 pages 33 Illustrations Cloth Postage 2d
- No. 14 Practical Orthochromatic Photography. By A Payne, FC S 178 pages 53 illustrations (Joth Postage 2d net is 0d No. 15 Intensification and Reduction By H W Bennett FRPS 128 pages Cloth Postage 2d net is 0d 126 pages Cloth Postage 2d net is 0d
- No. 16 Foning Bromide Prints By R. B Blake Smith 106 pages Cloth
- Postage 2d. net is od No 17 Practical Professional Photography. By C H Hewit Vol L.
- 128 pages Fully Illustrate1 Cloth, Pastage 2d net is od
- No. 18. Practical Protess, nal Photography Vol. II 116 pages Illus-trated Cloth Postage 2d net 18 3d No. 19 Practical Frame Making By Colonel W L Noverre Cloth
- Postage 2d (In the Press) not le od No. 29. The Gum-bichromate Process By J Cruwys Richards Cloth

bound Illustrated Postage 2d (In the Press) net 2s 6d

No. 21 Photo Enamels Translated from the French Illustrated Cloth, Postage 2d (In the Press) net 28. 6d.

#### "The Amateur Photographer" Library.

- No. 1. Platinum Toning By Lyonel Clark Fifth Edition Crown Svo Cloth Posta, e 2d net to Ad
- Cloth Postage 2d net is 0d. No 2 P 0 P By A Horsley Hinton This is a work on similar links to 'Plathotype Printing' by the ame author Postage 31 ... net is 0d. No, 3 Experimental Protography By C J Leafer, FCS Third Edition. Crown 800 Cloth. Postage 2d ... net is 0d
- No
- 4. Short Chapters on Art Photography By H P Robinson Third Edition Crown 8vo Cloth Postage 2d net is Od. Development and Developurs. By George E Brown Crown Svo.
- No. 5 Development Cloth Postage 2d net is, od No 6 The Art of Retouching By J Hubert, Eleventh Edition Crown
- Svo Cloth Postace 21 net is Od No. 7. Elementary Photography. By John A. Hodeva, Fourth Edition.
- Crown 8vo Cloth. P. Stage 24 No 8 Carbon Printing By B J Wall, Sixth Edition Crown 8vo. Coth Postage 2d
- No o Wet Collodion, and How to Work it By C. W. Gamble. Crown Svo.
- Cloth. Postage 2d net is Od No. 10. The Lantern, and How to Use it By Goodwin Norton Second
- Edition Crown 8vo Cloth Postage 2d .... net is. od No. 11 Platinotype Printing By A Horsley Hinton, Second Edition, Crown 8vo Cloth Postage 2d
- No. 12. The Pliotographer s Note Book and Constant Companion By Rev. F C Lambert M A Second Edition, Criwn Svg Cloth,
- Postage 2d net is od No 13 Photo-Aquatint or, The Gum-Bichromate Process Second Edition By Alfred Maskell and Robert Demachy, Grown 8vo, Cioth.
- Postage 2d ... net Is. Od
- No. 14. Animated Photography: The A B C of the Cinemstograph, By Cecil Hepworth Second Faition Crown 8vo, Cloth: Postage 2d. net is nd.



# PERIODICALS.

"The Model Engineer." Contains Pracical Articles, Original Workin, Drawings and High class Illustrations on Model Engine Making Lathe Work, Pattern Making Sheet Metal Working Ersts and Iron Found Dynames and Motors. Electric Bells, Britteries, Accumulators, Telephones Influence Nuchriss, Electric Lighting, Electrical Experiments, Elevery Thursday 2d net. Post free 34.

"The Engineer-in-Charge," A Journal catering especially for Begineers and Works Maragers in Mills Colleries, and Factories of every description Monthly 2d, net Post free 3id. Annual Subscription, post free....

Gives particulars of the hand-tools usually employed for light engineering work, with some hints on how many are used.

AND THEIR USES.

No. 7 of "THE MODEL ENGINEER" SERIES. By PERCIVAL MARSHALL, A.I.MECH E.

See our List.

Invaluable for all Amateurs starting a workshop.

Price 6d, net from all Agents for THE MODEL ENGINEER, or post free rd., from PERCIVAL MARSHALL & CO., 26-20 POPPIN'S COURT, FLEET STREET, LONDON, E.C.