
### Desktop Video-Putting It All Together



Bulk Rate U.S. Postage PAID Permit No. 79 Gordonsville, VA 22942

たかなない。

APH

ROAD

MI

484

Low-Battery Alarm With Automatic Load Disconnect GeoWorks-Windows For The Rest Of Us? Build A \$50 Lab-Grade Function Generator


<section-header></section-header>	UCHINICAE DIALITY OF	A DORRING RUSK PRAS
diak cabe         diak cabe <t< th=""><th>SUPPORT We'll hoo Over 5000 product</th><th>ts to choose from!</th></t<>	SUPPORT We'll hoo Over 5000 product	ts to choose from!
ARD DRIVES           Dur Hard Drive are infailed, partitioned and formatted. Each drive is then tested for integrity, to ensure you all rist class product finduced emprovements with your drive you get disk mangement as well as speed caching software indiced era emprovements with there hous and hourse with a disk mangement as well as speed caching software indiced era emprovements with your drive you get disk mangement as well as speed caching software indiced and formatted. Each drive is then tested for integrity, to ensure you need to start communication in munites?         Our modems are Hays compatible. They come complete with communication software cable and everything you need to start communication in munites?           200 BAUD External         400 BAUD Modem         500<	i disk cache speed-up software. Also comes with many other free software programs such as games, ties and many others' These Hard Cards are easy to install and can go from one machine to another. Install in wites, just plug in and gol (Please specify if you own a Tandy, IBM or IBM compatible.) 8 BIT 16 BiT 16 BiT 16 BiT 22900 DH Lightcard 21 Meg 29 ms 244.00 Lightcard 21 Meg 39 ms 249.00 DH Lightcard 32 Meg 39 ms 245.00 DH Lightcard 42 Meg 28 ms 245.00 DH Lightcard 42 Meg 28 ms 344.00 Lightcard 68 Meg 22 ms 375.00 DH Lightcard 68 Meg 28 ms 349.00 DH Lightcard 68 Meg 28 ms 425.00 DH Lightcard 68 Meg 28 ms 499.00 DH Lightcard 68 M	ment as well as speed-up software programs such as games, utilities and many others! By simply removing the EX/HX adaptor our drives will plug into any normal computer. Order the flash drive today and spend hours with the free software.         DH FlashDrive 21 Meg 39 ms       285 00         DH FlashDrive 21 Meg 39 ms       325 00         DH FlashDrive 42 Meg 28 ms       375 00         DH FlashDrive 68 Meg 28 ms       455 00         DH FlashDrive 68 Meg 28 ms       479 00         DH FlashDrive 68 Meg 28 ms       515 00
A Cambo I: 14, 28 DP, 640 x 480, 256 K, 8 Bit       8 bit       38 6.00         A Combo I: 14, 28 DP, 640 x 480, 256 K, 8 Bit       38 6.00         A Combo II: 14, 28 DP, 640 x 480, 256 K, 8 Bit       38 6.00         A Combo II: 14, 28 DP, 640 x 480, 256 K, 8 Bit       38 6.00         A Combo II: 14, 28 DP, 1024 x 768, 12 K, 16 Bit       425.00         A Combo IV: 14, 28 DP, 1024 x 768, 12 K, 16 Bit       455.00         A Combo IV: 14, 28 DP, 1024 x 768, 12 K, 16 Bit       515.00         CALL FOR PRICES ON:       515.00         Ard Drives all Models       Tandy 10000, 1000A         Trady 1000, 10001, 11/2, 7L/3       14 Meg Internal Drive Kit         Stern Diptal all Models       80287-10         Board Wind S       80287-20         Board Wind S       80387:20	ARD DRIVES           Dur Hard Drive are initialized, partilioned and formatted. Each drive is then tested for integrity, to ensure you a first class product! Included with your drive you get disk mangement as well as speed caching software. o included are many other programs such as games, utilities and many others. You will have hours and hours enjoyment from your new hard drive and free software!           del         Size         Brand         Speed         Dimension         Barc         XT/Tandy         16 Bit Kit           Size Brand         Speed         Dimension         Barc         XT/Tandy         16 Bit Kit           25         21 M         Seagate         28 ms         3.5         224         234           25         21 M         Seagate         28 ms         3.5         224.         255.         255           30         32 M         Seagate         20 ms         3.5         124.         255.         234.           251         42 M         Seagate         28 ms         3.5         226.         234.         257.           380         32 M         Seagate         28 ms         3.5         163.         225.         234.           2040         42 M         Seagate         28 ms         3.5         34.         N/A         355. <tr< td=""><td>you need to start communicating in minutes! 2400 BAUD Internal with Mod 5</td></tr<>	you need to start communicating in minutes! 2400 BAUD Internal with Mod 5
dime Drives all Models         DH 41L Upgrade 1L or TU/2, TL/3 from 640 to 768         29.00           corpolis Drives all Models         DH 41L Upgrade 1L or TU/2, TL/3 from 640 to 768         39.00           Drives all Models         DH 5NI Upgrade 3000 NL to 640         39.00           Drives all Models         DH 6RL Upgrade 1andy 1000 RL, 1000RLX from 640 to 1 Meg.         42.95           Call our factory-trained sales and tech support staff.         OH 100 Upgrade 1andy 1000 or 1000 RL 1000RLX from 128 to 640         .235.00           and let them bela would the best drive for work computer system         D 120 Upgrade 1andy 1000 tor 1000 A from 128 to 640         .200.00	Ready for VGA Upgrade the Data Hul Way! Fuil replacement warranty!           A Combo I: 14, 28 DP, 640, x480, 512 K, 16 Bit         386.00           A Combo II: 14, 28 DP, 640, x480, 512 K, 16 Bit         425.00           A Combo II: 14, 28 DP, 1024 x 768, 512 K, 16 Bit         455.00           A Combo VI: 14, 28 DP, 1024 x 768, 1024 K, 16 Bit         515.00           Combo VI: 14, 28 DP, 1024 x 768, 1024 K, 16 Bit         515.00           Combo VI: 14, 28 DP, 1024 x 768, 1024 K, 16 Bit         515.00           CADUB VI: 14, 28 DP, 1024 x 768, 1024 K, 16 Bit         515.00           CADUB VI: 14, 28 DP, 1024 x 768, 1024 K, 16 Bit         515.00           CADUB VI: 14, 28 DP, 1024 x 768, 1024 K, 16 Bit         515.00           CALL FOR PRICES ON:         Tandy 1000, 1000A           Tandy 1000X, SL, SL/2         Tandy 1000X, SL, SL/2           Stern Dipital all Models         803875X-20           wator Drives all Models         803877-20           Inter Drives all Models         80387-20           Storpolis Drives all Models         80387-20           Stories all Models         80387-20           Storpolis Drives all Models         80387-20	Board with 2 MEG         285.00           Board with 2 MEG         285.00           Board with 4 MEG         540.00           FLOPPY DRIVE FOR TANDYS         540.00           These floppy drives will install in minutes. Add a high density drive to your computer for less moneyl High density include controller card, cables, everything you need to make you start running!           360K Internal Drive Kit         67.00           720K Internal Drive Kit         70.00           1.2 Meg Internal Drive Kit         139.00           1.4 Meg Internal Drive Kit         145.00           SYSTEM MEMORY UPGRADES         145.00           D SX Upgrade Tandy EX or HX to 640         174.00           DH 10X Upgrade Tandy EX or HX to 640         45.00           DH 20L Upgrade SL or 5L/2 from 384 to 640         45.00           DH 3X Upgrade Tandy UD Thr 640 to 768         29.00           DH 4TL Upgrade Tandy 1000 RL 1000RLX from 640 to 768         29.00           DH 6RL Upgrade Tandy 1000 RL 1000RLX from 640 to 1 Meg         42.95           OH 100 Upgrade Tandy 1000 RL 1000RLX from 640 to 1 Meg         42.95           OH 100 Upgrade Tandy 1000 RL 1000RLX from 640 to 1 Meg         42.95           DH 6RL Upgrade Tandy 1000 RL 1000RLX from 640 to 1 Meg         23.50           DH 100 Upgrade Tandy 1000 RL 1000RLX from 640 to 1 Meg         23.500

1

CIRCLE NO. 88 ON FREE INFORMATION CARD



Volume 2, No. 4 April 1992



### 44

### UPGRADING & ENHANCING

### **36** A Tower of an Enclosure, Part 3 By Nick Goss

Expand your PC's bus by six expansion slots with a Bus-Expander system.

### 52 Fast-Acting Modem Protection By T.L. Petrizzellis Low-cost devices you build protect a computer modem, fax machine, telephone answering machine and computer from electrical damage.

### **APPLICATIONS**

### **16** Networking Basics

By Jan Axelson How circuits talk to each other to keep computers in communication.

- 20 Computer Speed By Hardin Brothers How a host of factors influence a computer's operating speed.
- 26 PC Desktop Video, Part 2 By Tom Benford Titling, animation and video putting it all together.
- 44 Experimenting With Motorola's 68HC11 True Single-Chip Microcomputer, Part 4 By Tom Fox Supplying battery power to

MAG-11, programming the EEPROM and experimenting with the 68HC11 in Special Bootstrap/Modified single-chip mode.

### 55 \$50 Lab-Grade Function Generator

By Crady VonPawlak Full-featured 1-Hz to 250-kHz project adds CMOS/TTL compatibility and FM sweep input, near-zero distortion, etc., to sine/ triangle/square-wave outputs.

61 Low-Battery Alarm With Automatic Load Disconnect By Jan Axelson Flashes a LED or sounds an alert when battery voltage drops below a predetermined level and, optionally, disconnects the load if no action is taken.

### REVIEWS

- 72 WInvoice: Time & Billing for Windows By SF Sparrow
- 77 GeoWorks—Windows for the Rest of Us? By Ted Needleman
- 87 Computer Games BushBuck Charms, Viking Ships & Dodo Eggs... and more.

### COLUMNS

74 Joseph Desposito A Sleep-Mode Op Amp; New A/D Board for the PC/AT; Fast SCSI

Controller; 14-ns RAM Cache; and Programmable Multiplexer.

80 The World On-Line Portable Wireless Modems, 14,400-bps Modem, Previewing Software for Free, Going to School on AOL and Virtual Reality.

### **DEPARTMENTS**

- 4 Editorial By Art Salsberg Built-In Upgrading.
- 6 The Winner Is... Announcing the winner of the drawing for the notebook computer from among respondents to the *ComputerCraft* Reader Poll.
- 8 What's Happening! Latest PC News.
- 10 What's New! By Peter R. O'Dell A roundup of new computer and electronic products.
- 89 Advertisers Index

**ON THE COVER:** Getting down to cases, a *ComputerCraft* reader readies a circuit of his own design for use with the Motorola 68HC11EUB single-board computer. The circuit being breadboarded might be an interface, data-acquisition unit or any of a host of other devices.

Cover Photo: by Larry Mulvehill

### Editorial

### **Built-In Upgrading**

The PC is a remarkable machine: it's easily upgradable. You can add more memory and greater disk storage, speed up operations with faster RAM and cache controllers, stretch functions by inserting new cards into bus slots, transfer the works into a new body, such as a tower enclosure, and so on.

What's more, doing the foregoing is within the grasp of anyone who has some basic computer hardware and software experience and a do-it-yourself bent. The most desirable attribute anyone can have when making such modifications is a bit of self-confidence. If one keeps in mind that just by exercising common-sense care (remove the plug from the ac power outlet, never exert extreme force when inserting one device into another, make sure IC pins are all lined up with socket holes before pressing it in, handling the card with the precautions required for static-sensitive devices, etc.) you can't harm a new device or the machine.

This doesn't imply that you won't encounter any problems. You well might due to poor installation instructions and other hurdles. But this only means that you might face some frustrating problem-solving challenges, not damage of any kind. Moreover, with success likely to follow your efforts, you become an expert of sorts in a growing number of computer-enhancement areas.

Even though computer prices are relatively cheap compared to what they were a year or two ago, it all still amounts to a fairly hefty expenditure. A host of manufacturers recognized this and, to overcome buying reluctance due to anticipated obsolescence, introduced machines with upgrading conveniences built into them.

For example, Intel is touting i486SX motherboards that have an accompanying processor socket that will enable the owner to plug in another IC to convert the system to an i486DX equivalent. This simple modification will, according to Intel, double the machine's performance while adding math coprocessor capabilities, should one want this capability at a later date.

In cooperation with Intel, Acer introduced PCs whose upgrade implementation is easy. Essentially, it combines the design of three system boards into one motherboard in order to accommodate i486 CPUs that run at different speeds (20, 25 and 33 MHz). Advanced Logic Research (ALR) is another company that endorsed "Just Upgrade the CPU" design, providing buyers with a lower-cost 486SX entry point. In essence, these companies are bypassing the need to substitute a whole new system board with just a single chip-replacement upgrade path. Upgrading a PC is almost a way of life for most of us due to fast-moving advances made in this industry. You just don't throw away a whole computer every time a new improvement is introduced. The ante is often less and very fruitful if you make a modification and continue doing so whenever you wish.

At some point, you'll want to make the big change, of course. You may be able to get by with an old XT or AT, but you won't savor the computing power provided by many of today's software packages. Both hardware and software makers point to the '386 and i486 machines when creating new models. Nevertheless, I expect that many XT/AT users who have limited nongraphics-oriented computing needs will continue along with their systems largely as they are.

The coming year or two will be volatile ones, however, as designers and marketers shift and turn. For example, the sub-notebook-size portable computer is expected to come into its own, one that falls in size and weight between the  $8\frac{1}{2}$  "  $\times$  11" notebook computer and palmtop devices such as Hewlett Packard's HP95LX. SCSI ("scuzzy") I/Os will blossom as CD-ROM drive ownership grows and multi-media systems are adopted.

But it will probably be in the area of operating systems where revolutionary changes will be observed. Rickety old DOS can't go on forever. Or can it for many people? After all, there are about 70-million DOS computers being used in the world today.

Switching to a new operating system, whether it's OS/2, *Windows NT* or whatever, shouldn't be a particular calamity in itself. But the need for new applications software and computers with faster operating speed, quick-working multi-tasking and much more memory will, indeed, be a hardship for many people and businesses.

At some point, however, DOS has to be put out to pasture so that others can march forward with greater computer productivity and higher-quality work. It means that there will be at least two distinct groups of PC users for as long a time as it takes for DOS users to switch to a more-advanced computing system.

For some, this may not ever occur, leaving a great number of computer DOS orphans to serve. As they diminish over the years, they'll join users of CP/M-type eight-bit machines still being feverishly used today by a stalwart minority.

art Salaberg

### EDITORIAL STAFF

Art Salsberg Editor-in-Chief

Alexander W. Burawa Managing Editor

Dorothy Kehrwieder Production Manager

Emily Kreutz Production

Elizabeth Ryan Art Director

Barbara Terzo Assistant Art Director

Susan Reale Artist Pat Le Blanc

Florence V. Martin Linda Romanello Phototypographers

Hal Keith Illustrator

Bruce Morgan Photographer

Bud Aaron, Jan Axelson, Tom Benford, Hardin Brothers, TJ Byers, Joe Desposito, Nick Goss, Martin Meyer, Ted Needleman, Peter R. O'Dell, SF Sparrow, Stan Veit Contributing Editors

### **BUSINESS STAFF**

Richard A. Ross Publisher Art Salsberg Associate Publisher

Dorothy Kehrwieder General Manager

> Frank V. Fuzia Controller

Catherine Ross Circulation Director

Melissa Kehrwieder Carol Minervini Data Processing

Denise Pyne

Customer Service

### ADVERTISING SALES

Eric Teitelbaum Margaret Milanese

(516) 681-2922 FAX: (516) 681-2926

> Karen Nauth Sales Assistant

Offices: 76 North Broadway, Hicksville, NY 11801. Tetephone: (516) 681-2922. FAX (516) 681-2926. Computer-Craft (ISSN 1055-5072) is published monthly by CQ Communications, Inc. Subscription prices (payable in US Dollars only): Domestic—one year \$18,97, two years \$36.00, three years \$53.00; Canada/Mexico—one year \$21.00, two years \$40.00, three years \$59.00; Foreign one year \$23.00, two years \$44.00, three years \$55.00. Foreign Air Mail—one year \$76.00, two years \$150.00, three years \$224.00.

U.S. Government Agencies: Subscriptions to Computer-Craft are available to agencies of the United States government, including military services, only on a cash with order basis. Requests for quotations, bids, contracts, etc. will be refused and will not be returned or processed.

Entire contents copyright 1992 by CQ Communications, Inc. ComputerCraft or CQ Communications Inc. assumes no responsibility for unsolicited manuscripts. Allow six weeks for delivery of first issue and for change of address. Printed in the United States of America.

Postmaster: Please send change of address notice to ComputerCraft, 76 North Broadway, Hicksville, NY 11801.



Chatsworth, CA 91311

### SINCE 1983 — YOUR I.C. SOURCE — AND MUCH MORE!! **NO SHIPPING CHARGES ON PRE-PAID ORDERS!\* NO CREDIT CARD SURCHARGE!** SCHOOL P.O.'s WELCOME!

TOBOARD DESIGN STAT

Variable DC output

Frequency generator

ranges

protected

5 - to -15 VDC @ 0.5 amp, ripple 5 mV

frequency range: 0.1 Hz to 100 KHz in 6

output voltage: 0 to ± 10V (20 Vp-p) output impedance: 600 (except TTL)

output current: 10mA max., short circuit

output waveforms: sine, square, triange, TTL

sine wave: distortion 3% (10 Hz to 100

SER WAVE OUTPUT OPER OPER STOCK # MEG 1-24 25-99 100+ LENGTH POWER CUBB VOLT LS9220 TOSHIBA 660nm 2.5 V 129.99 123.49 111.14 3 mW 85 mA LS9200 TOSHIBA 670nm 3 mW 85 mA 2.3 V 49.99 47.99 43.19 LS9201 TOSHIBA 670nm 5 mW 80 mA 24 V 59 99 56.99 51.29 LS9211 TOSHIBA 670nm 50 mA 2.3 V 69.99 5 mW 66.49 59.84 LS9215 TOSHIBA 670nm 10 mW 45 mA 2.4 V 109.99 104.49 94.04 1.\$3200 NEC 670nm 3 mW 85 mA 2.2 V 59.99 56.99 51.29 LS022 SHARF 780nm 5 mW 65 mA 1.75 V 19.99 18.99 17.09 SB1053 PHILLIPS 820nm 10 mW 90 mA 2.2 V 10.99 10.44 9.40

### WAO II PROGRAMMABLE ROBOTIC KIT



### And the Winner is .... Kenneth R. Stoddard

Many thanks to the thousands of you who responded to the ComputerCraft Reader Poll in our December 1991 issue. Your responses were enlightening and will be helpful in helping us direct our editorial content to your needs.

Along with the poll was a drawing among respondents for a free Tandy 2810 HD Notebook Computer. The winner was Ken Stoddard of Lathrup Village, MI. Congratulations, Ken!

Ken used a PC at work, where he worked as an Employee Benefits Consultant, and at home, where he owns an IBM 55SX computer, IBM VGA color monitor and an NEC P5 24-pin dot-matrix printer. Like most ComputerCraft readers, he has upgraded his system unit by himself. Ken

## Electronics Workbench® The electronics lab in a computer m

### Powerful software to build and simulate analog and digital circuits.

Building and testing is fast and easy with Electronics Workbench. Just clickand-drag with a mouse to add parts, run wires, adjust instruments. The traces on the simulated instruments are the same as you'd get on real equipment.

Electronics Workbench really is an electronics lab in a computer. It's ideal for learning about electronics, experimenting, and prototyping circuits.

### "Electronics Workbench is pretty amazing." - Jerry Pournelle, Ph.D., InfoWorld.

DOS Professional Version - \$299\*. Macintosh Version - \$199\*.

#### Includes:


- Analog Module: With passive and active components including transistors, diodes, and op-amps; a function generator, an oscilloscope, a multimeter, and a Bode plotter.
- Digital Module: With gates, flip-flops, adders, a word generator, and a logic analyzer.

### (416) 361-0333

Interactive Image Technologies Ltd. 908 Niagara Falls Boulevard North Tonawanda NY 14120-2060. Fax (416) 368-5799

INTERACTIVE

Electronics Workbench Professional Version runs on any IBM AT or PS/2 or true compatible with 640 kB RAM; Microsoft-compatible mouse; EGA/VGA graphics; hard disk; MSDOS 3.0 or later. Macintosh Version (monochrome only) runs on Macintosh Plus or greater. All trademarks are the property of their respective owners. "Prices are in US dollars. Offer valid in the USA and Canada only.



#### **CIRCLE NO. 65 ON FREE INFORMATION CARD** 6 / COMPUTERCRAFT / April 1992



generally works with word-processing, graphics, spreadsheet and Microsoft Windows software, and buys PC hardware and software mostly through mail-order sources, expecting to spend \$2,000 to \$4,999 this year for computer-related equipment and software.

Ken responded to notice of his winning the Tandy computer with a letter, part of which follows:

"Thank you again for the computer. It arrived on January 2... and I got immediately into the serious business of playing with it. It's already pretty well set up the way I want it.

"You couldn't have picked a more appropriate day to announce my prize. That date, December 20, 1991, was the date of my early retirement. When we spoke, I had been retired for about 45 minutes! In addition, it could not have been more appropriate as a companion to my wife's retirement present to me of Davis Instruments' Weather Monitor II hardware and Weatherlink software. I'll be moving to Oregon, where I intend to develop a weather database so that I can analyze data relative to planning a vineyard for the production of personal wines.

"I also plan to take up flying, using software for flight planning, weather briefings and interfacing with a variety of navigational instruments, moving-map displays, etc. The 2810 will be an invaluable tool in these endeavors.

"Again, thank you for the prize ... we are excited!"

Good luck, Ken, with your early retirement in your new home and with your new portable computer. Next month, we'll give readers the results of our Reader Poll as a sort of profile of a ComputerCraft reader. Thanks again to all of you who participated in this study.

The Editors

TO ORDER (800) 531-5369 FAX (512) 637-3264 TO ORDER (800) 531-5369 FAX (512) 637-3264 TO ORDER (800) 531-5369 FAX (512) 637-3264 TO ORDER (800) 531-5369 FAX (512) 637-3264



531-5369 FAX (512) 637-3264 TO ORDER (800) 531-5369 FAX (512) 637-3264 TO ORDER (800) 531 1-5369 FAX (512) 637-3264 TO ORDER (800) 531 -5369 FAX (512)637 3264

CIRCLE NO. 103 ON FREE INFORMATION CARD

TO ORDER (800 531 -5369

ORDER (800) 531-5369

FAX (512) 637-3264

TO ORDER (800) 531-5369

FAX

(512)

637-3264

TO ORDER (800) 531-5369

FAX

(512)

637-3264

TO ORDER (800) 531-5369

FAX (512) 637-3264

TO ORDER

008)

531

-5369

### What's Happening!

New Multimedia PC Specs. The base specification for the multimedia PC has been modified by the MPC Marketing Council. Now the minimum configuration is a personal computer with a 386SX microprocessor instead of the original baseline of a 10-MHz 802826 microprocessor. Moreover, the market for upgrade kits for multimedia purposes is expected to be 386DX- and i486-based.

Good Viruses. Not all viruses are bad, it seems. It has been reported that the U.S. introduced a virus to Iraq's controlcommand defense system--with success--before its initial attack in the Gulf war.

The National Computer Security Association (NCSA) has upgraded its security-oriented bulletin board, expanding it to four dedicated lines. It features information on all known viruses and a "Virus Door" provides on-line lookup of all common viruses, nature of their effect, and information on what products detect and remove it. The BBS at 202-364-1304 operates seven days a week, 14 hours per day. Non-members can try it out. Set communication software to N-8-1, dial at 300 to 9600 baud, and use any password you like when signing on.

A Million Synonyms. Mycrolytics updated its "Word Finder" electronic thesaurus with "Word Finder Plus." It features onemillion synonyms that requires less than 200K of disk space. The mew software, which was available initially for Apple Macintosh computers, employs a powerful linguistic technology called "autoinflection." This produces the correct grammatical form of a word for more concise synonym choices. "List" is only \$69.95. Current Word Finder users can upgrade for \$19.965 by calling Microlytics at 1-800-828-6293 or 716-248-9150.

Memory-Card Technology. The PCMCIA's (Personal Computer Memory Card International Association) new Release 2.0 specification for the 68-pin memory card is expected to increased its use for portable equipment. Fujitsu Microelectronics' IC Division introduced enhanced memory card design kits that comply with it. They contain a Fujitsu 68-pin memory card connector and a "ThinCard Drive" from Databook Inc, complete with software, cables and manuals. The drive interfaces to a PC/XT/AT computer. Product information: 1-800-642-7616.

Computer Speech Doings. Fax-to-voice and E-Mail-to-voice software was announced by Malibu Software Group, Malibu, CA. The new software is said to quickly and accurately convert faxes or E-mail into spoken words. It can be used as a stand-alone system or integrated into most other voice mail systems. Tel. 213-456-8940.

Statistics-keeping during professional sporting events may get a real efficiency boost soon. A prototype conversational voice interface for capturing, retrieving and displaying statistics at sporting events has been developed by Applications Express. It's used in conjunction with voice recognition equipment supplied by Verbex Voice Systems and STATMAN II from Play By Play Corp. Coupled with them, the system is reported to free the announcer to follow each play while simultaneously capturing statistics in a natural conversational manner.



Special-Order Hotline

The Radio Shack near you stocks over

1000 electronic components-and

another 15,000 items are available

fast from our special-order ware-

house. Make Radio Shack your com-

plete source for linear and digital ICs, transistors and diodes, vacuum tubes,

crystals, phono cartridges and styli,

selected computer accessories and

There's no postage to pay because we send your order to the Radio Shack near you. Delivery time for most items is about a week. Come in for details.

**Build a Soldering Iron!** 

SAMS® service manuals.



Digital Logic Probe. The fast way to pinpoint problems and check operation in all types of digital circuits LEDs and "beep" tones reveal logic states instantly. Includes owner's booklet with valuable troubleshooting tips. #22-303 . 16.94



"Business" Power Cords. UL listed AC cords with CEEtype connector for many PCs, printers, monitors, copiers and test instruments

(1) 6-Ft. Cord With Right-Angle Connector. #278-1260. 5.99

(2) 12-Ft. CEE Cord. #278-1261, 5.99 (3) 6-Ft. CEE

Extension. #278-1259, 4.99





#273-071, 8.99




LCD Multimeter With Automatic Shutoff. We've never seen such quality and features in a UL-listed 

Since 1921 Radio Shack has been the place to obtain up-to-date electronic parts as well as quality tools, test equipment and accessories at low prices. Nearly 7000 locations are ready to serve you—NOBODY COMPARES

Prices apply at participating Radio Shack stores and dealers. Radio Shack is a division of Tandy Corporation





Lighted AC Switch. Panelmountable switch with heavy-duty 10-amp rating. 125VAC use only. Push-on, push-off action Button lights when on. #275-671, 3.99

6-Ft. BNC-to-**BNC Patch** Cable. For test RF hookups #278-964, 5.99

-Ft. Cellular Phone Exten-sion. Male TNC to Female TNC #278-976, 4.99

Building Power Supplies. Covers linear and switching types and includes full construction plans for five supplies. 96 pages. #276-5025, 4.95









Dual-color LEDs monitor seven data/ control lines to help you spot problems quickly. D-sub 25. Connects inline. #276-1401, 14.95

(1) Binding Posts to BNC Male. #274-715 .... 8.95 (2) Binding Post to Banana Plugs. Stackable #274-716, Set 4.95 (3) Dual Banana Plug. Accepts test probes, wire and/or banana plugs. #274-717 .... 2.99



3" Brushless 12VDC Fan. Best choice for cooling mobile equipment or hum-sensitive circuits. Low noise level-34dB max. 27 CFM airflow. #273-243, **14.95** 

High-Speed 12VDC Motor.

Up to 15,200

RPM at no load. Ideal for sci-

ence projects

and robotics. About 2" long

(including shaft)

Halogen Bulbs. Long-

life, brighter-


than-original

replacements

for your flash-







Set of 100 Ceramic Disc Capacitors Popular values at a bargain price. Ratings WVDC. (Big se-lection of resistor assortments in stock, too!) #272-801, Set 1.98



Deluxe Breadboard. Our best! Molded  $21/4 \times 61/2''$  board is mounted on a 7 × 4'' steel base with stabilizing rubber feet. Features 640 plug-in points and three binding posts. #276-169 . 19.95 Breadboard Jumper Wire Kit. In-cludes 140 insulated, preformed, stripped wires in a snap-shut plastic box. #276-173 ..... Set 4.9 ... Set 4.95



**CIRCLE NO. 82 ON FREE INFORMATION CARD** 



(5) Mini Forceps. Insulated grips. #64-1910 ..... 1.79 (6) Lead-Free Solder. 96% tin, 4% silver formula. 0.032" size. 0.25 oz. #64-025 ..... 1.99 (7) High-Tech Solder. 63/37%. 0.050" size. 1.5 oz. #64-015 ... 2.49 (8) One-Lb. Electronic Solder. 0.062" size. #64-008 ..... 8.99

Battery Guide. Save money by choosing the right battery! Data on our top-rated ENERCELL® brand plus a wealth of basic battery info. 230+ pages. #62-1304, **5.95** 



RS-232 Tester.

### What's New! By Peter R. O'Dell

PC/AT Breadboard

TMC's Pcat Interface Designer

and Breadboard System plugs

directly into an AT bus slot and

can be used in building and

testing interfaces. It allows ac-

cess to all AT bus signals using

solderless tie-point blocks. Cir-

cuit assembly is on two high-

quality solderless breadboard

sockets. The isolation card buf-

fers and isolates all internal

IBM/AT bus signals. Address

and data bus drivers isolate the

bus from external circuits and

eliminate the need to construct

bidirectional drivers common

in I/O and memory circuits.

Surge Suppresser

The Power Pause surge sup-

presser from Tripp Lite pro-

tects electronic equipment

from unstable or extreme over-

voltage conditions that often occur when power is restored

after a blackout, as well as

against typical voltage spikes.

After-blackout protection is

accomplished with a time-delay

relay that waits five seconds be-

fore reconnecting to the ac line.

tractive, compact unit that fea-

tures direct plug-in connection.

Two protected outlets are rated

at 15 amperes. A green light in-

dicates that the unit is function-

ing properly. The Power Pause

The Power Pause is an at-

**Time-Delav** 

### **Epson SX Computers**

Epson has two new machines in its desktop line, the Equity 486SX/25 Plus and 386SX/16 Plus. The 486SX/25 Plus, based on the Intel 25-MHz 486SX CPU, has 4M of RAM (expandable via SIMMS to 16M), 32K cache, 200M hard drive, 1.4M floppy drive, AT-




style keyboard and integrated VGA/serial/parallel/mouse ports. Two external and one internal drive bays are open and available for expansion. The unit comes with MS-DOS 5.0, *Windows* 3.0, Asymetrix *Daybook* and Bitstream *Facelift* installed. \$4,959.

The 386SX/16 Plus is based on the 16-MHz 386SX CPU and features 2M of RAM (expandable via SIMMS to 24M), 1.4M and 1.2M floppies, 40M hard drive and the same bundled software. \$2,050. Epson America, Inc., 20770 Madrona Ave., Torrance, CA 90509-2842; tel.: 1-800-922-8911.

CIRCLE NO. 10 ON FREE CARD

### Data Acquisition


Prairie Digital's model 30 is a low-cost data-acquisition and control system for XTs and ATs (ISA/EISA bus). It features 24 lines of programmable TTL-level I/O, eight-bit A/D converter, eight-channel analog multiplexer for A/D signals, 12-bit CMOS counter, 30volt, 0.5-ampere open-collector driver option, easy interface to all popular programming languages, quarter-slot plug-in card and sample program on 5¼" floppy. Digital I/O is in 24 bits, arranged as three eight-bit groups (Ports A, B and C); Port C can be divided into two four-bit ports. The board is



configured using a fourth control port.

A/D has eight-bit resolution and a 0-to-5-volt scale. Input range for the counter is 0 to 5 volts in a user-configurable CMOS circuit. \$79. Prairie Digital, Inc., 846 17th St., Prairie du Sac, WI 53578; tel./fax: 608-643-8599.

CIRCLE NO. 14 ON FREE CARD



This approach doesn't restrict you to a particular port or memory address and permits master/slave co-processing. \$495. TMC, Inc., 20 South Lakeshore Dr., Brookfield, CT 06804; tel.: 203-775-5167; fax, 203-740-9313.

CIRCLE NO. 11 ON FREE CARD

is UL 1449 listed. \$70. Tripp Lite, 500 N. Orleans, Chicago, IL 60610-4188; tel.: 312-329-1777; Fax: 312-644-6505. CIRCLE NO. 12 ON FREE CARD

### Math Program Update

CompMath version 2.0 from BSOFT Software is a menudriven mathematics program with enhanced graphics. It is useful in the areas of General, Complex, Matrix, Engineering and Statistical Mathematics. Requirements are an IBM/ compatible computer, 256K RAM, DOS 2.1 or later and a graphics adapter. \$39. BSOFT Software, Inc., 444 Cotton Rd., Columbus, OH 43207-3902; tel.: 614-491-0832; Fax: 614-497-9971.

CIRCLE NO. 15 ON FREE CARD


### PC Power Module

The Intelligent Power Module from Server Technology Inc. is a computer-activated power module that sits in-line between an ac wall outlet and a power strip. It accepts signals from a PC serial or parallel port to turn on/off ac power. This product was designed for use with computers assigned to unattended operation. By placing the power OFF command at the end of a batch file used to run unattended operations, a PC can shut itself down when the job ends. A PC with multiple ports can be used to control other equipment, turning it off and on via additional modules. The Intelligent Power Module ships with software and a signal cable. \$59. Server Technology Inc., 2332-B Walsh Ave., Santa Clara, CA 95051; tel.: 800-835-1515.

**CIRCLE NO. 13 ON FREE CARD** 


### Multi I/O Box

Connect Tech has a new I/O connector-box option for its product line of intelligent and standard multi-port serial communications adapters. These adapters currently ship with four- or eight-port cable harness assemblies. The I/O connector box option provides such features as an external eight-port connector box, both



RJ-45 and female DB-25 connectors, connector configured as DCE, connection to the Intellicon and DFlex communications adapters and a variety of installation configurations. *Connect Tech Inc.*, 18-340 Woodlawn Rd. W., Guelph, Ontario, Canada N1H 7K6; tel.: 519-836-1291; fax: 519-836-4878.

CIRCLE NO. 16 ON FREE CARD



### Low-Cost MIDI

PAIA Electronics' PCM68 MIDI interface is designed in the currently popular UART style and is supported by major publishers of MIDI software. A second MIDI port expansion option is available for



\$15. The PCM68 is available in both kit and factory-assembled and tested versions. A starter set that consists of the PCM68 and Voyetra's Sequencer Plus, is also available. \$50, kit; \$60, assembled, \$99, set. PAIA Electronics, 3200 Teakwood Lane, Edmond, OK 73013; tel.: 405-340-6300.

CIRCLE NO. 25 ON FREE CARD

### The Stephen Cobb Complete Book Of PC And LAN Security

#### **By Stephen Cobb**


(Windcrest/McGraw-Hill. Soft cover. 556 pages. \$24.95.)

Most of us are absurdly complacent about computer security. "It's something that only networks must be concerned with." Or, "I've never had a virus. The virus scare is just groundless panic." And so on. According to Cobb, such a view is shortsighted. He poses a rhetorical question in Chapter 1, "Next Monday morning you arrive at work to find the office in chaos. There has been a break-in. Your PC has been stolen. What is your first thought?" Do you have records of the serial numbers? When did you last make backups? Any mention of credit card numbers? Passwords to on-line services? These questions just scratch the surface of the problem, but Cobb covers computer security in detail.

Cobb sees computer security ranging from the obvious (theft and viruses, for instance) to issues far less obvious with subtle implications. For instance, he devotes an entire chapter to software piracy and the threats it poses to a company. Other topics covered include securing hardware, keeping computers running, controlling computer access, controlling file access, file backup, network security and hacking.

The approach to preventative measures in this book is as practical and unclouded as the author's vision of the problems. He suggests that you should familiarize yourself with the basics of DOS and use the tools available for enhanced security before investing in expensive alternatives. Some of the security measures he suggests actually require no hardware. For example, would you permit a temporary employee from an agency to update your payroll files? If a floppy is damaged, what's the best method for disposing of it? At the other end of the spectrum is a discussion of network security software and hardware.

The author covers both IBM-type and Macintosh computers. Although the dustcover blurb and title make the book sound like an esoteric treatise useful to only LAN and MIS managers, this volume will be of value to anyone who makes significant use of a personal computer. Cobb's writing style is clear and upbeat. In spite of the daunting title, it's a fun book to read.



What's New!

### Software For Home

Radio Shack has upped the ante in the "home computer" wars with Automatic House Companion software and Plug'n Power computer interface. The software lets users set and control electric lights, appliances and security devices throughout the home. They can establish daily routines or schedule events for a specific time of day or day of the week. With Plug'n Power remote modules, Automatic House can handle up to 128 separate time events and control as many as 256 modules. The program runs on any Tandy or IBM-compatible computer and requires MS-DOS and Desk-Mate 3.0 or later.

Automatic House has three primary functions: Floor Plan, Routine Maker and Schedule Manager, that you use to graphically program the Plug 'n Power Interface through the computer serial port. After programming the interface, you can detach it from the computer and then use it for other purposes or turn it off. \$70. *Radio Shack, 700 One Tandy Center, Fort Worth, TX 76102.* 

CIRCLE NO. 17 ON FREE CARD

On the health front, DINE Windows 3.0 and MacDINE II from DINE Systems are designed to help you create complete nutrition and fitness programs that meet individual needs. Using food records, activity records, diet analysis and a proprietary scoring system, you can improve nutrition and lose weight by becoming aware of and altering your eating patterns. These programs feature expandable food databases with 5,656 brand-name, generic, ethnic, processed and fast foods. Each food record contains the number of calories and amount of major nutrients in it. DINE Systems, Inc., 586 North French Rd., Amherst, NY 14228; tel.: 716-688-2492; fax: 716-688-2505.

CIRCLE NO. 18 ON FREE CARD

### Multi-Media Workstation

The Imagination Station from CCSI is a 12-slot, 33/50-MHz multi-media workstation. This new product line provides both NTSC and S-video input and output ports to facilitate overlaying or mixing of external video sources with text, graphics and animation created within the workstation. Additional NTSC and S-video ports provide for digitizing video images from such external sources as camcorders, laser disks, video tapes and video still cameras. Ports are available for recording and playback of digital stereo audio for voice-overs, music and sound effects.

The workstation features 4M of RAM (expandable to

### Semiconductors On A Disk

SGS-Thomson's new semiconductor selection guide comes on an IBM/compatible disk and works with virtually any computer configuration. It provides users with complete

64M), a 200M hard drive, 1.2M and 1.44M floppy drives, CD-ROM drive and library, NMB 101-key keyboard, DOS 5.0, mouse and 400-watt power supply housed in a heavy-duty tower case. The Imagination Station arrives with a full complement of multi-media software already installed. *Computer & Control Solutions Inc.*, 1510 Stone Ridge Dr., Stone Mountain, GA 80083; tel.: 404-492-1131; fax: 404-493-7033. CIRCLE NO. 19 ON FREE CARD

selection information and pricing for SGS-Thomson's semiconductors. It is designed specifically for engineers who make design-in choices. CyberSoft, Inc., 1820 W. Drake Dr., Suite 108, Tempe, AZ 85283-4312; tel.: 602-491-0022.

CIRCLE NO. 21 ON FREE CALD



### Dust Repellent

TORNADO, a dust removal system, and WIPES, cleaning cloths with LintBlock Protection, join flagship STATX (a dust-repellent cleaner and antistatic protector) in the STATX Brands Co. line of high-tech cleaning products. TORNA-DO directs a powerful blast of air to clear dust and lint from hard-to-reach areas through its nozzle or with its supplied extension tube. WIPES are reus-



able lint-free and non-abrasive cleaning cloths. These products are available separately or in a combination pack priced at \$19. STATX Brands Co., RTW International Corp., 1110 Lake Cook Rd., Buffalo Grove, IL 60089; tel.: 708-520-0007; fax, 708-520-1951.

CIRCLE NO. 22 ON FREE CARD

### Low-Cost Network

Server Technology's Easy-OFFICE Network is said to be an easy-to-install resourcesharing network that averages less than \$99 per IBM/compatible computer installed. In addition to normal printer sharing, E-mail and file-transfer capabilities, it incorporates a smart communication port that allows a single modem to support both inbound and outbound calls. The network can be expanded to support up to 32 systems.

EasyOFFICE requires no network operating system, trained consultant or adapter cards. Using telephone-style cables with snap-on connectors, each computer, modem, printer and plotter in the network connects directly to the control unit via the computer's serial port. File transfers occur at speeds up to 115KB. \$500, four-computer package; \$750, eight-computer package; \$750, eight-computer package. Server Technology, Inc., 2332-B Walsh Ave., Santa Clara, CA 95051; tel.: 408-988-0142; Fax: 408-988-0992.

CIRCLE NO. 23 ON FREE CARD

### Heavy-Duty DMM

Fieldpiece Instruments has added models HB75 and HB77 to its heavy-duty HB70 series of multimeters. The meters include a variable-pitch tone, a logic probe and 600-volt fusing on all current jacks. Variabletone pitch is useful for spotting intermittents while wiggling suspect connections. The 20-MHz logic probe responds with both visible and audible indicators. Both meters can measure



capacitances up to  $200 \,\mu$ F, current from 200  $\mu$ A to 20 amperes, voltages from 0 to 1,500 volts dc and 1,000 volts ac.

The meters are manual ranging on voltage. The HB77 measures true-rms ac voltages and currents. Both meters incorporate Valox housings to protect against drops, "O" rings to seal the housing and MOVs to protect against transients. Both measure  $6\frac{3}{4}'' \times 2\frac{3}{4}'' \times 1\frac{1}{2}''$ . HB-77, \$179; HB-75, \$139. *Fieldpiece Instruments, Inc.*, 8322B Artesia Blvd., Buena Park, CA 90621; tel./fax: 714-992-1239.

**CIRCLE NO. 24 ON FREE CARD** 

# **Networking Basics**

# How circuits talk to each other to keep computers in communication

any computer-controlled devices can act as independent, self-contained units. However, sometimes computers need to be able to exchange information, to send or receive instructions, or communicate with each other in some way. For example, a scientist studying tomato varieties might want to grow the plants in a series of enclosed boxes, with temperature, light intensity and duration, air flow and humidity controlled individually in each box. To do so, each box could have its own microcontroller that controls lamps, heaters, fans and so on according to preset conditions.

Now what if the scientist wants to monitor and vary the conditions in each box from a central location, or vary the environment in one box according to conditions in another? This is a job for a network, where each microcontroller can act independently, yet can exchange information with the others. This is just one example of the many uses for networks.

This month we'll look at microcontroller networking: when and how to do it, with a look at an efficient ninebit network you can implement using hardware and software from Cimetrics Technology. As usual, my focus will be on single-purpose or embedded microcontroller projects you might design and build yourself, rather than on applications limited to general-purpose personal computers.

Networking is one of the more-challenging microcomputer projects. Instead of just building and programming a single device, you have to get two or more devices working, and then get them working together, with all of the quirks of serial communication thrown in. The result—devices that can communicate and interact is rewarding, with the rewards usually well-earned.

### When to Network

A network is a solution if you need to send and receive complex information over distance (typically from several feet to several thousand feet), especially if there are more than two devices, or nodes, that need to communicate. A microcontroller, keypad and simple display don't normally require a network, since distances are short and the keypad and display can interface directly to pins on the microcontroller.

But what if you want to enter information at a keypad at one location and have a circuit at another location respond? You can design a network so that one device sends commands like "Decrease humidity by 10%," or "Send me the sensor readings from yesterday," or whatever it is you want to accomplish, and the receiving device will interpret the commands and execute them.

To establish a network between two or more computers, you need three things: a physical path for the data to travel on, hardware interfaces to connect the network devices, or nodes, to the communications path and a software protocol, or set of rules, that enables the nodes to understand the information carried by the network. Let's look at each in turn.

• *Physical Path.* The physical path for the data is usually copper wire, though it doesn't have to be. Fiber-optic cable or transmission through the air on radio or infrared signals are other possibilities. In this article, we'll stick with copper-wire networks and leave more exotic media for another time.


To save on cabling expense, networks use serial communications. Instead of using eight conductors to send a byte of data (one conductor for each bit), the transmitting computer sends bits out one by one onto a single pair of wires. The receiving computer captures the bits as they arrive and converts them back into parallel data for processing.

A common, low-cost form of network cabling is the twisted pair, which consists of two insulated conductors twisted around each other once every few inches or so. Twisting helps to reduce electrical noise induced by changing magnetic fields. You can buy twisted-pair cable or twist your own pair of conductors using ordinary hookup wire. To prevent r-f interference caused by the network and protect the network from electromagnetic interference (emi), use shielded cable and connectors with shielded metal head shells.

Network transmissions can be halfduplex or full-duplex. In half-duplex communication, data travels in one direction at a time over the same conductors. In full-duplex communication, transmitting and receiving use separate conductors, and both can occur at the same time.

• Hardware Interface. On the transmitting end, the hardware interface must convert the data into a format suitable for transmitting and send the data onto the network with enough power to assure that it arrives in good shape at the other end. The receiver's hardware interface has to convert the received signals into a format that the receiving computer can accept and understand.

A UART (universal asynchronous receiver-transmitter) normally handles the task of converting between a microcomputer's parallel data and the network's serial data. The UART also adds and removes the start, stop and parity bits used in serial communication. All personal computers with a serial port contain a UART, as do many single-chip microcomputers.



**Fig. 1.** Texas Instruments TS176 transceiver chip interfaces an 8031 microcontroller's serial port to an RS-485 network.

The UART's serial input and output are normally compatible with TTL or CMOS logic. This is fine for interfacing between chips on a circuit board, but for network transmission over greater distances, drivers with more power are required.

One interface standard especially suited for microcomputer networking is RS-485. Like its RS-232 and RS-422 predecessors, RS-485 is a standard drawn up by the EIA (Electronic Industries Association). The EIA is an association of private industries that develops standards like these, with the goal of eliminating the expense and confusion that result when each organization designs its own way of performing a common task (like serial communications).

RS-485 communication permits up to 32 receivers and transmitters (but only one transmitter at a time), cable lengths up to 4,000 feet in length and speed up to 10M bits per second (but not at maximum cable length and maximum speed). It requires only a single + 5-volt supply and uses differential transmission, where signals are measured as the voltage difference between two signal conductors, rather than as the difference between a signal conductor and a common ground. Differential transmission tends to reject noise and, thus, allows transmission over greater distance.

In contrast, RS-232 was intended for communication between just two devices, at a maximum bit rate of 20,000 bits per second and, because it doesn't use differential transmission, limits cable length. RS-422 is similar to RS-485, but allows only one transmitter and ten receivers.

See "PC Serial Communications" in the September 1991 issue of *ComputerCraft* for more on differential transmission, UARTs and RS-422. The text of the RS-485 standard is available from Global Engineering (see Sources box) for a steep price of \$45 for a 27-page document.

Figure 1 shows an RS-485 interface to an 8051 microcontroller. The interface uses a Texas Instruments 75176 transceiver chip, available from Jameco and other sources. The chip contains a three-state differential line driver, or transmitter, and differential-input line receiver, with an activehigh enable (DE) for the driver and an active-low enable (RE) for the receiver. By tying DE to RE, you get a single direction-control line, high enabling transmit and low enabling receive.

The DE, RE, D and R pins are TTLcompatible, with low inputs of 0.8 volt or less, and high inputs of 2 volts or more. On the RS-485 side (pins A and B), a valid logic level is indicated by a difference (A to B) of 0.2 volt or more, with a logic high occurring when A is greater than B and a logic low occurring when A is less than B.

Figure 2 shows multiple RS-485 devices connected to form a network. These are the requirements for the interconnection:

(1) Wire the transceivers directly to the network wires, or connect them via short stubs (such as pc-board traces from the transceiver chips to the network connectors). You can use twisted-pair cabling.

(2) Add a 120-ohm termination resistor across the signal conductors at each end of the network. No matter how many nodes you have, there should be just two terminating resistors, one at each end of the network.

(3) Keep track of which conductor is which, and don't cross-connect conductors. On 75176s, one conductor connects to all inverting inputs (pins 7), the other to all noninverting inputs (pins 6).


(4) Provide a common return path for all nodes, to prevent large and possibly damaging ground currents from developing due to differences in ground potentials among the nodes. You can achieve a common ground by connecting signal ground at each node to a common earth ground or by adding a third, common, ground conductor to the network cable. If you use the third conductor, connect it through 100-ohm current-limiting resistors to signal ground at each node.

(5) Ensure that the network is biased to a high state when idle to prevent spurious signals from being interpreted as data. In Fig. 2, the 560-ohm resistors in series with the two parallel 120-ohm resistors bring the "A" line about 250 millivolts more positive than the "B" line, which the transceivers interpret as a logic high. A properly designed network should have only one biasing circuit.

If your network requires more than 32 transceivers, you can use repeater chips, such as Texas Instruments' 75177 and 75178, to extend it.

### Protocols

Once your nodes are interconnected, they need to be able to understand each other. The control program



**Fig. 2.** Up to 32 devices can be connected in an RS-485 network on a single pair of conductors. This example shows a half-duplex network in which data travels in both directions but in only one direction at a time over two conductors.

stored in each node must carry out several functions, among which are:

• Configure the serial port (bit rate, number of start and stop bits, etc.) to a common standard.

• Detect and process incoming messages.

• Ensure that the node doesn't try to transmit when the network is busy.

• Handle transmission errors and other problems.

These are in addition to the fact that each node will be busy with its own tasks, with the network interface as a sideline! Now let's look at each function in turn:

Function 1: Configure the serial port. With RS-485, as with all asynchronous serial communications, all nodes must agree on bit rate, number of start and stop bits and parity type. This is usually done by programming the microcomputer's registers. For example, in the 8051, the SCON and TCON or T2CON registers control the bit rate and number of bits per frame. **Function 2:** Detect and process messages. The control programs at each node also must watch for incoming messages, interpret them and act on them if required.

First, each node must be able to detect when a message has been received. Two ways to do this are by interrupts and by polling.

With an interrupt, the program branches automatically to a subroutine whenever a byte is received at the serial port. In the 8051, serial-port interrupts are enabled by setting a bit in the IE register.

With polling, the program must check periodically to see if a byte has been received and, if so, branch to a subroutine. In the 8051, reception of a byte can be detected by checking the RI bit in the SCON register.

Since most networks have several nodes, each node must be able to detect whether a message is meant for itself or another node. If it's for another node, the message is ignored. Otherwise, the node must interpret and act on the message.

One efficient way of identifying the target node is to use a standard message format. For example, all nodes might be programmed to expect messages that are 15 bytes long, with the first byte in each message identifying the node for which the message is meant. This way, each node needs only to examine the first byte of a message to determine whether or not the message is intended for itself. It then can act on or ignore the next 14 bytes as appropriate.

A standard message format can include other information at specific locations, such as the sender's node, error-checking information or message length (for varying-length messages). Function 3: Ensure that two or more nodes don't try to transmit at once. Otherwise, the result is a garbled mess. There are several ways to keep things under control. Three common protocols are master/slave, token passing and collision detection.

Master/slave is simplest. In this type of network, one computer is designated the master, the others as slaves. The master controls all network communication, and a slave can transmit only when the master requests a response from it. For example, a master might send a message to Slave 1, asking it to transmit a reading from a sensor. The master can then process the information received from Slave 1 and send a message to Slave 2, requesting it to increase or decrease light intensity in response to the sensor reading. Slave 2 might respond to the master by acknowledging that it has received the message and has taken the requested action.

To give everyone a chance to transmit, the master can poll each slave periodically by sending a message asking if it has anything to send.

Master/slave protocol keeps everything under tight control, but with a sacrifice in speed, since slaves have to wait to be polled by the master, and all messages must funnel through the master because slaves can't talk to each other directly.


With token passing, there's no fixed master. Any node can act as the master, but only one at a time. The master is whoever possesses the token, which may be indicated by receiving a pre-defined message. When a node receives the token-passing message, it knows it must transmit next.

Token passing is more flexible than master/slave, since nodes can communicate directly. But token passing is more difficult to program.

A final way of controlling a network is with collision-detection. With this protocol, any node can decide on its own to transmit. If two nodes decide to transmit at the same time, they must detect the collision (noise) that results and either wait and try again later or have some way of deciding who wins the right to transmit.

Collision detection can work well if the network is lightly used, resulting in few collisions. But it's the most complex protocol to implement and becomes less and less efficient as network traffic increases.

Function 4: *Handle errors*. Each node should be able to handle transmission errors without causing the network to go wild or grind to a halt. For example, each node should know what to



**Fig. 3.** Cimetrics Technology's NBS-10 card contains an 82510 serial controller and RS-422/485 interface for networking.

do if it receives an unintelligible message or no response to a request.

To help detect messages that don't arrive intact, the transmitting node can add checksums or other errorchecking information to the messages. The receiving node must then determine if there has been an error. If so, it must know what to do (request a repeat transmission, for example).

### Nine Bit Networks

Cimetrics Technology has developed a set of hardware and software networking tools for microcontrollers. All are based on a nine-bit protocol that's supported by many chips, including Intel's 8051, 8096 and 80C186; Motorola's 68HC05, 68HC11, 68HC16 and 68332; Zilog's Z180 and Super8; Hitachi's HD64180; Texas Instruments' TMS7002/7042; and National's COP888CG, COP884CG and HPC46000.

With Cimetrics' products, you can do the following:

• Use a personal computer as a master

in a microcontroller network.

• Use a personal computer to help develop and debug a microcontroller network. (After debugging, the personal computer can be removed from the network.)

• Use Cimetrics' code as a base for developing custom microcontroller network programs.

Applications for Cimetrics' products have included home control, access-card security systems, point-ofsale terminals, waste-water treatment systems and energy management.

Nine-bit networks have one big advantage. They free the nodes from having to examine (or at least recognize) each and every transmission on the network, to ensure that they don't miss any messages meant for them. If the nodes are busy with their own tasks, they can't afford to spend all their time listening on the network, just waiting until a message is addressed to them.

In a nine-bit network, the nodes use a ninth bit to signify whether a frame (nine bits plus a start and stop bit) contains a node address or data, with a 1 indicating an address and a 0 indicating data. The microcontrollers are configured to ignore all frames until an address frame is received. When an address frame is sent, an interrupt occurs and all nodes examine the address. When a node recognizes its own address, it processes the data frames that follow. Otherwise, the data frames are completely ignored.

Some devices, like Intel's 83C51FA, have automatic address recognition, which automatically recognizes one address. With this feature, no interrupts are generated unless a message is addressed to that node.

Cimetrics has written software routines for nine-bit communications for the 8051 and other microcontrollers, including the HC11 and Z180, with more to follow. In addition, the company offers two PC-compatible network cards with an RS-485 interface and UART for nine-bit networking and software for use with the cards. The PC cards allow you to use a personal computer as a master node in a microcontroller network for easy monitoring and control with the PC's keyboard and video display.

A personal computer isn't required in a nine-bit network, however. A network can consist entirely of microcontrollers, with one dedicated as the master, if necessary.

Cimetrics offers a variety of products at different price levels to fit different needs and budgets. I've been experimenting with the NBS-10 serial communications card (\$249) and Tiny-NSP software (\$199). The NBS-10, shown in Fig. 3, is a PC-compatible expansion card that contains an Intel 82510 asynchronous serial controller (an enhanced UART), an RS-485/422 interface and switch-selectable configuration options.

The 82510 can emulate simpler UARTs like the 16450 found in many PCs, but it has additional features. A four-byte FIFO (first-in, first-out) buffer means that you don't have to read each character immediately after receiving it but can store up to four bytes. Transmission rates can be as fast as 288,000 bits per second, and there's an extra timer/baud-rate generator (allows different transmit and receive rates) and support for automatic address recognition. Communication with the 82510 is via its 35 registers, which are arranged in four banks. In contrast, the 16450 has a single register bank, corresponding to bank 0 on the 82510. One 82510 register contains a bit that enables true nine-bit communication. With simpler UART chips, the parity bit must be pressed into service as a ninth bit.

To use the card, you must select a base address for it in your computer (you can use the address of a COM port or another address), an interrupt request number, half-duplex or fullduplex operation and handshaking options. The board includes male and female nine-pin D-connectors, wired identically, so you can use whichever is more convenient.

Cimetrics' software supports the NBS-10 card, or you can do your own programming in assembly language, BASIC, C or whatever language you choose. If you do your own programming, though, be aware that nine-bit communication requires reading and writing directly to the UART's registers. MS-DOS BIOS calls don't support nine-bit communications, nor do many statements in the higher-level languages.

Documentation for the NBS-10 includes an installation and configuration guide, a schematic diagram of the board, programming information, sample C code that allows two PCs equipped with NBS-10 cards to communicate and a reprint of Intel's 40page data sheet for the 82510 UART.

Tiny-NSP, is a software toolkit consisting of several modules:

NBS10COM is assembly-language code that provides an interface to the NBS-10's UART. The code configures the UART, installs an interrupt handler and takes care of details involved in sending and receiving characters. The routines were written in assembly language for fast execution. Both source code and assembled formats are provided. Also included is equivalent NBS2COM software for Cimetrics' NBS-2 card.

**TNSPPC** is PC-compatible software that allows you to read and write to a network node and read the 82510's registers. It's provided as Microsoft C source code and as an executable file.

NETMONIT is PC-compatible software that displays all network traffic in hexadecimal format on a PC's monitor. Like TNSPPC, it's provided in executable format and C-language source code.

TNSP8051 is 8051-compatible code that enables an 8051 microcontroller to communicate with a PC running NBS10COM (or NBS2COM). It's provided in assembly-language source code and in Intel hex format.

You can run TNSPPC and NET-MONIT as-is, in their executable formats, but eventually you'll want to customize the code, adding your own functions, and recompile. Both programs can be compiled with Microsoft C or QuickC, and both incorporate the NBS10COM and NBS2COM modules, which must be linked to the C code after compiling.


The 8051 code, TNSP8051, is written for the Archimedes 8051 assembler. Using other assemblers will require modifications (more on this later). You can program an EPROM or other memory device immediately with the hex file. But, as with the other programs, you'll eventually want to customize the code for your application and reassemble.

All of the Tiny-NSP programs use nine-bit communication and all use a common message structure, which includes dedicated fields for the target node address, source node address, message length, opcode (for example: reset network, read or write to slave, etc.), an error-checking byte and an optional message of up to 250 bytes. The master node places messages on the network, and slaves can respond with the requested information or by acknowledging receipt of the message.

Documentation for the Tiny-NSP Toolkit includes explanations of the code modules, an example schematic of an RS-485 interface to an 8051 microcontroller, advice on compiling and assembling the code and a helpful example project using an 8051 that controls a heater according to temperatures entered at the network master. Comments in the source code also help to document the modules' functions.

I experimented with the NBS-10 board and Tiny NSP software, using a '386 computer as a master and an 8031 clocked at 12 MHz, which allows communications at 62,500 bits per second. I followed the included instructions to configure the NBS-10 and installed it in my computer. I then wired

```
RP - read port
RI - read internal RAM
RE - read external RAM
WP - write port
WI - write internal RAM
WE - write external RAM
Type command: ri
Read internal RAM: starting address? (0 - 255) 0
How many bytes? (1 - 250) 8
Message from node 1: DATA:
48 1 55 55 55 55 55 55
Your options are:
  D - send a data transfer command
  S - get status from each node
  T - send test display message (to a PC only)
 M - send display message (to a PC only)
 R - display UART Registers
Esc - exit
 55
              Ω
                   8
                      60
                                0
      1
          1
                           0
 55
     40
         21
             30
                       0
                   0
                           0
                               12
 ff
      0
         41
             20
                   8
                       0
                          1e
                                0
 50
         61
             84
                  fc
                       f
                               ff
      4
                           0
```



an RS-485 interface to the 8031 board (as shown in Fig. 2), programmed an EPROM with the TNSP8051 object code and installed the EPROM at program address 0 on my 8031 board.

I made a twisted-pair cable with a nine-pin D-connector on one end to connect to the NBS-10 and connected the other ends to the RS-485 interface on the 8031 board.

To get the basic network working on COM3 on my computer, I had to unload a mouse driver on COM1, (even though I wasn't using the mouse), since COM 1 uses the same interrupt as COM 3. I also spent some time tracking down a DIP switch on the NBS-10 that wasn't fully closed and prevented the network from operating properly. Eventually, I got everything working and was able to use my personal computer to read and write to the 8051. Fig. 4 shows an example screen from TNSPPC.

I next decided to try recompiling and assembling the code. I was able to recompile the C code without problems, using Microsoft C version 6. (Earlier versions of C that don't permit in-line assembly language to be used won't work.) For the 8051 code, if you don't have the Archimedes 8051 assembler for which the code was written, you'll probably have to make some changes to get the code to assemble.

With some editing, I was able to use an A51 assembler from Systronix. My first try resulted in dozens of errors, but most were due to easily spotted differences in formatting or syntax conventions. The documentation provided clues to other problems, such as a warning to reserve enough room for the stack segment.

If you want to develop a microcontroller network, Cimetrics' products can help you put together an efficient, full-featured one, but you'll need some programming tools and expertise. Because the PC code is written in both C and assembly language, you must be familiar with both and have access to a C compiler as well as an assembler for your PC.

Modifying the 8051 code requires an 8051 assembler and an EPROM programmer. You also need a copy of the data book for your microcontroller, for details on its nine-bit interface.

By taking some time to study the code provided, you can add code to

### Sources

**Cimetrics Technology** 120 W. State St. Ithaca, NY 14850 Tel.: 607-273-5715 Fax: 607-273-5712 Networking products.

**Global Engineering** 

7730 Carondelet Ave., Ste. 407 St. Louis, MO 63105 Tel.: 1-800-854-7179 EIA-485 RS485 standard.

Jameco 1355 Shoreway Rd. Belmont, CA 94002 Tel.: 1-800-831-4242 Fax: 1-800-237-6948 75176 RS485 transceivers.

the modules and develop your own applications, without having to reinvent the network basics (which are considerable).

In addition to the nine-bit interface, I'd hoped to cover another serial communications protocol this month— Philips' I-squared-C synchronous serial interface. But since I've run out of room, I'll have to save that one for another time.

Next month: How to find and use sensors and transducers to detect and measure just about anything.

Send your comments, suggestions and questions on topics relating to designing, building and programming microcontrollers or other small, dedicated computers to Jan Axelson, ComputerCraft, 76 N. Broadway, Hicksville, NY 11801. For a personal response, please include a self-addressed, stamped envelope.



Jan Axelson

# **Computer Speed**

# How a host of factors influence a computer's operating speed

**P** ut two 33-MHz 386 computers side by side and run the same spreadsheet calculation, database query or compiler. In almost every case, the machines will finish at different times. In a perfect world, computers with the same CPU running at the same clock rate should work at the same speed, but few do. Buying a computer by CPU and clock speed alone is like buying a car based solely on the number of cylinders and valves it has. Both measures will give you some idea of the machine's performance, but no real standard.

Many factors affect a computer's processing speed. Most can be gleaned from the computer's engineering specifications. But some depend on how you use the computer and its exact status at any particular point in time.

The most important factors that determine your computer's performance are, of course, its CPU and its clock speed. Clock speed is the number of ticks the CPU receives each second. For example, a 33-MHz computer has 33,000,000 clock ticks per second. On each tick, the CPU performs an internal operation, such as fetching a piece of data, putting a result in a register or performing all or part of a calculation. Each full machine instruction, like the instructions you write in assembly language, takes two or more clock ticks to complete.

The time required for old and simple CPUs to perform a block of code can be calculated from the manufacturer's hardware specifications, which list the number of clock ticks each instruction requires. Intel processors and the computers they run in, on the other hand, aren't as easy to pin down. Factors like interruptions for memory refresh, alignment of instructions and data in memory and the state of the CPU's pre-fetch queue make exact timing calculations almost impossible.

Intel and many assembler manufac-

turers publish timings for each machine instruction but warn that they're approximations or best-case values. And some published timings, especially for integer division and multiplication instructions, are given as ranges because the CPU's performance depends on the data items involved.

However, the faster the clock speed, the faster a computer can calculate. Because computer speed is affected by more than CPU speed, a 50-MHz machine won't be twice as fast as a 25-MHz computer... but it will be close. of its time cranking through the machine instructions that make up an application program. It must also spend a lot of time fetching both instructions and data from memory. In most computers, memory is implemented as dynamic or static RAM (DRAM or SRAM) on the motherboard, added RAM on a card plugged into the expansion bus or the ROM BIOS chips built into the motherboard and many boards on the expansion bus.

DRAM chips are relatively inexpensive and compact. They used to be an

"A 50-MHz machine won't be twice as fast as a 25-MHz computer, but it will be close."

The exact type of CPU also has a large effect on computing speed. An instruction as simple as "ADD AX,2" requires a minimum of four clock ticks on an 8088 computer, three ticks on an 80286 computer, two ticks on a 386 computer and only one tick on an i486 computer. In general, the 80188 and 80186 are more efficient and perform instructions in fewer clock ticks than the 8088 and 8086. The 80286 is faster. The 386 (both DX and SX versions) is even more efficient, and the i486 is generally the most efficient of all.

There's no exact measurement of the relative speeds of different CPUs in the Intel family, however, because speed is strongly affected by the particular mix of instructions in a particular application. The relative speeds of machine instructions vary from one CPU to another. If you want to write the fastest code possible, you have to learn different optimizing tricks for each chip.

### Waiting Around

Unfortunately, a CPU can't spend all

ideal medium for volatile or on-line memory and are still the only economical choice for the multi-megabytes of RAM modern applications need. DRAM is called volatile because it loses the data it contains when the computer's power is shut off. DRAMs also lose data if they aren't constantly refreshed, which means that the computer has to spend a small percentage of its time refreshing these chips (by accessing every cell) instead of performing other work.

The speed of DRAM chips is usually measured in nanoseconds and is related to the time needed for the chip to receive a read instruction and put the requested bit on the data bus, or to store a bit from the data bus into a specific memory location. In early PC/XTs and 80286 AT/compatible computers, DRAMs could keep up with the CPU. Not all DRAM chips can keep up with today's faster processors, though.

To fetch a byte or word of data, the CPU puts the address of the data on the address bus, places a signal on the control bus that says it wants to read data and then reads the data from the data bus. In the time between the read signal and actual data read, each affected DRAM chip must react to the read instruction, decode the address, look up the necessary bit internally and place the bit on the data bus.

DRAM technology has failed to keep pace with increases in CPU speed. At one time, all that was needed to make a faster memory system was to use faster DRAM chips. But CPU speeds keep increasing at a faster rate than DRAM speeds, which leads to a memory bottleneck. among several different strategies. They can use faster (and expensive) DRAMs, build a memory architecture that takes advantage of the "flash" read mode of 386 and i486 processors and use an SRAM memory cache.

Static RAM chips are less compact and much more expensive than DRAMs, but they can also be much faster and they don't require refreshing. They retain data until it's changed or the computer's power is turned off. An SRAM cache acts as an intermediary between the CPU and main memory. When the CPU asks for data or

# "The simplest solution to match slow DRAM with a faster CPU is to use wait states."

The simplest solution for matching a slow device (DRAM, in this case) with a faster CPU is to use wait states. When the CPU sets up the address and signals that it wants to read a byte of data, the memory system puts the CPU into a wait or idle state by signaling on the wait-state line. When data is ready, after one or more clock ticks, the memory system turns off the wait state line and lets the CPU gather the data and proceed.

If your memory system asserts one wait state during each memory access, your computer loses a clock cycle each time it has to read or write data from memory. When it's reading machine instructions instead of data, the situation is less clear. Each CPU in the Intel "86" family contains an on-board prefetch instruction queue. The size of the queue has grown with each new member of the family.

One part of the CPU reads instruction bytes into the prefetch queue while other parts are busy performing internal calculations. In such cases, memory wait states may have no effect on performance at all because the internal calculations continue during wait cycles. But every time the CPU has to perform a jump to a new memory location or a call to a subroutine or respond to a hardware or software interrupt, it flushes the queue and must refill the queue from the new instruction location. When this occurs, wait states will slow down the CPU until it has its queue full again.

To avoid wait states as much as possible, manufacturers can choose machine instructions, the cache fulfills the request if it contains the correct bytes. If not, it reads data from memory at the same time the CPU does and stores the data in cache in case the CPU wants it again.

On many systems, read requests fulfilled by the SRAM cache use no wait states, while those that must come from DRAMs require at least one wait state. Overall speed of such memory systems depends on the efficiency of the cache controller.

Another memory-related method of speeding up a computer is to "shadow" the ROM BIOS. ROM chips tend to be much slower than either DRAMs or SRAMs. Many 386 and 486 computers have a boot-up option that copies ROM contents into faster RAM and then map the RAM block at the location where the system thinks the ROM is stored. The result is that instructions and data in the ROM chips can be read at full DRAM speed. able to keep up with the CPU and will eventually cause flaky operation or a system crash.

### **Faster Calculations**

All programs spend a portion of their time performing calculations. These may be as simple as incrementing and decrementing pointers to video and data memory locations or as complex as pinpointing orbit positions for satellites. The CPU can perform integer addition, subtraction, multiplication and division with single instructions. But if it has to handle floating-point numbers or calculate square roots and transcendental functions, it must do so using long and slow subroutines.

If you use your computer for word processing, database management or graphics, it probably performs few floating-point calculations. But if you use spreadsheets or engineering applications, your computer spends a lot of time crunching numbers in floatingpoint subroutines.


Almost all 8088/8086, 80286 and 386 computers have a socket for a math coprocessor chip (no coprocessor is needed for i486DX CPUs because these chips have a built-in coprocessor). A coprocessor can handle floating-point numbers directly and perform complex calculations 10 to 100 times faster than the best floatingpoint subroutines. To install a coprocessor chip, you simply push it into a socket on the motherboard and perhaps set a switch or jumper or two inside the computer. The CPU and coprocessor perform all necessary communications automatically.

Any programs you run must be able to detect and use the coprocessor to realize benefit from its presence.

# "You can't speed up a computer by simply installing faster DRAM chips."

You can't speed up a computer simply by installing faster DRAM chips on the motherboard. The memory system is engineered to operate at one specific speed. No matter how quickly the DRAM chips operate, the other memory hardware will enforce the original speed. If you install faster DRAMs, their extra speed capabilities will never be utilized. But if you put in slower DRAMs, they may not be There's nothing in the computer that keeps a dumb application from ignoring the coprocessor and continuing to use slow subroutines to perform its calculations. Most commercial programs can recognize and use a coprocessor, as can programs written with most popular language compilers.

Coprocessors in most 8088 and 386 computers usually run at the same speed as the main CPU. The same is



true of newer 80286 computers. However, many older 80286 computers have a motherboard that runs the coprocessor at a slower clock speed than the main CPU because Intel didn't release updated coprocessors at the same time as it did faster CPUs. Like DRAM chips, there's usually no admotherboard. Intel-compatible coprocessors from companies like IIT and Cyrix are often less expensive and faster than the Intel-compatible chips they replace. As far as I know, there's never any advantage to buying a faster chip if you choose one of these compatible models.

"Many older 80286 computers run a coprocessor at a slower clock speed than the main CPU."

vantage to installing a coprocessor that can run faster than the speed for which the computer's coprocessor socket was designed.

However, Intel's 33-MHz 80387 coprocessors, which can usually be used in 25-MHz 386 computers, are more efficient than the 25-MHz and slower models. This means a 33-MHz 80387 coprocessor can perform calculations in fewer clock ticks than the 25-MHz model of the same chip. Intel apparently redesigned internals of the coprocessor before it released the faster version.

Thus, if you have a 25-MHz 386 computer, you might want to consider using a 33-MHz Intel 80387 coprocessor for fastest possible operation. For any other computer, choose a coprocessor that matches the speed of the coprocessor socket on your computer's There are inherent inefficiencies built into the linkage between the CPU and Intel (or Intel-compatible) coprocessors. To get around them, Weitek produces coprocessors that are favored for high-end engineering applications. They're faster than any Intel/ compatible models for two reasons.

"Weitek chips are faster than any Intel/compatible models."

They avoid the linkage bottleneck by using a memory-mapped configuration (they use memory locations you'd never fill with DRAM chips). And they use fewer internal digits for each calculation to obtain answers faster, even though those answers sometimes have less precision.

Weitek coprocessors, however, require programs written with special compilers or hand-coded machinelanguage instructions. For this reason, they're generally used in only high-end engineering applications.

If you regularly perform floatingpoint calculations with programs that support a coprocessor, a math chip can make your computer seem much faster. But if you rarely perform such calculations, a math coprocessor will simply be an expensive heat generator inside your computer.

### Waiting for the Bus

Microcomputers were designed to be expandable. Except for small laptop and notebook computers, almost every DOS-based machine has an internal expansion bus that can be used to install video cards, disk controllers, network cards, modems and a host of other peripherals.

In the original PC and PC/XT, the CPU ran at 4.77 MHz and so did the internal expansion bus. The original PC/AT ran an 80286 CPU at 6 MHz and the bus at the same speed. Bus speed was increased to 8 MHz, along with the CPU, in later models of the PC/AT computer.

As computer speed increased, users faced a real dilemma. If the speed of the bus kept pace with the CPU, addin cards would become obsolete each time the user upgraded to a new and faster CPU. The solution was to keep bus speed at 8 MHz while the CPUs got faster and faster. The advantage of a slow bus is that all add-on cards will work in the computer, even ones that were designed for the PC/AT. But if you put an 8-MHz expansion bus in a 50-MHz i486 computer, the machine will come to a near standstill every time it has to access the video card, hard disk, memory expansion card or other peripheral.

The solution used by many manufacturers is to let the user pick the bus speed. The 25-Mhz 386 computer I'm using right now, for example, has a switch on the front that changes bus speed (after a reboot). Every card I've tried has been able to keep up with the bus running at full speed, but if I wanted to transfer some cards from one of my older computers, I'd have to slow down the bus.

(Continued on page 85)

## With NRI handson training, you can experience the rewards of a career in computer programming

Now you can get the practical training and experience you need to succeed in computer programming, today's topgrowth computer career field.

NRI at-home training gives you real-world programming skills in four of today's hottest computer languages: BASIC, Pascal, C, and COBOL. You get hands-on training that now includes a powerful 386sx/20 MHz mini-tower computer, modem, and programming software ... all yours to train with and keep! Best of all, NRI gives you the programming know-how you need to succeed on the job, in a new career, or in a business of your own.

Job opportunities for the skilled computer programmer will increase by 71.7 percent over the next 10 years according to Bureau of Labor Statistics forecasts. And now, with NRI training, you can be one of the increasing number of computer programmers using their skills to build a top-paying career — even a business of their own — in this professionally and financially rewarding high-tech field.

### ▼ The only programming course that includes a powerful 386sx-based computer system and programming software you keep

Right from the start, NRI training gets you actively involved in the challenge of realworld programming. You learn how to create the kinds of full-featured, powerful programs today's employers and clients demand.

And, unlike any other school, NRI lets you experience first-hand the power of an IBM PC/AT-compatible, 386sx-based computer system, complete with modem, a full megabyte of RAM, disk drive, and monitor — all yours to train with and keep! Plus you explore the extraordinary capabilities of not one or two but <u>four</u> in-demand

computer languages. You learn to design, code, run, debug, and document programs in

BASIC, Pascal, C, and COBOL. In the process you become uniquely prepared for the wide variety of programming opportunities available today.

### ▼ No previous experience necessary

Immediately, you start getting the money-making job skills you need to secure a future in computer programming — no matter what your background. NRI's unique Discovery Learning Method guides you swiftly from computer novice to computer professional with step-by-step lessons covering program design techniques used

every day by successful PC programmers. You'll find no heavy textbooks to plow through. No night classes to attend. Instead, NRI's at-home, step-by-step training covers all the bases, guiding you from the important fundamentals to realworld methods and techniques. Backed up throughout your course by your experienced NRI instructor, you quickly gain the skills you need to handle a wide variety of programming tasks with confidence. You even use your modem to "talk" to your instructor, meet other NRI students, and download programs through NRI's exclusive programmers network, PRONET.

11

### ▼ Send today for your FREE catalog

Now you can experience the professional and financial rewards of a career in computer programming. See how NRI athome training gives you the know-how, the computer, and the software you need to get started in this top-paying field. Send today for your FREE catalog!

If the coupon is missing, write to us as the NRI School of Computer Programming, McGraw-Hill Continuing Education Center, 4401 Connecticut Avenue, NW, Washington, DC 20008.

	SEND FOR YOUR FR	EE NRI CATÀLOG TODAY!				
	McGraw-Hill Continuing Education 4401 Connecticut Avenue, NW, V	on Center				
	Check one free catalog only					
世世世	Computer Programming     Microcomputer Servicing     PC Applications Specialist	<ul> <li>□ Programming in C++ with Windows</li> <li>□ Desktop Publishing &amp; Design</li> <li>□ Bookkeeping and Accounting</li> </ul>				
	Name	Age				
ets you	(ple	(please print)				
n IBM nputer	Address					
ll <sup>*</sup> nonitor	City Accredited Member, National Home Study Council	State Zip 5414-042				

# PC Desktop Video

Part 2

### Titling, animation, sound and video-putting it all together

L ast month in Part 1, we discussed the major hardware components that make desktop video possible on PCs, including video boards with overlay capabilities and the high-end, PC-controllable NEC PC-VCRs. This time around, we'll be looking at some of the better and more innovative software products available for bringing PC video presentations and productions all together with a truly professional touch.


The principal production areas we'll be focusing on here are titling, animation, sound and combining all of these elements with video imagery to produce a finished desktop video production. Because we have lots of ground to cover this month, let's get right to it.

Video Titler, \$495 Entropy Engineering 12317 Village Square Terr. Suite 202 Rockville, MD 20852 Tel.: 301-770-6886

CIRCLE NO. 50 ON FREE INFORMATION CARD

Entropy's Video Titler program comes packed with in an OEM version with the TrueVision Video VGA with Overlay board and the Willow Peripherals VGA-TV GE/O board covered in Part 1. Whether you're using the OEM version or stand-alone retail version, *Video Titler* is without a doubt the king of all video-titling software products.


To install and run Video Titler, you need at a minimum a 286 AT-class computer running at 12 MHz and preferably a 386or i486 machine running at a faster speed, hard drive with at least 2M available and VGA graphics card with NTSC output and overlay capabilities. You also need 640K of RAM with 540K available, which may require relocating device drivers and TSRs to high-memory areas to free up more space in the lower 640K area. This is particularly important when using TSR-activa-



An example of Deluxe Paint Animation's "metamorphosis" effect.



Screen shots show DPA's user interface (left) and one possible spin/rotation effect (right).



Video Titler's (A) user interface makes it easy to enter text and choose a lettering style for (B) truly broadcast-quality results.

tion utility programs provided with video cards like the TrueVision Video VGA with Overlay and Everex Vision VGA video card, which both provide a TSR to toggle recordable and overlay modes from within an application as a handy alternative to the DOS-prompt command lines for the equivalent functions. Relocating TSRs to upper memory using the "load high" command tucks these handy utilities above the 640K mark and leaves extra room in which the Video Titler program can operate.

Software is supplied on six disks, and excellent user manuals come in a three-ring binder. Installation is fully automatic once you've selected the type of video board present in your system. Since the OEM versions are preset for the boards with which they ship, they don't give the board-selection options that are present in the standalone retail version. The retail version provides choices for 16 popular video boards, including a generic VGA driver and drivers for Tseng 3000- and 4000-based cards.

The software set is composed of an installation disk, display drivers disk, utilities disk and FontPak MI, the last on the three remaining disks. FontPak MI is a collection of 129 type fonts in assorted styles and sizes for creating video titles. The quality of the type faces is amazing—no crude letterforms here! Excellent renderings of such perennial typefaces as Park Avenue, Helvetica, Old English, Times Roman and many others are all proportionately spaced with the right amount of "air" around characters for proper appearance and high legibility on an NTSC display.

The overall controls of the program permit making each title line or even each character a different color. Such additional effects as underlining, drop shadows and more permit further enhancement of the basic letterforms. Title and text sequences of virtually any length can be created and saved, limited only by the amount of disk space available for storage. More than 100 wipe, fade, dissolve, roll and scroll patterns are available for introducing text to the screen. These can be combined for all kinds of interesting effects. Timing intervals for duration of static screens and/or movement of "rolling titles" or scroll-across sequences can be set in infinite variations as well. Color palette selections allow you to "key" the background color of the titles to be transparent when combined with video to produce text overlays with live action.

Video Titler's user interface is amazingly simple, considering the amount of power and creative flexibility the program provides. In addition to a quick-reference card and the user manuals, on-line help is available. Drop-down menus, accessed through function keys, display choices for the current mode, whether it's entering text, editing, previewing or adjusting timing and effects. An included eye-catching demo program really showcases this amazing program's capabilities when multiple effects are combined.

Additional utilities provide more power and flexibility to Video Titler by allowing you to import and customize logo art in .PCX image format. An ASCII import utility facilitates using text files created in word processors or other applications in title sequences without having to retype the text. A page copy utility permits you to copy one or more pages of text and attributes to other pages in the sequence, another handy feature for "boilerplating" information that must be uniform from sequence to sequence, as in corporate presentations. A page print utility is also included for printing selected title pages from a sequence.

While character generators are commonly found in today's better camcorders and VCRs, they lack the truly professional options and broadcast video quality that you can get using *Video Titler*. It's really an indispensable tool for any kind of serious desktop video work that requires textual matter to be displayed or overlaid.

Deluxe Paint Animation, \$134.95 Electronic Arts P.O. Box 7578 San Mateo, CA 94403 Tel.: 1-800-245-4525

#### **CIRCLE NO. 49 ON FREE INFORMATION CARD**

If you've ever used *Deluxe Paint* from Electronic Arts, you'll have an almost zero learning curve for *DP Animation*. If you're a total novice, you'll be creating animations almost as quickly. *DPA* combines virtually all of the excellent painting tools found in the Paint program and adds motion control to them (along with some other nifty tricks) to produce a full-featured animation program that's truly intuitive to operate.

Having the color and shaping capabilities of a full-featured paint program endows DPA with a wealth of creative options from which to choose, including an assortment of interesting fonts. An optional Kara fonts package, available directly from Electronic Arts for \$69.95, provides an excellent addition to the monocolor fonts that come with DPA. The full-color Kara fonts are named Bevel, Brick, Cast, Chisel, Chrome, Granite, Marble, Column and Wood, which simulate metal, carved wood and chiseled stone. Kara fonts are spectacular for creating main title animations and, using DPA's 3D motion capabilities, the possibilities really become interesting. Spinning titles that zoom in from some point at infinity and tumbling, rotating and floating title sequences are surprisingly simple to produce.

Any image (including text) created on *DPA*'s screen can be turned into a "brush" you can then rotate, flip, shear, re-size, smear or shade. These brushes can also become "animbrushes" that allow you to select an area of animation as a brush and

paint with it. With animbrushes, the sequence of the brush itself changes as you paint with it so that you can "rubber stamp" blank frames with stepped animation to produce finished sequences in very little time.

Automated transitional animations that "metamorphose" one shape into another are also easily created with the metamorphous animbrush feature. Creating such transitional animation automatically is as easy to do as selecting a beginning image animbrush, such as an egg, and an ending image animbrush, like a chicken. When prompted you merely specify how many cells (frames) over which you wish the transition to take place and click on OK.

Specifying a cell number like 60 would make the transitional animation twice as long as specifying 30. The end result is a computer-generated metamorphosis of the egg image into the chicken image. It's nothing short of amazing to watch this offthe-shelf software product produce computer-generated animation sequences like this on a personal computer in a matter of seconds when you consider that the equivalent feat, if done manually, would take many hours of human effort.

Several sample animations and animbrushes supplied with the program files serve as teaching aids and impressive demonstrations of what's possible with DPA. The 256-color palette supports tiling and color cycling and a "wrap" feature that makes a tiled pattern follow the proper perspective of a shape like a ball or any other geometric shape to give the illusion that the selected shape is actually wrapped in the pattern.

Because the user manual for the program is exceptionally well written and indexed, finding a particular procedure or technique is easy. While DPA's friendly menu-bar interface and context-sensitive options make using the program easy right out of the box, to fully exploit its features, power and capabilities takes many hours of reading technique descriptions and experimenting with different settings in the program to see their effects in action.

An optional and outstanding VHS videocassette is available for \$27.95 directly from Electronic Arts. This hour-long tape gives invaluable tips and shortcuts for such advanced topics as AnimPainting (painting while the frames flip automatically), using the move dialog to achieve dazzling three-dimensional movement and rotation sequences and loads of pointers and ideas that aren't covered in the manual. If you're going to use DPA, this video is indispensable for getting the most from the program in the least amount of time.

Deluxe Paint Animation packs lots of bang for the buck and makes creating advanced animations an enjoyable and relatively easy process. It's an excellent animation package that's ideally suited for many desktop-video uses, from titling to cartooning and everything in between.

Autodesk Explorer (formerly Autodesk Animator), \$199 Autodesk, Inc. 2320 Marinship Way Sausalito, CA 94965-9910 Tel.: 415-331-0356

**CIRCLE NO. 48 ON FREE INFORMATION CARD** 



The product covered here is really Autodesk Animator. By the time you read this, it will be replaced by Autodesk Explorer. The new package retains all the terrific features of Animator and adds Windows 3.0 compatibility for additional multimedia capabilities. However, since Autodesk Explorer wasn't available as of this writing, Autodesk Animator is the program I'm covering here.

If your desktop-video applications require a true "industrial-strength" product, *Autodesk Animator* is the animation package of choice for you. Created by the makers of *AutoCAD*, *Autodesk Animator* pushes the envelope limit of what's possible on a PC.

Offering a more comprehensive selection of drawing tools and coloring options than *Deluxe Paint Animation, Autodesk Animator* is capable of producing true broadcast-quality animations. Several examples of this are provided with the program disks. One example, an animated tidal chart showing the high- and low-tide times, looks amazingly similar to the animated graphic I've seen on a local TV station during the weather segment of its news broadcasts.

Like DPA, Autodesk Animator gets much of its strength from a well-designed, simple-to-use interface that integrates all paint, image-processing and animation functions together. Using a mouse-oriented point-and-click scheme to pull-down menus or pop-up dialogue boxes, other friendly features include slider bars, action buttons and scrolling windows to access a bewildering range of image- and motioncreation tools.

Integrating graphics, text and photos (or captured video images) with AA is easy to accomplish using the 22 different drawing tools that include polygonal lines, spline curves, boxes, circles, ellipses and stars supplemented with airbrushes, fills, streaks

and gels. The program features 26 different "ink" types to simulate transparency, shading, embossing and color gradations.

By combining the ink types with the various drawing tools, 572 different combinations are available for use with any 256 colors out of a palette of 262,144 colors. An embossing effect is particularly unique for creating images that look like they were "punched" into (or out of) the video screen. An example of this embossed effect is the VH1 logo that resides in the lower-right corner of the screen on your local VH1 cable channel. This effect and hundreds of others are possible with AA.

One of the really neat things about the user interface is its control layout, which closely resembles a professional videotape editing console. Directional arrows signify forward or backward motion, play speed can be "dialed" up, and color cycling can be adjusted, individually or in groups, using the RGB overall controls. Animation sequences can be stepped through individually or played in continuous loops.

This is, indeed, a professional-level package that permits creating, editing and playing back a full-length presentation—in real-time—from your hard disk. With the right equipment (a recordable video board and VCR), you can record an entire production to videotape in one pass. Since *Autodesk Animator* uses the same video drivers as sister product *AutoCAD*, extended VGA modes are possible for stunning realism in animations and simulations.

Provided with the software diskettes are a quick-start card, 157-page tutorial manual and 320-page reference manual that answer virtually any question you could think of regarding a program feature, function or effect. A provided VHS videocassette gives a very impressive demonstration of the program's capabilities, although it isn't a tutorial. On the other hand, the tutorial manual leads you step-by-step through modifying the sample animations and creating your own animations to teach you the program from ground zero.

In addition to a huge assortment of type fonts and typographic effects, the paint portion of AA includes a metamorphosis feature called "tweening" that computergenerates a series of images 'tween the beginning shape and the final one of a transition. However, by selecting portions of the target image that contains a "tweenable" shape, you can customize the metamorphosis. If you've seen any of the new car commercials that metamorphose a car's dashboard and seats, you've experienced tweening. Since AA can accept digitized video images as raw material, tweening between two video images isn't only possible, it's fairly simple to accomplish.

No serious desktop-video or broadcastvideo project that requires professional graphics and animation capabilities should be attempted without a copy of *Autodesk Animator* at hand. I don't know of any other product that does so much, so easily and so well when it comes to creating show-stopping animations. *Animator*'s public-domain player utility is also included for distributing your animations to other computer users.

GRASP (GRaphic Animation System for Professionals), \$349. Paul Mace Software, Inc. 400 Williamson Way Ashland, OR 97520 Tel.: 503-488-2322

CIRCLE NO. 47 ON FREE INFORMATION CAPD



*GRASP* is an interesting and useful package that does double duty as an independent creative medium as well as serving as an integration tool for pulling DTV elements created with other products into a cohesive, smooth-running presentation. Its real strengths are an ability to create and animate images in CGA, EGA, Hercules and VGA modes up to  $1,280 \times 1,024$  (with the right video hardware) in 256 colors and an ability to synchronize digitized sound created with a SoundBlaster or AdLib sound board with *GRASP*-created applications.

Additional sound support is also present in the program's ability to precisely control CD-ROM and audio CDs for music and sound effects. Just released as this was being written is an optional *Authentic Audio Tools* package (\$99) that plays digitized sound from the PC's speaker, rather than through a sound board. More than 500 digitized sound effects are included, and sounds can be looped for sustained effects. Sound quality can also be adjusted using high-filter, bass boost and volume controls.

Animations and sequences created under Autodesk Animator can be utilized with GRASP since it handles .FLI (Autodesk) file types in addition to .PCX, .GIF and .TIF and other popular formats. A Graphics Link Plus (TGL +) image capture, file conversion and printing utility is included for converting images from one file format to another for added imagehandling and manipulation capabilities.

A full-featured paint program is integrated into the package and is fairly easy to use, although not on the same level as either DPA or AA. The pattern and shading effects of the program, however, are quite extensive, and RGB or "process" color mixing is also supported. Multiple images can be manipulated with full control of the color palette, movement and timing for each.

A very handy included feature is a screen-capture program that can save and edit images from other programs, especially useful if you're doing work that requires "grabbed" images.

An included collection of programs called ARTOOLS automatically generates special animation effects based on your own artwork, whether created within GRASP or imported from other applications. Lots of interesting rotations, spins, tumbles, wipes and other eye-catching effects are possible and relatively easy to accomplish using these tools.

An optional add-on package called *GRASP Tools* (\$79) is also available for serious users. This is a collection of advanced application utilities. Mostly devoted to file-management activities, the *Tools* package facilitates creating *GRASP* libraries automatically without unnecessary files, ridding the demo directory of unused files, adjusting clipping offset values, accessing important font information and making custom palette files to save memory space in addition to other filemanagement and housekeeping tasks.

Aside from creating productions and presentations for desktop video uses, *GRASP* also makes it possible to create interactive computer demos and presentations that support keyboard, mouse or touch-screen input from viewers. Another nice touch is a Glexe compiler utility, which creates self-contained executable versions of your productions for public distribution with no licensing fees.

*GRASP* is an excellent tool whose real strength is its ability to combine individual audio and visual elements into a seamless production that can be directly recorded on video tape or used as automatic/interactive computer presentations.

ASK-ME 2000, \$495 Brown-Wagh Publishing 130-D Knowles Dr. Los Gatos, CA 95030 Tel.: 408-378-3838 CIRCLE NO. 46 ON FREE INFORMATION CARD



ASK-ME 2000 is a multimedia authoring environment specifically designed to integrate and assemble elements from various sources and applications into a finished production. The finished product is suitable for recording on video or as an interactive multimedia application running on computers that support joysticks, touch screens or the keyboard as interactive input devices.

Rather than creating presentations or animated sequences from scratch, A-M2000's main strength lies in its ability to integrate individual elements and capture video images (using a Digital Vision Computer Eyes digitizer board) to produce finished productions. Like GRASP, A-M2000 can be used to produce automatic demos, interactive multimedia presentations and create productions for PC desktop video.

A-M2000 can handle any .PCX format image created with paint programs like PC Paintbrush. Supported are audio integration for the SoundBlaster and Video Associates sound cards and Autodesk Animator .FLI files.

A really unique feature of A-M2000 is its script-based approach to multimedia authoring. The icon-based environment is very intuitive in design and very fast to learn. Based on a proprietary programming language called Stratos, commands are entered into three principal script-creation areas labeled "Before," "During" and "After." Each area is boxed and you literally tell A-M2000 what to do with each screen to be displayed in the application. The kicker here is that you use plain-English words like "animate," "speak," "show" and "display," rather than some arcane programming structure, to achieve desired results. The learning curve for this program is remarkably small, considering the number of interesting functions and effects possible with it.

ASCII text files can be imported in addition to animations and graphics you can create outside the program. A 256,000 color-shade palette that permits up to 256 concurrent colors (with extended VGA modes) to be displayed at any one time is one of the strong presentation features of the package. *ASK-ME 2000* is an excellent product for seamlessly integrating individual elements and media into a sleek finished product.

Animation Works Interactive, \$495 Gold Disk, Inc.

P.O. Box 789, Streetsville Mississauga, Ontario, Canada L5M 2C2 Tel.: 416-602-4000

CIRCLE NO. 45 ON FREE INFORMATION CARD

If you have *Windows* 3.0 and Microsoft's Multimedia Extensions 1.0 or later on your system, *Animation Works Interactive* is an animation and presentation package that

### Setting Up For PC Desktop Video

If the main article piqued your interest in desktop video for the PC, you'll probably want some guidance in selecting hardware, software and accessories to do serious work in this area. The best advice I can give you is research your needs carefully. And the best way I can show you how to do this is by giving you a rundown on dream desktop-video system. • PC. My host PC is a system unit built around a 33-MHz i486 motherboard and has 8M of user RAM; 5¼" and 3½" highdensity floppy drives; 85M hard disk (supplemented by a 105M hard card); and CD-ROM drive.

• Video. l use a Truevision VGA super-VGA card with Overlay card populated with 1M of video RAM and a 14" multifrequency color video monitor (soon to be upgraded to a full-digital monitor).

• Image Grabber. I use a Digital Vision Computer Eyes/RT video digitizer board and the Computer Eyes host software for all image-grabbing work (the preview feature is especially useful; see Image Grabbing in December 1991 Computer-Craft for details).

· Audio. My Sound Blaster card is MPCcompliant with the Microsoft Multimedia Extensions under Windows. I also use a Covox Sound Master II card for creating more elaborate musical scores via the MIDI interface. After creating and storing them, I can then access MIDI files from within MPC extensions in Windows to integrate them into my applications and presentations as desired. This is an example of trying to have the best of both worlds. I like Covox's software and built-in MIDI capabilities, but I can't live without the Sound Blaster's MPC compatibility. This arrangement proves that you can have it all if you're willing to spend the bucks.

• Video Sources. Though I used to use a Canon Xapshot digital still camera for image acquisition, I now use a Panasonic PV-21 VHS-C camcorder instead. Since the Computer Eyes/RT board can do real-time captures in 1/30 second, there's no problem grabbing a frame from moving video tape, and the Panasonic camcorder offers much better resolution than the Xapshot. Another advantage is that the camcorder records sound, which I sometimes use for narrative passages or sound effects that I digitize via the MPC extensions sound recorder capabilities. VCR. Dual NEC PC-VCRs (see Part 1) are connected to the PC via the serial ports for fully computer-controlled editing. One PC-VCR functions as the "source," the other the "target" deck. While expensive, these incredible VCRs leave everything else in the dust when it comes to programmability and quality. • NTSC Monitor. I use a portable 7" color Panasonic TV receiver/monitor to view my videotape and computergenerated video work. The Truevision board (with recordable VGA enabled) routes all video (both computergenerated and NTSC pass-through from the source deck or camcorder) to the Panasonic monitor so I can see what the result will look like before committing to video tape. Audio portions are also played via the Sound Blaster board through a pair of Walkman speakers to check sound quality and timing with the video portions.

• System Software. I run DOS 5.0 with MSCDEX 2.2 Microsoft CD-ROM extensions as the basic operating system. I also extensively use Windows 3.0 with Multimedia Extensions 1.0 in 386 Enhanced mode for many multimedia and desktop video projects. I don't use thirdparty memory managers, but I do load as many device drivers for the system as possible into DOS's high-memory area to free up as much of the base 640K.

· Applications Software. For basic image retouching and manipulation, I use PC Paintbrush IV under DOS and Publisher's Paintbrush under Windows; Animation Works Interactive for creating MPC productions under Windows; and GRASP when working under DOS. For simple title animations with rotations and spins, I use Deluxe Paint Animation. For more intricate sequences, where I combine captured video images with computer-generated imagery, I use Autodesk Animator. For overall titling and rolling video text I use Video Titler. When I want to put together something quickly, I use 2000 for integrating elements (it runs under DOS and is much faster than Windows-based equivalents).

• Miscellaneous. Of course, I have myriad cables, adapters and a variety of products like Inset System's Hijaak and Applications Techiques' Picture Eze, which I use for converting image formats. Other products play background roles in making a production come together, but the components mentioned here are the major players in my multimedia/desktop-video system.

As you can see, getting into PC desktop video isn't something you take lightly. Even if you go for a "minimum" hardware configuration and limit your software purchases to those packages that supply only minimal utility, you'll be making a hefty monetary investment. Too, be prepared to spend considerable time learning how to use all the elements that make up your system. Is it worth it? If you like to exercise your creative urges, you bet it is!

really exploits the possibilities of this environment. Predominantly intended for creating interactive multimedia presentations using a personal computer, A WI is a superb tool for creating desktop-video productions as well.

While AWI will run on a 10-MHz or faster 286-based machine, the recommended minimum configuration is a 386-SX or later-technology CPU with 4M of RAM, super-VGA or extended-VGA, MPCcompatible audio board and, for desktopvideo applications, a video overlay board.

Since AWI runs under Windows 3.0, everything is oriented for point-and-click operation throughout the program. Three principal modules comprise the AWI package: background editor, cel editor and movie editor. A runtime player is included to allow you to distribute your completed presentations to any *Windows* user.

You use the background editor to create colorful backgrounds. It contains a full set of paint tools, including multi-color gradients. Scanned images, digitized video images, bitmapped graphics and artwork created in other packages are all easily imported into A WI, which supports virtually all major image filetypes.


The cel editor is abundantly rich in professional animation features, like "onion skin" that lets you trace a new image based on an existing one, auto-zoom and autorotate for multi-dimensional movement. Anything created with the cel editor, whether artwork or titling, is referred to as an "actor" in A WI terminology. A generous library of stock "actors" is included with the program. Automatic zoom and rotational features are extremely useful in producing striking title sequences.

With the movie editor module, you easily combine backgrounds and actors (text, graphics, charts, etc.) and sequence them with sounds, music, narration and wipes to make dynamic productions. Putting the whole show in motion is easily accomplished via the VCR-style interface with familiar controls like play, rewind and forward. If the production is to be used as an interactive system, you can add "action buttons" on which users can point-andclick. For desktop-video applications, the completed production can be recorded on

-B. G. I	MICRO	P. O. Box 280298 Dal (214) 271-5546 FAX (214) 271-2462	las, Texas 75228
And and a state of the local division of the local division of the local division of the local division of the		TAA (414) 271-4404	
FANS Brand New from McLean Eng. A Division of Zero Corp. Square 4-11/16" by 1.5" Thick 10" Wire Leads 120V - 60hz12 amps - 110CFM Metal Housing - 5 Plastic Blades UL and CSA Approved \$5.95 ea. 12VDC - Brushless Manufactured by Commonwealth Model FP 108D-7 Blades 8" Wire Leads - 150MA 3%" Square - 1" Thick This size commonly used in computer power supplies. S6.95 ea. BECEIALS MAX232 2.30 1488 45 1489 45 DB25-(Solder Cup) M/F 2/1.00 DB25-Rt Angle PC BD. M/F .35 DB3-Rt Angle PC BD. M/F .35 DB3-Rt Angle PC BD. M/F .35 DB3-Rt Angle PC BD. M/F .35	THE \$25 NETWORK Try The 1st Truly Low Cost LAN • Connect 2 or 3 PCs, XTs, ATs • Uses serial ports and 5 wire cable • Runs at 115 K baud • Runs in background, totally transparent • Share any device, any file, any time • Needs only 14K of ram Skeptical: We make believers! BUPER BUYS BTMF SSI-202 Decoder 2.25 8870 Decoder 2.25 5087 Generator 2.00 5089 Generator 2.10 2N4401 Super 2N3904 NPN Switching Transistor 40V-TO-92 — P.C. Leads	GENERAL INSTRUMENTS SP02 CTS256A-AL2 TEXT TO SPEECH THIS BOARD USES ONE SLOT REQUIRES A COM SERIAL PORT STAND ALONE ENVIRONMENT (I ALMOST ANY COMPUTER THAT USE THE BOARD IT IS ONLY NEC TO THE RS232 INPUT ON THE E 1500 BYTE TEXT BUFFER AND H TO SEND DATA TO THE BOARD; DATA TO AN RS232 SERIAL PR FILES THAT WILL MAKE YOUR "GOOD MORNING MASTER," ETT DEMONSTRATION SOFTWARE / GRAM ARE INCLUDED ON A 5 DOCUMENTATION AND SCHEM,	E YOUR COMPUTER TALK! With the second secon
840 x 240 dots - Super twisted nematic type. Bull in driven - 4 bit TTL interface - Capable of diaplaying numerica, graphics, alphabelics, special characters, graphic, charts, and patierns. Viewing area 107-116° x-5-87. Overall 11-3/8° x-6-1/16° 14 pins for signais and power (+5V, -12V). Complete 27 page manual \$19.95 6/\$100.00	15/1.00         1000/20.00           80C32         C-MOS By Matra - 12MHZ           3.95	SYSTEM FOR THE VISUALLY IMP PACKET T.M.1. STAND ALONE POWER SL FOR ABOVE ADD \$2.50 SHIPPING & HAR STATIC RAM 2016-2KX8 200 n.s. 1.00	EPROM SPECIAL
74LS           LS00         14         LS114         .25         LS241         .60           LS01         .14         LS122         .35         LS242         .65           LS02         .14         LS123         .45         LS243         .50           LS03         .14         LS124         .35         LS243         .55           LS04         .14         LS125         .30         LS245         .55           LS05         .14         LS126         .35         LS251         .45           LS08         .14         LS126         .35         LS257         .35           LS10         .14         LS138         .35         LS259         .45           LS11         .14         LS138         .35         LS259         .45           LS11         .14         LS138         .5         LS279         .30           LS20         LS151         .35         LS208         .65         LS28         .55           LS21         L6         LS154         .528         .5299         .70           LS22         LS157         .30         LS298         .55         LS293         .50	16L8-15       TI-B-PAL       1.25         8088-2       3.25         8742       7.00         WIRE WRAP         Dual Wipe - 2 Level         14 Pin       10/2.50       100/20.00         16 Pin       10/2.50       100/20.00         20 Pin       10/3.50       100/30.00         SOCKETS         Low Profile SOLDER TAIL         6 Pin       14/1.00         8 Pin       13/1.00         14 Pin       13/1.00         14 Pin       13/1.00         14 Pin       13/1.00         14 Pin       13/1.00         20 Pin       13/1.00         20 Pin       13/1.00         22 Pin       8/1.00         28 Pin       7/1.00         BUY \$10       GET \$1.00 - FREE CHOICE         68 Pin PLCC       .79         84 Pin PLCC       .89         Colspan="2">6550         G652         6551         2.00         6520       2.00         6520       2.00         6520       1.00         6522       2.00         <	2101-1 - 256X4 500 n.s.       .75         2102-1 350 n.s.       .65         2102AL-4 L.P. 450 n.s.       .49         2111-1 256X4 500 n.s.       100         2112A-2       250         2114L-3 1KX4 300 n.s.       .49         2112A-2       250         2114L-3 1KX4 300 n.s.       .45         2125A-2 1KX1 70 n.s.       1.70         2147 4KX1       .95         6116P-4       1.00         6117       1.20         6264-15       1.40         6264-15       1.40         62656 32KX8       5.75         DYNAMIC RAM         2108-4 8KX1       1.50         2118-4 16KX1-5Volt       .70         4027-4KX1-250 n.s.       .40         4116-16KX1-200 n.s.       .40         4116-16KX1-200 n.s.       .40         4116-16KX1-200 n.s.       .10         4164-100 n.s.       .140         4164-100 n.s.       .140         4464-120 n.s.       .140         4464-120 n.s.       .140         4464-100 n.s.       .45         4464-100 n.s.       .45         4464-100 n.s.       .45         4464-100 n.s.       .45	We bought a large quantity of 2708s, 2716s, 2532s, 2732s, 2764s, 27128s, 27256s and 27512sfrom a computer manu- facturer who redesigned their boards. We removed them from sockets, erased and verified them, and now we offer the sav- ings to you. Complete satisfac- tion guaranteed.           Your Choice           2708         1.20         10/8.00           2712         1.20         10/8.00           2708         1.20         10/75.00           2708         2.00         10/17.50           2712         2.00         10/17.50           2732         2.00         10/17.50           2744         .00         10/17.50           2756         3.50         10/30.00           27512         4.75         10/40.00           27512         4.75         10/40.00           27512         3.55         8255           8031         2.95         8251         1.10           80032         1.00         8255         1.50           8085         1.55         8255-5         1.75           8086         1.55         8257         1.50           8085         1.55         8257         1.50           8085         1.55         8257         1.50           8087         1.55

SEND FOR FREE CATALOG! OVER 150 NEW ITEMS!

TERMS: (Unless specified elsewhere) Add \$3.25 postage, we pay balance. Orders over \$50.00 add 85¢ for insurance. No C.O.D. Texas Res. add 81% Tax. 90 Day Money Back Guarantee on all items. All items subject to prior sale. Prices subject to change without notice. Foreign order - US funds only. We cannot ship to Mexico or Puerto Rico. Countries other than Canada, add \$9.00 shipping and handling.



video tape in a single pass, complete with sound effects, if desired.

External devices like VCRs and laserdisc players can be controlled from within A WI for activating video segments upon command. This is a handy feature to have for exporting computer-generated material in concert with previously taped video to a recording VCR. At predetermined points in the presentation A WI activates the "source" VCR; adds any titling, graphics or overlay material; and lets you record the combined output on a "target" VCR. This feature can also be used for "live" interactive productions, such as point-of-sale and kiosk displays to show product videos from a VCR or Videodisc player.

A WI is a tremendously powerful package that makes all kinds of special effects both possible and incredibly easy to access. While its user's manual is excellent in its clarity and scope, I used it mostly as a reference work to learn some very advanced techniques. You can start producing animations as soon as the program is loaded since A WI is remarkably straightforward, and its interface is highly intuitive. Animation Works Interactive is an indispensable tool for anyone who wishes to produce professional-level presentations and productions under Windows 3.0 with Multimedia Extensions.

Sound Blaster, \$200 Sound Blaster Pro, \$300 Brown-Wagh Publishing 130-D Knowles Dr. Los Gatos, CA 95030 Tel.:408-378-3838 CIRCLE NO. 44 ON FREE INFORMATION CARD



Creative Labs' Sound Blaster, distributed through Brown-Wagh, is probably the best-known and most widely-used audio board for IBM/compatible PCs. As such, it's in a cat-bird seat when it comes to software support and compatibility. This is further evidenced by its MPC (Multimedia PC) compatibility and it's support in Microsoft's Multimedia Extensions 1.0.

While it's possible to add sound after all the video is already on tape, there are numerous instances where it's desirable to have the sound concurrent with the video action. Here's where the Sound Blaster comes in handy. In addition to providing an 11-voice FM music synthesizer that's fully AdLib compatible, SB also permits digitizing and playing back your own sounds (including voice narration). So it's especially useful for putting "sound bytes" in sync with computer animation and graphics. The advantage of combining sound and images together in the PC is that when you export to video tape, both audio and video are taken care of in a single pass.

The <sup>3</sup>/<sub>4</sub>-length SB card easily installs in any available eight-bit slot. A stereo patch cord is included for connection to a home stereo system. However, I recommend a pair of inexpensive Walkman-type speakers for convenient audio playback on a PC. A volume control is on the card's mounting bracket, though speakers aren't included. If you wish to record voice or do other sound sampling, you'll also have to provide a microphone, which doesn't come with the card.

Software setup is a breeze. An included test program checks the FM music and voice sampling circuitry to ensure that no interrupt or DMA conflicts are present on the system. An included "intelligent organ" program facilitates creating music with SB, and a good assortment of sample musical selections is provided.

An optional MIDI interface kit (\$79.95) allows you to generate sound via a MIDIcompatible keyboard or instrument. For most desktop-video applications, however, the internal 11-voice synthesizer should be quite adequate.

Brown-Wagh also has a number of optional support packages for the Sound Blaster, including *HSC Audio Tracks* (\$79.95), which is an assortment of music clips and sound effects that are very useful for adding sound without having to create or record your own.

*Musiclips* (\$149.95), a collection of more than 150 multi-track royalty-free MIDI song files for multimedia and desktop-video presentations, includes drivers that can integrate MIDI, FM and digitalaudio support into existing applications. One of the most useful features is that song files can be played concurrently from the DOS command line while other applications (like animations) are running, for combining sound and imagery.


*Recording Studio Professional* (\$199) is a professional-level editor for digitized sound samples. Its user interface is graphically-oriented with pull-down menus, windows and icons. The package is rich in features, including 3D frequency analysis, loop editors and tools with crossface, digital signal processing and assorted toolbox utilities. With this package it's easy to combine narration with a musical background, edit with cut-and-paste functions and add special effects via a digital equalizer with assignable center frequency.

If you're running *Windows* 3.0 with the Multimedia Extensions, you can also rec-

ord, edit (to a limited extent) and play back sound via the Extensions shell with a Sound Blaster. So some of the add-on packages listed above may not be necessary for your applications. If you're working from DOS, however, you'll want to obtain some of these add-ons to get the most from Sound Blaster.

Sound Master II, \$230 Covox Inc. 675 Conger St. Eugene, OR 97402 Tel.: 503-342-1271

**CIRCLE NO. 149 ON FREE INFORMATION CARD** 



Covox has been in the business of making audio-enhancement products for personal computers for over a decade and gives the most bang for your buck with Sound Master II. Lots of the accessory items that are optional with the Sound Blaster come standard with Sound Master II.

The <sup>3</sup>/<sub>4</sub>-length SM-II card installs easily in any available eight-bit slot. Like Sound Blaster, it contains an 11-voice FM synthesizer chip and a UART-standard MIDI interface. Unlike SB, however, Covox gives you everything but the kitchen sink.

A MIDI interface cable with a DB-9 connector on one end and dual five-pin DIN MIDI-IN and MIDI-OUT connectors at the other is supplied, as is a pair of good-quality desktop mini speakers with an adapter supplied. (The monophonic card's adapter routes the mono audio to both speakers). If you want to do voice digitizing or sound sampling, you must provide your own microphone (both low- and high- impedance jacks are on the card's mounting bracket).

Software, supplied in abundance, includes basic recording and playback utilities and a very advanced editor that has many of the same capabilities for sound as a good word processor has for text. Among these are cut-and-paste, block move, copy and more. Playback rates can be altered, echo/reverb effects added, etc.

An included excellent *PC Lyra* musiccomposition program is quite easy to use for creating music. Compositions created with it can be played back through the FM synthesizer or via an external MIDI instrument; so output flexibility is good.(See September 1991 *ComputerCraft* for more details on SM-II's MIDI capabilities.) The DMA-driven SM-II makes it possible to play back sound files while other applications are running. Covox provides a wealth of information on programming in its user manual. Implementing simultaneous sound with graphics or other applications is relatively easy from DOS. So producing multimedia works for export to video is possible.

According to the Microsoft Multimedia Extensions, the SM-II isn't MPC-compatible. Therefore, if you're working under *Windows* with the MPC Extensions you're out of luck. This is really a shame because *Windows* 3.1, which may be available by the time you read this, will include the Extensions as part of the basic package. Since the SM-II doesn't comply with these standards, the audio capabilities of the board will go untapped when *Windows* MPC applications are being run.

There have been unconfirmed reports that Covox is working on a stereo version of the SM-II that, hopefully, will be MPCcompliant. However, no official confirmation of this was available from the company. If you're working on DTV projects under DOS, the SM-II is an excellent product. If you're running *Windows* and MPCcompatibility is important to you now (or will be in the future), this board won't be the ideal choice.


### Summing Up

It isn't possible to cover all of the useful products available for desktop video, animation and multimedia, primarily because new ones are being released continually. In these two articles, I've limited discussion to products I've used extensively and of which I have personal knowledge regarding performance and application fitness for desktop video. The ones I've covered here and last month represent the cream of the crop.

Photos by Liz Benford



Tom Benford



# A Tower of an Enclosure Part 3


Installing a passive backplane and support cards and a dedicated power supply in the CYANCE enclosure extends your PC's bus by six expansion slots

c power users frequently run out of spare slots on the motherboard of their computers. If you find yourself in this condition and have more plug-in cards than you have expansion slots on your motherboard, the CYANCE Bus Expander system to be described is just what you need. By installing an eight-slot passive backplane system in the CYANCE enclosure that was the subject of Part 1 of this series, you can extend your computer's expansion bus by six slots. The two-slot penalty results from the fact that you must dedicate a slot on your motherboard and another on the backplane to interface cards for the Bus Expander.

With our Bus Expander, you have far more slots that are available on just your motherboard. Furthermore, these extra slots are fully isolated from the motherboard and have their own separate power supply. This takes takes the potential danger out of "proofing" untried hardware in your system, preventing possible damage to your main computing system.

One reason why you might want to extend the bus of your computer is to have more peripheral cards on-line simultaneously so that you can eliminate having to swap cards. If you're an experimenter who designs his own bus-oriented computer projects, you want to do so safely, without running the risk of trashing an expensive motherboard and any devices connected to it. If either, both or other considerations are important to you, you can connect our CYANCE Bus Expander to your present computer and solve such problems.

The basic CYANCE enclosure has



its own power supply (your choice of power) that handles any hardware you put into the expansion unit. The Bus Expander provides its own separate address, data and control-line buffers. This assures complete isolation between the PC's motherboard bus and any development project plugged into the Bus Expander.

The CYANCE Bus Expander consists of five pc cards: two controllers, two slaves and a passive backplane. One master and slave (the latter is a daughterboard to the first) and the bus card reside in the CYANCE enclosure. The other master/slave combination resides in a slot on the bus of the host PC's motherboard. Master/slave combinations each require one expansion slot on the PC's motherboard and CYANCE's passive backplane.


Be aware that the Bus Expander isn't a project for beginners. To build and use it, you should be experienced in electronic practices and familiar with computer hardware.


### Design Considerations


In theory, a computer bus expander simply consists of a couple of connectors and some ribbon cable. However, the demands of the PC bus make the reality much more complicated. As motherboard clock speed increases and more peripheral cards are plugged into the bus, control, address and data signals can become distorted and unusable. This is why the number of motherboard expansion slots has settled in at eight cards or less. Increasing this number, not to mention placing slots remotely from a motherboard, presents serious technical challenges that must be overcome.

In designing the Bus Expander, a few minor concessions were made to keep it relatively inexpensive and eliminate the need for specialized and expensive assembly tools. Going this route resulted in a system that doesn't have the "hot" performance required for, say, a 486 system running flat out at 50 MHz.

Though it lacks the extremely wide bandwidth required by the speediest of processors, the Bus Expander performs well at more reasonable speeds. So if you want to expand a hot-performance motherboard, simply keep the cards that require maximum performance on the motherboard itself and delegate cards that place lesser demands on bus performance in the Bus Expander's slots. This way, you get the best of both worlds.












Fig. 3. Schematic details of Master Control Card circuitry.

Cost-cutting design compromises were made in two areas. One was the decision to use ordinary double-sided printed-circuit boards and throughhole components, rather than multilayer boards and surface-mounted devices, both of which would have added greatly to system cost and the latter requiring specialized and expensive tools. The performance edge multilayer boards and surface-mounted devices would have added would not have been justified by the additional cost of building the system.

The other area of compromise was use of ribbon cables to interconnect the two systems. Better performance would have been achieved by using shielded round cables and connectors for this purpose, but it would have done so at a dramatic boost in the cost of building the system.

By carefully selecting components and limiting cable lengths to less than 5 feet, the CYANCE Bus Expander should more than meet any expansion need that doesn't require the full bandwidth of the motherboard's bus, even with the compromises mentioned. With the CYANCE Bus Expander built according to the procedure described here, you'll have a safe platform for "proofing" untried hardware designs and a means to accommodate more hardware than the slots in your PC can support.

### **Circuit Operation**

The pinout of the CYANCE Bus shown in Fig. 1 is the same as that for the PC bus (left). Take some time to examine the layout of the CYANCE Bus Card (right) with regard to the various card slots and power connector to familiarize yourself with the system and know your way around.

Figure 2 graphically shows the elements of the basic CYANCE Bus Expander system. As you can see, one motherboard slot must be dedicated to the Master Control Card that buffers and conditions the various bus control signals and routes them through the 40-conductor control cable to its companion Slave Control Card. Mounted on the Master Control Card, in daughterboard fashion, is a Data Master Card that buffers and conditions the address and data lines on the PC bus. The Data Cable connects the Data Master Card to the Data Slave Card.

On the bus of the CYANCE Bus Expander, one slot is used up by the Slave Control Card and its daughterboard Data Slave Card. Choice of a plug-in daughterboard and passive backplane scheme, rather than a one in which the CYANCE Bus Card contains the slave components, is better because it lets you make changes to the basic circuitry or expand the system to 16 bits.

As control, address and data signals are buffered and routed between the two buses, propagation delays are introduced by the buffer ICs and ribbon cable. By carefully selecting the logic family for the buffers and keeping the ribbon cables as short as possible, you can minimize these delays. Furthermore, special consideration must be given to the extra capacitance that comes with the relatively long interconnect cables and peripheral cards. • Control Cards. The PC Bus connector, shown in the center of the Master Control Card circuit in Fig. 3, uses a 62-contact edge connector with 31 each "A" and "B" contacts in the Fig. 1 pinout arrangement. The control cards use only the "B" side that routes most of the bus signals.

To keep construction as simple as possible, the same pc design is used for the Master and Slave Control Cards. The Master Control Card sits on the host PC bus, the Slave Control Card sits remotely on the CYANCE Bus Card and is controlled by the "Master" unit.

By connecting the adjacent pins of each 74S240 buffer, you can control the direction of the buffered signals using pins 1 and 19. When pin 1 is tied to ground and pin 19 to Vcc, signals at pins 2, 4, 6 and 8 are routed across the device to pins 18, 16, 14 and 12 to produce a bus "driver." Similarly, grounding pin 19 and tying pin 1 to Vcc, signals on pins 17, 15, 13 and 11 are routed through the device to pins 3, 5, 7 and 9 to create a bus "receiver" that conditions signals received on the interconnect cable.

All control signals on the PC bus must be conditioned and sent to the CYANCE Bus, which receives and conditions them. By configuring the voltages applied to pins 1 and 19 of the 74S240 buffers, both functions can be performed with one card.

In the Fig. 3 Master Control Card circuitry, the buffers located on the right send PC bus signals to the CYANCE Bus. Similarly, the buffers on the left condition signals received from the CYANCE Bus and apply them to the PC bus.

In the Fig. 4 Slave Control Card circuitry, the situation is reversed. Signals on the right are received from the Master Control Card and are conditioned and applied to the CYANCE Bus. On the right, the buffers send the CYANCE Bus signals back to the PC bus, while on the left, these signals are transmitted back to the Master Control Card.

Trace these signals using Fig. 1 through Fig. 4 until you completely understand the data flow. This will be important when you build and test your Bus Expander.

In studying Fig. 3 and Fig. 4, several "damping" resistors in series with the buffer output lines reduce the effects of under-shot signals. On the conditioning (receiving) side, these resistors are replaced with jumper wires. Hence, the difference between the Master and Slave Control Cards is determined by whether each has resistors or jumpers installed in the corresponding positions.

• Data Cards. In Fig. 5 and Fig. 6 are shown the schematic details of the circuitry on the Data Master and Data Slave Cards. In the Fig. 5 Data Master Card circuit, the PC bus connector is shown as an outline in the center. Recall that side "B" of the PC bus connector is composed primarily of control signals. Side "A" contains the address and data signals and a few control-line signals.




Fig. 4. Schematic details of Slave Control Card circuitry.

### Earn Your B.S. Degree in ELECTRONICS or COMPUTERS



### By Studying at Home

Grantham College of Engineering, now in our 42nd year, is highly experienced in "distance education" teaching by correspondence—through printed materials, computer materials, fax, and phone.

No commuting to class. Study at your own pace, while continuing on your present job. Learn from easy-tounderstand but complete and thorough lesson materials, with additional help from our instructors.

Our Computer B.S. Degree Program includes courses in BASIC, PASCAL and C languages — as well as Assembly Language, MS DOS, CADD, Robotics, and much more.

Our Electronics B.S. Degree Program includes courses in Solid-State Circuit Analysis and Design, Control Systems, Analog/Digital Communications, Microwave Engr, and much more.

An important part of being prepared to move up is holding the right college degree, and the absolutely necessary part is knowing your field. Grantham can help you both ways to learn more and to earn your degree in the process.

Write or phone for our free catalog. Toll free, 1-800-955-2527, or see mailing address below.

Accredited by the Accrediting Commission of the National Home Study Council

GRANTHAM College of Engineering Grantham College Road Slidell, LA 70460

### PARTS LIST

### **Master Control Card**

Semiconductors U1 thru U6—74S240 buffer

Capacitors

C1 thru C7—10- $\mu$ F, 16-volt electrolytic

Resistors (¼-watt, 5% tolerance) R1 thru R13—100 ohms

### Miscellaneous

P1-40 pin DIP IC socket

P2—36-pin male single-row connector Printed-circuit board; IC sockets (see text); solder; etc.

### **Slave Control Card**

Semiconductors U1 thru U6—74S240 buffer Capacitors C1 thru C7—10-μF, 16-volt electrolytic Resistors (¼-watt, 5% tolerance) R1 thru R9—100 ohms Miscellaneous

P1-40 pin DIP IC socket

P2—36-pin male single-row connector Printed-circuit board; IC sockets (see text); solder; etc.

#### Data Master Card Semiconductors

U1,U2,U3,U6—74S240 buffer U4,U5—74S38 quad two-input NAND gate with open collectors U7—74S00 quad two-input NAND gate D1,D2—1N4148 switching diode **Capacitors** C1 thru C6—10-μF, 16-volt electrolytic **Resistors** (¼-watt, 5% tolerance)

R1 thru R20, R22 thru R29–100 ohms

R21-2,200-ohm SIP pack

Miscellaneous

- P1-40-pin DIP IC socket
- P2-36-pin female single-row connector Printed-circuit board; IC sockets (see text); solder; etc.

#### Data Slave Card Semiconductors U1,U2,U3,U6—74S240 buffer U4,U5—74S38 quad two-input NAND gate with open collectors U7—74S00 quad two-input NAND gate Capacitors C1 thru C6—10-μF, 16-volt electrolytic Resistors (¼-watt, 5% tolerance) R1 thru R8—100 ohms

R10—470 ohms

R9—470-ohm SIP resistor pack

Miscellaneous

P1-40-pin DIP IC socket

P2—36-pin female single-row connector Printed-circuit board; IC sockets (see text); solder; etc.

### **Bus Card**

### Capacitors

- C1 thru C28—10- $\mu$ F, 16-volt electrolytic with radial leads
- C29—47- $\mu$ F, 16-volt electrolytic with radial leads
- C30—1- $\mu$ F, 16-volt electrolytic with radial leads
- C31 thru C37—10-µF, 16 volt electrolytic with axial leads

### Miscellaneous

P1 thru P8—62-pin card edge connector with contacts on 0.100" centers

P9-12-pin male PC power connector Printed-circuit board; solder; etc.

Note: The following items are available from U.S. Cyberlab, Inc., Rte. 2, Box 284, Cyber Rd., West Fork, AR 72774 (tel.: 1-501-839-8293 or 1-800-232-9865 voice only): All five double-sided pc-board kit with holes not plated-through, \$79.95; complete CYANCE Bus Expander electronic kit, including pc boards, \$169.95. Add \$4.95 P&H. Akansas residents, please add 6% sales tax. MasterCard and Visa welcome.

As before, Master and Slave depend on which unit sits on the PC's motherboard bus and which sits on the CYANCE Bus. Address buffers U1, U2 and U3 buffer the address signals present on the PC motherboard's bus. Because these signals drive the 40-conductor DATA cable, damping resistors are again used.

In Fig. 6, the buffers are reversed and the resistors are replaced with wire jumpers. The buffers now condition the received signals coming from the Data Master Card and apply the reconstructed address signals to the CYANCE Bus.

At the right in Fig. 5, inverter/buf-

fers and NAND gates U4, U5 and U6 are the heart of the data encoding and decoding circuitry. To share the data on the PC bus, the flow of data on the CYANCE Bus must be carefully controlled to and from the PC bus. This is accomplished by splitting the transmit and receive data path into 16 individual lines.

In Fig. 5, the data transmit lines come from the buffers at the right and have damping resistors in series with them. Just below each data-transmit line is the data-receive line that feeds one input of the NAND gate. If data signals are being sent from the PC bus to the CYANCE Bus, as in Fig. 5, for




Fig. 5. Schematic details of Data Master Card circuitry.




Fig. 6. Schematic details of Data Slave Card circuitry.

Say You Saw It In ComputerCraft

example, the data is simply buffered and placed directly on the interconnect cable. Likewise, in Fig. 6, the Data Slave Card directly buffers the returning data of the CYANCE Bus.

The critical part of the arrangement comes when you wish to place the transmitted data on either of the two buses. This data transfer must be carefully controlled to keep the computer from "crashing." Quad two-input NAND gate U7 accepts two inputs from the bus. On the Data Master Card, these are the MEMR and IOR control lines, while on the Data Slave Card, they become the MEMW and



IOW lines. Pin 8 of U7 is used to enable open-collector quad two-input NAND gates U5 and U6.

Every time the PC bus processor wants to receive data from the bus, it enables U5 and U6 on the Data Master Card. By virtue of their open-collector wired-OR design, U5 and U6 place data received from the CYANCE Bus directly on the PC bus. Likewise, when data is sent to the Data Slave Card, U5 and U6 place data from the PC bus directly on the CYANCE Bus. Because U5 and U6 place open-collector devices, R21 provides the required pull-up source current across the CYANCE Bus data lines.

In addition to the address and data lines, the Data Master and Slave Cards transmit and receive the AEN control signal and I/O CHANNEL CHECK and I/O CHANNEL READY lines. Diodes *D1* and *D2* on the Data Master Card allow pull-down-only operation of the outputs of *U3*.

• Bus Card. The CYANCE Bus Card is passive owing to the fact that it contains no active components. The artwork you can use to make the pc board for it is laid out so that it can be either single- or double-sided. Several  $10-\mu F$ capacitors placed across the card serve as "energy wells" and reduce switching noise on the + 5-, + 12-, -5- and - 12-volt power lines.

There's also a place for eight capacitors at the termination end of the data bus at contacts A2 through A9. These capacitors, usually in the value range of 100 to 1,000 pF, may or may not be needed, depending on cable type and length and your arrangement of peripheral cards. Power for the CYANCE Bus is supplied by an independent power supply, preferably at least a 200-watt unit.

Next month, we'll finish up with construction, system checkout and installation of the Bus Expander in the CYANCE enclosure.



Nick Goss

# **COMPUTER SHOW** SCHEDULE

### WHOLESALE PRICES - OPEN TO THE PUBLIC SAVE \$1.00 OFF ADMISSION WITH THIS AD!

- EDISON, NJ RARITAN CENTER EXPO FEB. 15-16 Sat. 10-5 1,000 Tables - 100,000 Sq. Ft. of Space Sun. 10-4 NJ Turnpike Exit #10 - Bigger than Trenton
- FEB. 22 WOBURN, MA - North of Boston-800 Tables Sat. 10-5 Full Hall-800 Tables - Off I-95 EXIT #35

MAR. 14 FAIRFAX, VA - PATRIOT CENTER-Nr DC Sat. 10-4 Off I-495 - 250 Tables - Geo, Mason Univ

MAR. 15 VALLEY FORGE, PA - CONVENTION Ctr. Sun. 10-3 Philadephia Area - PA Tpke. - 400 Tables

**MAR. 21** ASPEN MANOR - PARSIPPANY, NJ Sat. 10 to 4 Rte. 46 West = Near I-80 - 400 Tables

APR. 4 BOXBOROUGH, MA - Boxborough Hotel Sat. 10 to 3 I-495 Exit #28 at Rte. 111- 250 Tables

## **KGP PRODUCTIONS, INC.** (800) 631-0062

**CIRCLE NO. 67 ON FREE INFORMATION CARD** 

## Cross-Assemblers from \$50.00

## Simulators from \$100.00 Cross-Disassemblers from \$100.00 Developer Packages from \$200.00(a \$50.00 Savings)

#### Make Programming Easy

Our Macro Cross-assemblers are easy to use. With powerful conditional assembly and unlimited include files.

#### Get It Debugged--FAST

Don't wait until the hardware is finished. Debug your software with our Simulators.

#### **Recover Lost Source!**

Our line of disassemblers can help you re-create the original assembly language source.

#### Thousands Of Satisfied Customers Worldwide

PseudoCorp has been providing quality solutions for microprocessor problems since 1985.

#### Processors 4 1802.05

Intel 8048 Motorola 6800 Hitachi 6301 Rockwell 65C02 Hitachi HD64180 All products	RCA 1802,05 Motorola 6801 Motorola 6809 Intel 8080,85 Mot. 68k,8,10 require an IBM Po


Intel 8051 Intel 8096,196kc Motorola 68HC11 Motorola 6805 MOS Tech 6502 WDC 65C02 Zilog Z80 NSC 800 Zilog Z8 Zilog Super 8 68k,8,10 Zilog Z8 an IBM PC or compatible.



# PC-BASED DEVELOPMENT TOOLS

If you're interested in microprocessor-related projects, our tools can help. Our PIC microcontroller tools allow you to learn about and use single-chip computers. And our EPROM emulators are time-savers in almost any project that uses EPROMs.

## MICROCONTROLLER PROGRAMMER



The PIC®16C5x family of microcontrollers are inexpensive. 8-bit, single-chip computers. They combine a CPU, EPROM. RAM, and I/O for as little as \$3.00 each. Our tools allow you to program these parts with your own software. A single PIC can replace many ICs, in addition to adding real intelligence and flexibility to your designs.

Includes assembler, programmer, and cables. PIC is a registered trademark of Microchip Technology. Inc.

5199

## 27256 EPROM EMULATOR

PAPAL AX2	82,322=8 SRAH	erser mennen ter
6		
1158+18(PiQ)		
	6 D D	
feeiQ = arr	20 10 0 10 10	
ROMEMULATO	C 0.00	

If your projects use EPROMs, you can probably use an EPROM emulator. An EPROM emulator plugs in place of an actual EPROM, but instead of programming parts to test your code, you simply download to the emulator.

Emulates 2764, 27128, and 27256 EPROMs.





(916) 721-8217 · FAX: (916) 726-1905 Parallax, Inc. - 6200 Desimone Lane, #69A - Citrus Heights, €A 95621

rices subject to change without notice. California, residents add appropriate sales tax Add \$4.00 for UPS ground, \$7.00 for 2nd day, \$15.00 for next day.

**CIRCLE NO. 77 ON FREE INFORMATION CARD** 


# Experimenting With Motorola's 68HC11 True Single-Chip Computer Part 4

Building a board to supply battery power, installing the monitor program, programming MAG-11's EEPROM and experimenting with the 68HC11 in Special Bootstrap/Modified Single-Chip mode

T his time around, we have basically two focuses: operation, construction and use of a Battery Board for the MAG-11 single-board computer and the BUFFALO monitor program that makes it possible for you to use the MAG-11 Single-Board Computer for a wide range of applications.

Though the MAG-11BAT Battery Board is basically a convenient platform for supplying battery power to MAG-11, optional circuitry can be included to provide low-battery indication and an eight-channel Logic Monitor. The latter is useful as a diagnostic/instructional aid for the MAG-11 and expansion boards and for analyzing other projects. It's completely independent and plays no role in the operation of the SBC, but it is a low-cost option you might want to include if you ever have to troubleshoot the SBC or other digital circuits.

The BUFFALO (Bit User Fast Friendly Aid to Logical Operation) monitor program, available for just the cost of the call to Motorola's Freeware BBS and the time it takes to download it, is remarkably sophisticated. If you don't have the facilities to access the BBS and download files or prefer not to program your own EPROMs, you can obtain the BUF-FALO monitor already programmed into a 27C256 EPROM for a small fee



from the source given in the Note at the end of the Parts List. Also available from this source is a diskette that contains all the software for the first four parts of this series and the source code for the BUFFALO monitor and the file in Motorola S format.

### About the Circuit

The MAG-11 single-board computer that was the subject of Parts 1 through 3 can be powered by a single 9-volt battery and uses a separate battery for memory back-up, in addition to the back-up provided by an on-board 0.1-Farad super-capacitor. Powering MAG-11 from batteries is optional, but it's a great convenience because it lets you use the SBC anywhere you happen to be, whether or not ac power is available. If you don't need such convenience, you can use just an acline-powered source that outputs filtered but unregulated 9 to 12 volts dc.

MAG-11 has its own UPS (uninter-




Fig. 7. Complete schematic diagram of optional battery-powering circuit for MAG- 11 SBC. This portion of the MAG-11BAT board offers a number of choices for battery-powering the system.

ruptible power source) and batterybacked memory system in addition to the built-in super-capacitor. The simple circuitry for the UPS is on the MAG-11 board, while the power source for the UPS (a 7.2-to-7.8-volt Ni-Cd battery is on the MAG-11BAT board) is identified as BI in Fig. 7. Battery B2 consists of three  $\frac{1}{3}$ -AA Ni-Cd cells located on the MAG-11BAT board and provides memory back-up for MAG-11.

Circuitry on-board MAG-11BAT provides separate visual low-battery alert for BI and B2 via light-emitting diodes. The Fig. 7 circuit is a bit unusual because it has the capability of being powered by three distinct energy sources: ac line, BI and B2. In normal operation, the ac line or BI is the primary energy source. However, the system is still functional if B2 or either of the other two energy sources is operating at more than about 50% of rated capacity. So, just about every power source has to give up the ghost for the low-battery alert circuit to fail.

MAG-11BAT's optional eightchannel Logic Monitor is shown schematically in Fig. 8. Channel 1 has a pulse-extender circuit that lets you view extremely short-duration pulses. This Logic Monitor has numerous applications. It can serve as an additional bank of LEDs for display purposes, an instructional aid for MAG-11 and expansion boards, a diagnostic tool for expansion boards and even MAG-11 itself, etc. If you don't wish to include this handy circuit, simply omit *U1, U2* and associated components.

Getting back to the battery-powering system in Fig. 7, *B1* can be either a 9-volt alkaline or a 7.2-volt (sometimes specified as 7.8-volt) Ni-Cd rechargeable type. If you use an alkaline battery, jumper pins 2 and 3 of *JP2*, and omit the jumper on *JP8* on the MAG-11 SBC board.

If you use an Ni-Cd battery, put a jumper on JP8 and jumper pins 1 and 2 of JP2. If you use only battery power to run MAG-11 for short periods of time, select an alkaline battery for B1. Finally, if you plan on powering MAG-11 from the ac line, use an Ni-Cd battery if you wish the security of UPS service.

Potentiometer R2 on the MAG-11 board sets the charging rate for B1.

The three cells that make up B2 provide about 3.8 volts when fully charged. Charging rate for B2 is set with R10 on MAG-11. Power is applied to and removed from MAG-11 by S4 in Fig. 7. You need this switch if you operate MAG-11 solely on battery; otherwise, it's optional.

The low-battery indicator circuit consists of operational amplifiers U21A and U21C. Because these circuits are similar to each other, we'll examine only the one that turns on LED17 when the voltage from B2 is low enough to trigger it.

Notice that U21 and U22 are powered by both the +5-volt regulated source and B2. This permits the circuit to function even if the primary power supply is dead or missing, as long as B2 has some charge left. A 2.5-volt reference source is provided by U22. While U21 will operate down to 2.7 volts, the voltage-reference circuit starts to lose accuracy at about 3 volts. However, because the rate of change in the reference circuit is still less than the rate of change of V<sub>B</sub>, the circuit operates okay down to 2.7 volts.

The 2.5-volt reference is applied to

#### PARTS LIST

#### Semiconductors

- D5 thru D20—1N914 or similar silicon switching diode
- D21,D23-1N4001 rectifier diode
- D22—1N5817 Schottky barrier diode
- LED12 thru LED19,LED28,LED29— Low-power, high-efficiency T-1 red light-emitting diode
- LED20 thru LED27—low-power, highefficiency T-1 green light-emitting diode
- U19,U20—74HC245 octal tri-state transceiver
- U21—LM324 quad operational amplifier
- U22—LM336-2.5 2.5-volt voltage reference

#### Capacitors

- C33,C34-1,500-pF, 25-volt ceramic
- C35-0.1-µF, 25-volt monolithic ceramic
- C36—10-µF, 20-volt electrolytic
- Resistors (1/-watt, 5% tolerance)
- R20, R22, R24-10,000 ohms
- R21,R26-100,000 ohms
- R23, R25, R29-1,000 ohms
- R27—118,000 ohms, 1% tolerance R19—50,000-ohm miniature pc-mount trimmer potentiometer
- R28—100,000-ohm miniature pc-mount trimmer potentiometer
- RN6-820,000-ohm × nine-element SIP resistor network
- RN7—1-megohm × nine-element SIP resistor network
- RN8, RN9-1,000-ohm × nine-element SIP resistor network

#### Miscellaneous

- B1—9-volt alkaline or 7.2- to 7.8-volt nickel-cadmium battery
- B2—Three ½-AA nickel-cadmium cells with solder tabs (Digi-Key Cat. No. P109 or similar)
- J7—Nine-position female socket with contacts on 0.1" centers (Digi-Key Cat. No. 929974-01-10 or similar)

- JP14 thru JP19—Two-post jumper header with posts on 0.1" centers
- JP20-12-post jumper header with posts on 0.1" centers (Digi-Key Cat. No. 929836-01-36 or similar)
- P1,P2—20-post, two-row plug with contacts on 0.1" centers (Digi-Key Cat. No. 929720-03-36 or similar)
- S4—Miniature spst pc-mount pushbutton switch (Digi-Key Cat. No. SW100-ND or similar)
- Printed-circuit board (see text); sockets for DIP ICs; shorting jumpers JP14 thru JP19; holder for B1 Digi-Key Cat. No. BH9V-PC-ND or similar); machine hardware for B2 (see text); solder; etc.
- Note: Parts and software for the MAG-11 SBC are available from Magicland, 4380 S. Gordon Ave., Fremont, MI 49412. Hardware include: the double-sided MAG-11 pc board with plated-through holes and component-mounting overlay (No. MAG-11BD), \$25; set of all ICs that are not optional, including the MC68HC11A1P, 27C256 EPROM with your choice of MAG-11DIAG or BUFFALO monitor firmware, thermistor and precision resistor, and MAG-11 software on 31/2" or 51/4" PCcompatible diskette, but not including U9 and U10 (No. MAG-11CDK), \$49.50. Price for both pc board and IC kit when ordered at the same time is \$69. Available separately are: 68HC11, \$25; 27C256 EPROM programmed with either MAG-11DIAG firmware (No. MAG-11DIAG/E-256) or BUF-FALO monitor (No. BUFFALO/E-256), \$12: PC-compatible disk loaded with software for MAG-11 on 5¼" disk (No. 6811-ME-5), \$7.50 or 31/2" disk (No. 6811ME-3), \$10. Prices are in U.S. funds only. For shipment to Canada, add \$5 and to all other countries via air add \$10. Michigan residents, add 4% state sales tax. For a complete list of the parts needed for MAG-11 SBC, see Parts 2 and 3 of this series in the February and March issues.

noninverting input pin 3 of U21, and a sampling of B2's voltage is applied to inverting input pin 2. You use R19 to adjust pin 2's potential to 2.5 volts when B2's potential drops to some low value like 3 volts. Below 3 volts, pin 1 of U21 goes high, causing LED28 to light if JP14 is jumpered. The circuit is isolated from the C17 super-capacitor circuit on MAG-11 by jumpering JP15 to isolate it from the super-capacitor to prevent needless discharge.

The remaining jumper blocks serve the following purposes:

JP16—logic-monitor power

JP17—memory backup power to the MAG-11 SBC

JP18 - +5 volts to the entire MAG-11BAT board

JP19—storage for shorting jumpers that aren't being used.

Diode D23 allows B2 to be continually charged even if no jumper is placed on JP17.

The Fig. 8 Logic Monitor circuit consists of 74HC245 octal bus transceivers U19 and U20, which have tristate outputs. An off state isn't needed; so enable input pin 19 is grounded on both ICs. With U19, direction control pin 1 is grounded. Thus, pins 11 through 18 (B bus) function as inputs and pins 2 through 9 (A bus) are outputs. Pin 1 of U20 is at +5 volts, which reverses the direction of flow. Resistor network RN6 contains a bank of 820,000ohm pull-down resistors, and resistor network RN7 contains 1-megohm pull-up resistors.

If diodes D5 through D20 weren't used, the inputs of the bus transceiver would see about 2.25 volts when the inputs to the Logic Monitor are left floating (2.25 volts is typical switchover for high-speed CMOS—or HC logic). Operation at this voltage causes the ICs to draw excessive current.

The forward drop across D5 through D12 causes pins 11 through 18 of U19 to be at about 0.5 volt less than 2.25 volts, and the drop across D13 through D20 causes the potential at pins 2 through 9 of U20 to be about 0.5 volt greater than 2.25 volts. The result is that even when the Logic Monitor pins are left floating, the voltage at the inputs to U19 and U20 isn't close enough to the switch-over point to cause excessive supply current drain.

Another advantage of using the diodes is that short pulses become visible on the LEDs since the extremely high reverse impedance of the diodes allows only the charge stored in the circuit's stray capacitance to discharge through the resistor networks. Capacitors C33 and C34 permit detection of very short-duration pulses when Logic Monitor input line 1 is used.

Notice the large-value current limiting resistors used for the LEDs. Highefficiency devices are recommended for all LEDs, which can be used with forward currents of as little as 1 mA, although 2 to 4 mA is more typical.

#### Construction

Printed-circuit construction is recommended for this project. You can make your own board from the actualsize artwork given in Fig. 9. To keep things simple, the artwork is designed to yield a single-sided pc board. Consequently, you'll have to install 15 jumper wires, as detailed later, after all components are mounted and soldered into place to get it working properly when you mate it with the MAG-11 SBC board.




Fig. 8. Complete schematic diagram of optional eight-channel Logic Monitor for the MAG-11BAT board. It plays no role in operation of the SBC but does provide a convenient means for troubleshooting its circuitry and other digital systems.

Refer to Fig. 10 for component location and orientation details for populating the board. Use sockets for U19, U20 and U21. If you don't now need the Logic Monitor circuit and would like to save a few dollars in component cost, omit all the components shown in Fig. 8.

Install P1 and P2 on the solder side of the board, leaving enough metal pin length exposed between the plastic insulating tie strip and board to provide soldering access. Though just about any size 20-pin headers with pins spaced on 0.1 " centers can be used for P1 and P2, it's best to use headers that have long pins on both sides of the insulating tie strip to make it easier to solder them.

The three  $\frac{1}{3}$ -AA cells that make up B2 have solder tabs. Use 2-56 or smaller machine hardware to secure the solder tabs to the board. If you use 2-56 screws, you'll have to enlarge the holes in the tabs to accommodate them. If necessary to make a good connection, solder the screws to the copper foil on the board.

#### Tests & Adjustments

Install fully charged Ni-Cd batteries *B1* and *B2*. Configure the jumpers on MAG-11 for installed Ni-Cd batteries. Then install all shorting jumpers on MAG-11BAT. Set *R2* and *R10* on MAG-11 to center of rotation. Line up *P1* and *P2* on MAG-11BAT with *J1* and *J2*, respectively, on MAG-11, and carefully push them together, as illustrated in Fig. 11.

Apply 9 volts dc to SOI on MAG-11. Wait about 30 minutes for the charging currents to stabilize. Then use a DMM set to the dc volts function to measure the potential dropped across R7 on MAG-11. If don't obtain a reading close to  $200 \text{ mV} (\pm 100 \text{ mV})$ , adjust R10 on MAG-11 to get it. Access to R10 is through a hole drilled in the indicated location in the MAG-11BAT board.

If the measured drop across RI isn't close to 150 mV, adjust R2 as needed. It isn't possible to adjust R2 with a standard screwdriver because MAG-11BAT obstructs it; so use either your fingers or longnose pliers.

For preliminary adjustment of the low-battery alert circuit, connect the common lead of your meter, set to measure 20 volts dc, to ground. Touch the "hot" probe to pin 2 of U21 and adjust R19 for a reading of + 3 volts. Move the "hot" probe to pin 9 and adjust R28 for reading of + 3 volts.

At this point, *LED28* and *LED29* shouldn't be lit. Removing *B1* should cause *LED29* to light. Removing *B2* should cause both LEDs to light, assuming an external 9-volt source is connected to MAG-11. Replace *B1* and *B2*. Now *LED12* through *LED27* should be off.

Plug one end of a short No. 22 or 24 solid hookup wire into ground pin 9 of J8 and the other end successively into the sockets at pins 1 through 8 of J1. Green LED20 through LED27 should light as you proceed to ground pins 1 through 8, respectively, with the wire.

Solder one lead of a 10,000-ohm resistor to one end of a solid No. 24 hookup wire and temporarily connect the free resistor lead to a source of +5volts on the board (use a small alligator clip or tack-solder the lead). As before, plug the free end of the wire into pins 1 through 9 of J8 and note if *LED12* through *LED19* light.

If you experience any difficulty during this phase of testing, power down the system and correct the problem before proceeding.

Six functional jumper blocks are on MAG-11BAT, some or all of which can be replaced with permanent jumper wires. Use them to configure the board according to your needs. A hard-wired, soldered jumper can replace some or all (not recommended) jumper blocks. From Fig. 7, it's obvious that installation of a shorting jumper at the indicated jumper block activates/powers the respective system. Here's a list of the jumper-block functions with jumpers installed:

JP13-activates Low B1 LED29.

JP14—activates Low B2 LED28. JP15—allows B2 to supply power to U21 when all other power sources are missing or dead. Install JP15 only if B2 is installed; otherwise, installation will discharge MAG-11's C17 super-capacitor.

JP16-activates Logic Monitor.

JP17-activates MAG-11's memory battery back-up.

JP18—activates + 5-volt supply to MAG-11BAT.

The Logic Monitor on MAG-11BAT lets you visually detect pulses as short as several microseconds in duration. Because of the added capacitors, line 1 (connected to pin 1 of J3) is most sensitive to narrow pulses.




Fig. 9. Actual-size etching-and-drilling guides for MAG-11BAT's double-sided printed-circuit board.

If you use the Logic Monitor with any digital project powered by 5 volts dc, make sure to connect pin 9 of *J1* to ground in the circuit under test to activate it.


#### The **BUFFALO** Monitor

This monitor is very sophisticated, as evidenced by its more than 85-page source listing (BUF34.ASM). The S19 listing is about as long as BASIC-11's S19 listing!

You must make several minor changes to MAG-11 to be able to use the BUFFALO monitor. First, install a MAX232 RS-232 driver in the U3 socket. Then replace U7 with an EPROM that has the BUFFALO firmware programmed into it. Make sure pins 1 and 2 of JP4 and pins 2 and 3 of JP12 are jumpered. If you program the EPROM yourself, keep in mind that the addresses in the MOT S file seldom correspond to the actual address in an EPROM, especially for EPROMs used with Motorola's chips.

With the BUFFALO monitor, the starting address is \$E000 when obtained directly from the Freeware BBS. Addresses coincide exactly for 27C512 EPROMs. With 27C256 EPROMs, \$E000 corresponds to \$6000 in the EPROM, \$F000 in the Sfile to \$7000. With 27128 EPROMs, \$E000 corresponds to \$2000 in the EPROM and \$F000 to \$3000. As you can see, address translation is required. It can be done directly to the .S19 file or more painlessly and invisibly by most EPROM burners.

You must use a 4-MHz crystal to communicate at exactly 4,800 baud.



Set position 1 of DIP switch S2 to ON to ground pin 17 of U1. When pin 17 of U1 is high, Version 3.4 of the BUF-FALO monitor jumps to address \$B600, the first address of the internal EEPROM.

To make use of the BUFFALO monitor, you need a terminal or a

ASM [ <addr>] Line asm/disasm</addr>		
[/,=] Same addr, [^,-] Prev addr, [+,CTLJ] Next addr		
[CR] Next opcode, [CTLA,.] Quit		
BF <addr1> <addr2> [<data>] Block fill memory</data></addr2></addr1>		
BR [-][ <addr>] Set up bkpt table</addr>		
BULK Erase EEPROM, BULKALL Erase EEPROM and CONFIG		
CALL [ <addr>] Call subroutine</addr>		
GO [ <addr>] Execute code at addr, PROCEED Continue execution</addr>		
EEMOD [ <addr [<addr="">]] Modify EEPROM range</addr>		
LOAD, VERIFY [T] <host command="" dwnld=""> Load or verify S-records</host>		
MD [ <addr1> [<addr2>]] Memory dump</addr2></addr1>		
MM [ <addr>] or [<addr>]/ Memory Modify</addr></addr>		
[/,=] Same addr, [^,-,CTLH] Prev addr, [+,CTLJ,SPACE] Next addr		
<pre><addr>0 Compute offset, [CR] Quit</addr></pre>		
MOVE <s1> <s2> [<d>] Block move</d></s2></s1>		
OFFSET [-] < arg> Offset for download		
RM [P,Y,X,A,B,C,S] Register modify		
STOPAT <addr> Trace until addr</addr>		
T [ <n>] Trace n instructions</n>		
TM Transparent mode (CTLA = exit, CTLB = send brk)		
[CTLW] Wait, [CTLX,DEL] Abort [CR] Repeat last cmd		
This printout is exactly what comes out of the BUFFALO monitor in the EEPROM		
In spinitour sexacity what comes out of the bor FALO monitor in the EEP ROM		

#### **Prairie Digital, Inc.** PC DATA ACQUISITION SYSTEM - \$79 INCLUDES SOFTWARE ON 5.25" FLOPPY MODEL 30-FOR 386'S, XT'S, AT'S, PS2 MODEL 25 & 30'S. FEATURES: 24 LINES OF PROGRAMMABLE INPUT/OUTPUT \* 8 BIT ANALOG TO DIGITAL CONVERTER 8 CHANNEL ANALOG MULTIPLEXOR 12 BIT CMOS COUNTER \* PC BUS CARD ELIMINATES USING THE SLOW + RS232 PORT EASY INTERFACE TO ALL POPULAR LANGUAGES HIGH QUALITY PCB AND COMPONENTS A/D CHANNELS SELECTED BY SOFTWARE \* OPTIONAL 7 CHANNEL 50V DRIVER AVAILABLE FOR ADDITIONAL \$5 APPLICATIONS: ★ CONTROL RELAYS, LIGHTS & MOTORS \* MEASURE TEMPERATURE, PRESSURE, LIGHT LEVELS, & HUMIDITY INPUT SWITCH POSITIONS, THERMOSTATS, & LIQUID LEVELS GREATFOR ROBOTICS, SERVO CONTROL LOOPS **MODEL 150 TRUE RMS** DMM W/RS232 PORT - \$149 INCLUDES RS232 PC CABLE AND SOFTWARE ON 5.25" FLOPPY LARGE 3 3/4 DIGIT DISPLAY (3.999 VS. 1.999 FOR 3 1/2 DIGIT METERS) RS232 SERIAL INTERFACE COMMUNICATES WITH COMPUTERS AND PRINTERS MEASURES AC-DC VOLTAGE AND CURRENT, FREQUENCY, RESISTANCE 20 AMP CURRENT RANGE, 30 Hz TO 40 KHz \* FREQUENCY RANGE DIODE TEST AND AUDIBLE CONTINUITY AUTO-RANGING SELECTION CAN BE DEFEATED USING RANGE BUTTON TRUE RMS READING ELIMINATES ERRORS DUE TO NON-SINUSOIDAL SIGNALS DATA HOLD, MAX/MIN, AND RELATIVE READING MODES WITH INDICATORS ANALOG BAR GRAPH DISPLAY - UPDATES AT 5X THE RATE OF DIGITAL DISPLAY OVERALL SIZE 6.4 x 3.1 x 1.2 INCLUDES 9V BATTERY AND TEST LEADS SEND CHECK, MO, VISA, MC **INCLUDE \$5 FOR SHIPPING & HANDLING**

Prairie Digital, Inc. 846 Seventeenth Street Prairie du Sac, Wisconsin 53578 U.S.A. Tel/Fax: (608) 643-8599

CIRCLE NO. 78 ON FREE INFORMATION CARD April 1992 / COMPUTERCRAFT / 49




Fig. 10. Wiring guide for pc board. If you make your own single-sided board, eliminating the component-side conductors, install the jumper wires represented by the dashed lines.

computer with communication software and an RS-232 interface. We'll use the expression "terminal" even if you're using a computer with appropriate software because it's more appropriate in this context.

Set your terminal for 4,800 baud, eight data bits, one stop bit and no parity. Usa a cable with suitable connectors to connect MAG-11 via its J7 DB-9 connector to the serial port on the terminal. Make sure Receive Data (RD) pin 2 of J7 is connected to the terminal's Transmit Data (TD) line and TD pin 3 of J7 is connected to the ter-




Fig. 11. Optional accessory boards plug into the MAG-11 SBC main board via single-row jack/plug arrangements.

minal's RD line. Ground pin 7 of J7 to ground on the serial interface (normally pin 7 if the serial interface connector has 25 pins or pin 5 if it has only nine pins). No handshaking is used or required by either MAG-11 or the BUFFALO monitor.

After connecting MAG-11 to the terminal, turn on the latter. When you power up MAG-11, on-screen should appear the message: "BUFFALO v.3.4 (ext) - Bit User Fast Friendly Aid to ...." If it doesn't appear, use one line of MAG-11BAT's logic monitor (or a separate logic probe) to determine the source of problem. To do this, plug one end of a short length of No. 22 or 24 hookup wire into pin 1 of J3 on MAG-11BAT. Touch the other end of the wire to pin 11 of U3; red LED2 should light.

Press MAG-11's RESET switch (accessed through a hole in MAG-11BAT) while observing red *LED1* and green *LED9*. If both LEDs briefly light, the problem is most likely with the terminal or connections. Make sure you've set the terminal for 4,800 baud, eight data bits and one stop bit and have connected the pins correctly.

Once you obtain the proper message, press the terminal's ENTER or RETURN key to obtain the prompt: >. Then press ? or HELP to obtain a list of BUFFALO commands. See the BUFFALO Monitor Official Help List elsewhere in this article, which is printed exactly as it comes from the BUFFALO monitor in the EPROM.

BUFFALO expects the following format for commands:

<CMD[<wsp>arg>wsp>arg>...]<CR>

[] implies contents are optional;  $\langle WSP \rangle$  is whitespace character (space, comma, tab);  $\langle CMD \rangle$  is a command string of between one and eight characters;  $\langle ARG \rangle$  is an argument particular to the command;  $\langle CR \rangle$  is carriage return, which signifies the end of the input string.

As you can see from the Help List, the list of commands is extensive. Though no thorough description of how to use the BUFFALO monitor will be presented here, one precaution must be clearly understood. Unless

#### Sources


**Digi-Key Corp.** 701 Brooks Ave., S. P.O. Box 677 Thief River Falls, MN 56701 Tel.: 1-800-344-4539

#### Motorola Freeware BBS

Tel.: 1-512-891-3733 Set modem for: 2,400, 1,200 or 300 baud; eight data bits; one stop bit; no parity.

you know exactly what you're doing, avoid using the BULKALL command with MAG-11 in Special Test Mode. This command is designed to erase the EEPROM (usually no problem) and the CONFIG register, which can be a real pain if you don't know precisely what you're doing.

Next month, we'll go into more detail on the BUFFALO monitor and how to use it. We'll also discuss how to use MAG-11 to produce an inexpensive do-it-yourself custom singlechip 68HC11 system.



# Fast-Acting Modem Protection


Low-cost devices you can build and use to protect a computer modem, fax machine, telephone answering machine and computer from electrical damage

C omputer modems, facsimile machines and telephone answering machines are usually operated just as they come out of the boxes in which they were purchased. If you use such equipment without protection, you run the risk of serious damage to it as a result of electrical storms, transients and surges generated whenever heavy-duty electrical equipment switches on and off and other phenomena.

In this article, we describe how to build three low-cost, high-energy devices that protect sensitive (and notso-sensitive) electronic equipment. Protection with two of the three circuits to be described is *fast*, taking effect within 5 to 8 nanoseconds of the onset of a hazardous condition on a telephone or computer line. The circuits to be described use no moving parts, nor do they require ac line or battery power to operate, making them fail-safe and economical to use. The only requirement is connection to a good earth ground.

#### About the Circuits


A Modem Protector designed to protect electronic equipment connected to a telephone line is shown schematically in Fig. 1. It uses two CP Claire No. CG2301 or equivalent gas-discharge surge suppressors that have long been used for lightning protection. They handle a high-current arc discharge to ground when the gas inside them ionizes but are fairly slow to react to voltage surges. To offset this, two 180-volt, 5-watt 1N5386B or similar zener diodes connected back-to-back as shown can be wired




from each telephone-line conductor to ground. The zener diodes can be wired cathode-to-cathode, as shown, or anode to anode.

With the zener diodes wired into the circuit, action is considerably

speeded up to protect the telephone circuit from an initial surge. The zener diodes work almost instantaneously and continue to work until the surge suppressors catch up and take over handling the high-current energy.








Fig. 2. This simple circuit protects computer serial port lines from voltage surges. Each port conductor must be equipped with an identical circuit.

To understand how this protection of a modem or any other electronic device connected to the telephone line works, let us review what happens on the telephone line. When a telephone instrument is on-hook, approximately 48 volts dc appears across the line. Lifting the handset off-hook drops the line potential to about 6 volts. With the receiver onhook, when a ring signal appears on the line to signal an incoming call. about a 100-volt, 20-Hz ac signal is impressed on the already-present 48 volts dc. The amplitude of the ring signal determines the voltage required for the zener diodes and surge suppressors in Fig. 1.

Telephone circuits generally have built into them a resistive device on each line conductor to protect a telephone instrument from electrical spikes in excess of 500 to 600 volts. This "brute-force" approach is not very effective for all-electronic telephone instruments, modems and facsimile machines, which are more sensitive to voltage spikes.

Gas-discharge tubes initially used to protect telephone circuits could handle the high currents involved, but their response speed was slow. Later, an electronic device called a "varistor" served as a passive resistive shock absorber and was used in conjunction with gas-discharge tubes to yield much better performance. However, varistors are not as fast performers as semiconductor devices, and they wear out with repeated exposure to voltage spikes.

A variation on the Modem Protector theme, shown in Fig. 2, can be used to protect remote computer terminals connected over a long distance to a computer. If you decide to use this Serial Port Protector circuit, make sure you equip *each* conductor of the cable that goes to the remote computer with an identical circuit.

Shown in Fig. 3 is an AC Line Con-





Fig. 3. This circuit protects electronic equipment from electrical surges on the ac power line.

ditioner circuit that protects electronic equipment connected to the 117-volt ac line. It plugs into the ac line and has chassis-mount ac receptacles into which the equipment plug. Varistors prevent surges on the ac line from entering the power supplies of the equipment.


For most applications that do not involve a computer, you should incorporate the Modem Protector (Fig. 1) and AC Line Conditioner (Fig. 3) into your system. Where a computer is involved, you need at least the Serial Port Protector (Fig. 2) and AC Line Conditioner, and if the computer connects to the telephone line, the Modem Protector as well.

### Construction

You can build one or all three of the circuits described above from readily available components and materials. The Modem Protector circuit is so simple in terms of component count, you can wire it on a small piece of perforated board or fabricate a printed-circuit board (use the actual-size







**Fig. 4.** Actual-size etching-and-drilling guide (A) and wiring diagram (B) for Modem Protector circuit.

etching-and-drilling guide and component-placement diagram shown in Fig. 4) and house it inside a standard telephone-jack wall box. As you build the Fig. 1 circuit, make sure you observe proper polarity between telephone line and the equipment to which it is to go.

Construction of the Fig. 2 circuit is almost as simple. Wire as many of these circuits as there are conductors in your serial cable side by side on perforated board. House the assembly inside a suitable size project box. Plan the physical layout inside the box so that the cable coming from the remote computer enters at one end of the box and the cable to the terminal exits the opposite end of the box. If you use a metal project box, deburr the holes or slots made for the cables

ComputerCraft Subscribe Now and Save and line them with rubber grommets or other insulating material.

House the Fig. 3 circuit inside a metal utility box that is large enough to provide room on its top panel for mounting the three chassis-mount ac receptacles. The box will almost certainly be large enough to house the assemblies for the Fig. 1 or/and Fig. 2 circuit assemblies as well.

Machine the box as needed. When you are done, mount the three ac receptacles on the top panel. Then, referring to Fig. 3, wire the three-conductor ac line cord and varistors into the circuit exactly as shown. Use heavy-duty stranded wire to interconnect the components. If you are planning on housing the Fig. 1 or/ and Fig. 2 circuits inside the same enclosure, mount them into place as well, using spacers and suitable machine hardware.

Bring together all circuit grounds and tie them to a common point that then ties to your earth ground. (If you are using just the Fig. 1 or/and Fig. 2 circuits, tie their ground points to your earth ground separately.)

The effectiveness of your earth ground is extremely important with any and all of the circuits described above. The most effective ground is obtained by driving a grounding rod 6 to 8 feet deep into moist soil. [For full details on making effective earth grounds, see "Antenna Grounding Basics" in the August 1990 Communications column in *Modern Electronics*—Ed.]

If you are unable to establish a good earth ground by the groundingrod method, your second choice is to use the cold-water pipe where you live. A third choice is the grounded contact on your electrical outlet. This last choice may not be adequate, however, because the ground can actually be many millivolts above true ground potential. Also, oxidation on the contacts of the ac electrical system can render the ground ineffective. Therefore, if you have a choice, avoid this type of ground.

Once you have decided on the ground you will be using for your protection system, run insulated 14or 16-gauge stranded wire from it to the Modem Protector circuit(s). Make sure you use very-low-resistance means of connecting this wire at both ends.

FAX: (800) 366-9662

# \$50 Lab-Grade Function Generator


Full-featured 1-Hz to 25O-kHz function generator construction project adds CMOS/TTL compatibility, an FM sweep input, near-zero distortion and a power-amplifier output to drive 5O-ohm loads to the usual sine/triangle/square-wave outputs

**S** econd only to the oscilloscope, a Laboratory-Grade Function Generator like the one described here is a real necessity for developing and debugging a broad range of circuits. With it, distortion can be measured, bandwidths extrapolated, clocks created, time constants tested and open circuits found, to name just a few of its almost inexhaustible applications.

Our Function Generator provides the usual sine-, triangle- and squarewave outputs at frequencies ranging from less than 1 Hz to beyond 250 kHz at virtually zero distortion. It offers CMOS and TTL compatibility for digital circuits and a variable  $\pm 15$  volts. The Generator is also TTL/CMOS compatible for use in digital circuits. Other features include: an FM sweep input; variable offset to  $\pm 10$  volts; and a power-amplifier output for driving 50-ohm loads. If you were to obtain all these features and functions in a single commercial function generator, the instrument would cost you many hundreds of dollars. By building the Function Generator, your cost should be about \$50 or so for all materials. including enclosure.

### About the Circuit

The heart of the Generator is a precision waveform generator/voltagecontrolled oscillator chip that Digi-Key, among others, sells for less than \$5. This is the ICL8038 shown as *IC2* in Fig. 1(A). This particular chip has been around for a number of years and is the foundation upon which



every bench-top function generator on the market is built. To fully appreciate the potential of the ICL8038, you should contact Intersil, which makes the chip, via your local representative to request Application Note AO13, "Everything You Always Wanted to Know About the ICL8038." This informative publication explains in detail the functions and features of the ICL8038 and provides a variety of interesting applications for the chip.

Because the ICL8038 is basically a voltage-controlled oscillator (vco), some means for varying its sweep in-

put at pin 2 of *IC2* must be provided. This is the task of operational amplifier *IC1* and its associated circuitry. A near-1,000:1 sweep ratio is provided externally via SWEEP IN jack *J1*.

Any varying voltage applied to pin 2 of *IC2* through *J1* within the range of  $\pm 12$  volts produces frequency modulation (FM) of the output waveform at FINAL OUTPUT jack *J3* in Fig. 3(C). If no external sweep is used, output frequency is set via FREQ. ADJ control *R1* in Fig. 1(A).


Trimmer potentiometers R4 (HIGH FREQ TRIM) and R5 (LOW FREQ TRIM) permit one-time peaking of the upper and lower frequency limits, respectively. These trimmer controls are adjusted as needed during circuit checkout with a frequency counter or oscilloscope connected to J3.

SYMMETRY TRIM control R8 provides a one-time calibration of duty cycle and sine-wave symmetry. With an oscilloscope connected to J3, you adjust R8 until the sine wave displayed on the CRT of the scope appears as uniform and symmetrical as possible. Further "tweaking" for minimal sine-wave distortion is accomplished by adjusting DIST TRIM controls R6 and R7.

Frequency range is selected via S2 in Fig. 1(B). As the FREQUENCY RANGE SELECT switch is moved through its positions, it selects different values of capacitance. As the selected capacitance decreases, the RC time constant internal to *IC2* also decreases. This results in an increase in output frequency from the chip. Capacitance values for the S2 circuit range from 417  $\mu$ F to less than 100 pF to provide a frequency bandwidth at the output of *IC2* ranging from less than 1 Hz to beyond 250 kHz, with some overlap between ranges.

When selecting the capacitors for the S2 circuit, exercise care to obtain only high-quality, low-leakage devices. This ensures that the oscillator operates with maximum stability. Trimmer capacitor C15 permits tweaking for maximum frequency while maintaining some frequency overlap between the high end of range 3 and the lowest frequency available on range 4.

A high-speed CMOS/TTL-com-



**Fig. 1.** Complete schematic diagram of Function Generator is shown here in four parts, labeled (A) through (D).

PARTS LIST

#### Semiconductors

- D1—1N4001 silicon rectifier diode D2,D3—1N4148 or similar small-signal switching diode
- IC1-TL072 or similar internally compensated operational amplifier
- IC2—ICL8038 waveform generator
- IC3—74HC04 or 74HC14 hex inverter IC4—7812 fixed + 12-volt regulator
- IC5 = 7805 fixed + 5-volt regulator
- IC6—7912 fixed 12-volt regulator
- Q1,Q2,Q3—2N2222 or similar generalpurpose npn silicon switching transistor


- Q4,Q5—2N3906 or similar silicon pnp switching transistor Q6—TIP31 silicon npn power transistor
- Q7—TIP32 silicon pnp power
- transistor
- RECT1—50-piv, 1-ampere bridge rectifier assembly

#### Capacitors

- C1,C2–100-μF, 35-volt electrolytic
  C3–4.7-μF, 35-volt electrolytic
  C4–0.47-μF polypropylene or polyester
  C5 thru C8–0.1-μF monolithic ceramic
  C9,C10–0.33-μF, 35-volt tantalum
  C11–0.047-μF polypropylene or polyester
- C12—0.0047- $\mu$ F polypropylene or polyester
- C13—390-pF silver-mica or polypropylene
- C14—6-to-50-pF trimmer (Radio Shack Cat. No. 272-1340 or similar)

Resistors (¼-watt, 5% tolerance) R10,R11—10 ohms (½-watt) R12,R13—33 ohms (½-watt) R14—100 ohms R15,R16—1,000 ohms R17—1,200 ohms R18,R19,R20—1,800 ohms R21,R22—2,200 ohms

Say You Saw It In ComputerCraft



R23-3,300 ohms R24-510 ohms R25-20,000 ohms R26 thru R29-5,100 ohms R30-6,800 ohms R31 thru R35-10,000 ohms R36,R39-15,000 ohms R37-27,000 ohms R38-10.000 megohms R1-5,000-ohm linear-taper panelmount potentiometer R2,R3-10,000-ohm linear-taper panel-mount potentiometer R4-10,000-ohm pc-mount trimmer potentiometer R5,R9-1,000-ohm pc-mount trimmer potentiometer

R6,R7—50,000-ohm pc-mount trimmer potentiometer

R8—5,000-ohm pc-mount trimmer potentiometer

#### Miscellaneous

- F1-0.5-ampere slow-blow fuse
- I1—Neon panel lamp with limiting resistor
- (Radio Shack Cat. No. 278-105 or similar)
- S1—Spst toggle or slide switch
- S2—Four-position non-shorting rotary switch
- S3—Three-position non-shorting rotary switch

patible clock output is provided by HCMOS hex inverter IC3 in Fig. 1(A). TTL OUT J2 is quite useful as a variable logic clock when designing and troubleshooting digital circuits. Its fan-out is reasonably high. By utilizing the lower-frequency settings, you can better judge the logical operation of a circuit when testing different points in the circuit with a logic probe.

Selection of the sine-, triangle- or square-wave function is made using FUNCTION SELECT switch S4 in Fig. 1(B). This switch permits you to connect the input of the output amplifier inside the Function Generator to one of the three available waveform output pins of *IC2*. The sine-wave output of *IC2* is on pin 2, the trianglewave output is on pin 3 and the square-wave output is on pin 9.

Once a selection is made via S4, the output from IC2 is fed to the buffer amplifier consisting of the Q1/Q4 circuit. The buffered output from this circuit is fed to AMPLITUDE ADJ control R2 to permit you set the signal amplitude output from J3.

A variable dc offset voltage is provided by the Q2/Q3 circuit, also shown in Fig. 1(B). This offset can be switched between IN and OUT via OFFSET switch S3 in Fig. 1(C). Infinite variability of the dc offset is provided by OFFSET ADJ control R3, while OFF-SET TRIM ADJ control R9 provides one-time calibration of the zero-offset adjustment. With S3 set to OUT, you should adjust R9 so that no dc offset is observed on the CRT of your scope connected to J3.

A power amplifier capable of driv-

T1—Shielded 25.2-volt, 450-mA center-tapped power transformer (Radio Shack Cat. No. 273-1366 or similar) Printed-circuit board or perforated board with holes on 0.1-inch centers and suitable Wire Wrap or soldering hardware (see text); suitable enclosure (Radio Shack Cat. No. 270-272 or similar); sockets for all DIP ICs; fuse holder; three-conductor ac line cord; pointer-type control knobs; rubber grommet; heat-shrinkable tubing; ½" spacers; lettering kit and

S4—Spdt toggle or slide switch

clear acrylic spray (see text); machine

hardware; hookup wire; solder; etc.

ing a 50-ohm load is provided by the push-pull output stage made up of Q6 and Q7 in Fig. 1(C). Correct biasing of this output circuit is provided by Q5, D2 and D3. Signal feedback is provided by R35. As shown, the complete amplifier delivers a no-load output swing of almost  $\pm 15$  volts, or 30 volts peak-to-peak, with less than 1% distortion.


Power for the Function Generator circuits is provided by the ac-operated circuit shown schematically in Fig. 1(D). The incoming 117 volts from the ac line is stepped down to 24 volts ac by shielded power transformer TI. The center-tapped secondary of TIprovides two separate lines, both referenced to circuit ground, to bridge rectifier RECT1. The rectifier assembly converts the incoming ac into +17 and -17 volts pulsating dc. The pulsating dc is filtered to pure dc by Cl and C9 in the +17-volt line and C2 and C10 in the -17-volt. Both lines are then regulated to +12 and -12 volts by IC4 and IC6, respectively, for delivery to the circuits inside the Function Generator.


Note also that regulator IC5 in the + 12-volt line is used to obtain + 5 volts. The only point in the circuit to which the + 5-volt line goes is power pin 14 of HCMOS hex inverter IC3.

#### Construction


The circuitry for the Function Generator is relatively simple and lends itself to just about any method of wiring you wish to use. If you feel ambitious, you can design and fabricate a printed-circuit board on which to mount and wire together the components. Otherwise, use perforated board that has holes on 0.1-inch centers and suitable Wire Wrap or soldering hardware. Whichever way you go, be sure to use sockets for all DIP ICs. Also, if you can obtain it, perforated board that has each hole surrounded by a thin isolated ring of copper will ease securing components in place.

If you use perforated board, begin construction by laying out the circuit in a logical manner, with an eye toward maintaining physical isolation between the input and output circuits. Test fit the components (use the sockets—not the ICs themselves in the IC locations) to determine ex-





**Fig. 2.** Interior view of author's prototype shows details for mounting power transformer and fuse holder and how green conductor of ac line cord and ground lead from circuit-board assembly connect to enclosure ground via transformer mounting hardware.



actly how the layout is to appear. The layout for the prototype project that appears in the lead photo is shown in the Fig. 2 interior-view shot. Notice here that all switches, all but two rotary controls, the jacks, the power transformer, fuse block and power transformer mount off the board. A fairly large enclosure was used for the prototype; so it wasn't necessary to minimize real estate.

Once you know how you want the components to lay out on the board, mount the IC sockets in their selected locations. If your board has copper rings around each hole, tack-solder the four corner socket pins into place. Use solder sparingly if you're using Wire Wrap hardware. Do *not* plug the ICs into the sockets until you've conducted preliminary voltage tests and are certain you have correctly wired the circuit.

When you're ready to wire the circuitry, photocopy all sections of Fig. 1. Then begin wiring the circuit board. As you make each conductor run, trace the appropriate conductor on the schematic. Whenever you reach a point where a connection must be made to an off-the-board component, terminate it in a solder post to which a wire can be connected and soldered after the circuit board is mounted in place.

After wiring the circuit board, carefully go over your wiring to make sure it's correct. If you made any soldered connections, inspect each. If you missed soldering a connection, solder it now. If a connection is suspicious, reflow the solder on it and add solder if needed. Finally, if you locate solder bridges, especially between the closely spaced pins of the IC sockets, clear them away with a vacuum-type desoldering tool or desoldering braid.

Select an all-metal enclosure for your Function Generator. You can use an "instrument" enclosure like the one shown in the lead photo. If you can't find such an enclosure, any other metal project box that can accommodate the circuit board and power transformer on its bottom panel and has sufficient room on its front panel on which to mount the power indicator, controls, switches and jacks will do.

Machine the enclosure as needed. Drill mounting holes for the power indicator, controls, switches and jacks through the front panel; holes through the floor panel for mounting the circuit-board assembly, fuse holder and power transformer; and an entry hole for the ac line cord through the rear panel. When you're done, deburr all holes to remove sharp edges.


Temporarily mount the rotary switches in their respective holes in the front panel. Place pointer-type knobs on their shafts. Adjust switch positioning for symmetrical sweeps, and use a soft lead pencil to mark the pointer location on the panel in each position. When you're done, remove the switches. Then use a dry-transfer lettering kit to label the panel with appropriate legends for all switches and controls. A typical lettering scheme is shown in the lead photo.

Spray two or three light coats of clear acrylic over the entire front panel to protect the legends from scratches while the project is in use. Allow each coat to dry before spraying on the next.

When the acrylic spray has completely dried, mount the circuitboard assembly to the floor of the enclosure using  $\frac{1}{2}$ " spacers and suitable machine hardware. Then mount the power transformer and fuse holder, also to the floor panel, and the various items that go on the front panel.

Orient the project as shown in Fig. 3 to give you easy access to the lugs on the controls, switches and jacks. Note that the lugs of the controls, switches and jacks are all readily accessible. Using the photocopied schematic, crimp and solder the free ends of the wires coming from the circuitboard assembly to the appropriate lugs of the front-panel-mounted components.

Line the entry hole for the ac power cord with a rubber grommet. Pass the unfinished end of the cord through the grommet and secure a large plastic cable tie to it about 6" from the




**CIRCLE NO. 87 ON FREE INFORMATION CARD** 

# Laser Printer Toner Cartridge Recharging

Earn up to \$125/hr at home
\$30K - \$250K income possible
Huge market - less than 15 in 100 cartridges were recharged last year
Low-Cost, high-quality videotape and "Hands-On" training available
Complete training packages from only \$595 - \$995! (None-higher)
No supply contract requirements or on-going franchise fees
All supply sources fully disclosed
Ask about the "Business in a Box"
100% Money-Back Guarantee!
Call for details & DEMO VIDEO



CIRCLE NO. 68 ON FREE INFORMATION CARD 60 / COMPUTERCRAFT / April 1992



**Fig. 3.** This interior view shows how lugs of all front-panel-mounted switches, controls and jacks are easily accessible for connection to circuit-board assembly via hookup wires.

unfinished end inside the enclosure. Use the cable tie as a strain relief for the line cord.

Strip <sup>3</sup>/<sub>8</sub> inch of insulation from all three conductors. Tightly twist together the exposed fine wires in each conductor and sparingly tin with solder. Crimp and solder a spade or ring lug to the green-insulated conductor and another to the ground wire coming from the circuit-board assembly. Make the connection to chassis ground with the machine hardware that secures the near tab of the power transformer to the floor panel. Place a lockwasher on the screw, follow with the two lugs and another lockwasher and, finally, the nut.

Finish wiring the project according to the schematic diagram. Use heatshrinkable tubing over the connections in the primary circuit of the power transformer.

#### Checkout & Adjustment

With no ICs plugged into the sockets on the circuit board, plug the line cord into an ac outlet. Clip the common lead of a dc voltmeter or multimeter set to the dc-volts function to the grounding hardware of the power transformer.

Setting the POWER switch to "on" and touching the "hot" probe of the meter to pin 8 of the *IC1* socket and

pin 6 of the *IC2* socket should yield a reading of +12 volts. Similarly, touching the "hot" probe to pin 4 of the *IC1* socket and pin 11 of the *IC2* socket should yield a reading of -12volts. The reading obtained when you touch the "hot" probe to pin 14 of the *IC3* socket should be +5 volts. Next, touching the "hot" probe to the collectors of *Q1* should yield a reading of +17 volts.

If you fail to obtain the proper reading at any given point, immediately power down your Function Generator and troubleshoot it to determine where the problem exists.

When you're certain you've properly wired the project, remove power from it and allow the charges to bleed off the electrolytic capacitors in the power supply. Then plug *IC1* and *IC3* into their respective sockets. Make sure each is properly oriented and that no pins overhang the sockets or fold under between ICs and sockets. Do not plug the 8038 into the *IC2* socket just yet.

Power up the Function Generator and set the OFFSET switch to the OUT position. Measure the dc voltage from the "signal" contact of OUT-PUT jack J3 to ground. If the reading isn't 0 volt, adjust trimmer control R9 on the circuit board so that it is. (Continued on page 86)


# Low-Battery Alarm with Automatic Load Disconnect

Flashes a LED or sounds an alert when battery voltage drops below a predetermined level and, optionally, disconnects the load if no action is taken

**B** attery-powered devices free you from relying on power from an ac wall socket and, thus, permit portability. Of course, the tradeoff for the convenience of using battery power is that all batteries eventually run down and require replacement or recharging—usually at a very inconvenient time. The Low-Battery Alarm described here can be built into a portable device, where it flashes or beeps

to alert you when battery voltage has dropped to a specified level. Forearmed by the alarm, you can change or recharge batteries at your leisure instead of being stranded without power at an inconvenient time.

The Low-Battery Alarm has a second function built into it that goes beyond simply flashing or sounding an alert. If you ignore the warning and battery potential drops to a sec-



ond (still-lower) voltage, any circuits powered by the battery are automatically disconnected from the power source. Power is restored only when the voltage returns to a safe level for operation of the device. The automatic-disconnect feature is optional. If you include it, a switch allows you to override the disconnect function and restore power to the load even if battery voltage is low.

You can build the Low-Battery Alarm into your projects or add it to commercial products you own. Any battery-powered device that operates on 3 to 16 volts and draws up to 1 ampere is a candidate for the Alarm, as are devices with battery back-up. For example, if you have a clock or other device that contains a back-up battery that takes over when power fails, adding a low-battery alarm alerts you when it is time to change the battery to ensure that back-up power will be available when needed. Also, in computers that have small batteries that allow them to save important setup data when powered down, the Low-Battery Alarm will let you know when the internal one needs replacement. (Keep in mind, though, that adding circuitry to a commercial product may void its warranty.)

Another application for a low-battery alarm is to provide protection from damage due to over-discharging for rechargeable batteries. For longest life, nickel-cadmium (Ni-Cd) batteries should be discharged to about 1 volt per cell, but no further, on each discharge cycle. Lead-acid batteries may also be damaged if discharged too deeply. Low-battery warning and automatic disconnect




Fig. 1. The ICL7665 micro-power over/under voltage detector contains a voltage reference and two comparators. Output *OUT1* switches on when *SET1* is greater than Vref, and *OUT2* switches on when *SET2* is less than Vref.

lets you cycle fully any rechargeable batteries you have without risk of damaging them.

#### About the Circuit

The circuitry for the Low-Battery Alarm uses a special-purpose ICL7665 CMOS over/under-voltage detector. The Parts List gives one source for the IC, but other suppliers may carry it as well. Figure 1 shows that the IC contains a voltage reference, two comparators and outputs that are driven by open-drain MOS transistors.

You could build a circuit similar to the one shown in Fig. 1 using IC comparators and discrete components, but the ICL7665 has the advantages of compact size (an eight-pin DIP) and minuscule current consumption of 3 microamperes on average.

One half of the IC operates as an over-voltage detector, the other as an under-voltage detector: OUT1 switches on when the SET1 voltage is greater than  $V_{ref}$ , and OUT2 switches on when the SET2 voltage is less than  $V_{ref}$ . Connecting resistors to pins 2, 3, 5 and 6 allows you to program OUT1 and OUT2 to turn on and off at desired levels of V + . The outputs can sink up to 20 milliamperes of current.

Vref is a stable bandgap-type reference voltage. According to the ICL8665 data sheet, the temperature coefficient of Vref is 200 ppm/°C (parts per million per degree Centigrade). This means that Vref will vary at most just 0.2 millivolt per volt with each degree change in temperature.

From one IC to another, however, the voltages at which OUT1 and OUT2 switch may vary between 1.15 and 1.45 volts. For applications that switch at precise voltages, you will want to measure the switching voltages of your IC and use these when calculating resistor values for your circuit. (More about this later.) Another alternative is to use the "A" version of the IC, which has tighter specifications. One-percent-tolerance resistors are also recommended for best results in critical applications.

The complete schematic diagram for the Low-Battery Alarm is shown in Fig. 2. Battery BI is any dc supply that delivers 3 volts to 16 volts. LOAD is any circuit powered by BI and drawing up to 1 ampere of current.

The values of R1 through R5 and R8 will vary, depending on the desired voltages at which you want to turn on the alarm and disconnect and reconnect the load. The value of R9 depends on the maximum expected load current. We will show you how to calculate the values for these components later in this article.

Separate voltage dividers are made up of R1/R2/R3 and R4/R5. When a fresh battery is installed at B1, the voltages at pins 3 and 6 of *IC1* are greater than V<sub>ref</sub> of *IC1*. So, pin 1 switches on and pin 7 switches off.

When pin 1 is on, base current flows through QI, switching on this

#### PARTS LIST

Semiconductors
IC1—ICL7665 over/under-voltage
detector
IC2—TLC555 or similar low-power
CMOS 555 timer
LED1—Red light-emitting diode
(see text)
Q1—TIP42 or similar pnp silicon
transistor in TO-220 case
Capacitors (25 WVDC)
C1,C3–0.1ceramic disc
C2—1.0- $\mu$ F tantalum electrolytic
Resistors (¼-watt)
R1 thru R5, R8, R9—See text
R6-1 megohm (5% tolerance)
R7—100,000 ohms (5% tolerance)

#### Miscellaneous

- BZ1—Piezoelectric buzzer (Radio Shack -273-065 or equivalent see text)
- S1—Spst pc-mount toggle switch Printed-circuit board or perforated board with holes on 0.1-inch centers and suitable Wire Wrap or soldering hardware; IC sockets; machine hardware; hookup wire; solder; etc.
- Note: The ICL7665 over/under-voltage detector chip is available from Digi-Key, 701 Brooks Ave. S., P.O. Box 677, Thief River Falls, MN 56701-0677 (tel.: 1-800-344-4539)

transistor and allowing LOAD to receive power from B1 through Q1. Since Q1 is driven into saturation, its collector-to-emitter voltage drop is small, though it may be as great as a few tenths of a volt at higher load currents.

Over time, as B1 discharges, its voltage and the voltages across R3and R5 gradually drop. When the potential at the terminals of B1 drops to the predetermined alarm level, the voltage on pin 6 of IC1 equals V<sub>ref</sub>, which causes pin 7 to turn on, providing a path to ground for *IC2*.

CMOS low-power timer IC2 is configured as an oscillator. Its output at pin 3 drives either a piezoelectric buzzer (BZ1) or visual indicator (LED1), depending on whether you want an audible or visible alarm. When pin 3 of IC2 is low, LED1 or BZ1 is on. The values of R6, R7 and C1 are chosen so that the alarm flashes or beeps briefly, at a rate of about once per second. This gives a noticeable, warning without consuming large amounts of power.

Resistor *R8* limits current through *LED1*. Its value is calculated so that a maximum of 20 milliamperes flows when *LED1* is on.

If the warning is ignored and voltage across B1 continues to drop to a point where the battery potential reaches the predetermined load shutoff voltage, the potential on pin 3 of IC1 equals V<sub>ref</sub> and pin 1 switches off. This cuts off Q1 base current and removes power from the LOAD. Since IC2 also receives power through Q1, the alarm also shuts off at this point.




Fig. 2. Complete schematic diagram of the Low-Battery Alarm with circuitry automatic load disconnect.

When pin 1 switches off, IC1 also removes R1 from the circuit by providing a low-resistance connection from pin 2 to pin 8. Since R1 no longer has an effect, the potential across B1 must rise to a new, higher voltage before the potential on pin 3 equals  $V_{ref}$  and pin 1 switches on again to restore power to the load. In this way, the load-control circuit is prevented from chattering on and off when B1is at the load-disconnect voltage.

Resistor R9 limits base current to Q2. The value of R9 value must be chosen to minimize current consumption of the circuit, while still powering the LOAD effectively.


Closing S1 allows you to override the load-disconnect circuit in case you want to power the LOAD in spite of weak batteries. When the circuit is powered up, if voltage across B1 is not quite great enough to cause pin 1 of IC1 to switch on, momentarily closing S1 switches on pin 1 and power the LOAD.

Capacitor C1 slows the response of the load shut-off circuit to prevent the circuit from responding to small "glitches" in the supply. For a fast response, you can eliminate C1. Capacitor C3 provides power-supply decoupling for B1.

#### Customizing the Circuit

Several equations allow you to choose resistor values to fit your specific application. For best results, measure the switching voltages of SET1 and SET2 for each ICL7665 IC you use and use these values in the equations. Shown in Fig. 3 is a circuit for making these measurements. Connect a battery or other dc supply that has a voltage close to that of the battery you will be using in your circuit from pin 8 to pin 4 of the ICL7665. Then connect potentiometers and resistors as shown.

Connect the + probe lead of a dc voltmeter or multimeter set to the dcvolts function to pin 1 and the – lead to pin 4 of the ICL7665. Set the wiper of the potentiometer connected to pin 3 until pin 1 just switches from V + to 0 volt. With this potentiometer set to this position, measure the voltage from pin 3 to pin 4 of the ICL7665. This is the value you should substitute for Vs1 in the following equations.



**Fig. 3.** To measure the switching voltages at pins 3 and 6 of a specific IC, connect the IC as shown. Adjust the potentiometer connected to pin 3 until the signal on pin 1 just goes low, and then adjust potentiometer connected to pin 6 until the signal on pin 7 just goes low.

To measure the switching voltage of SET2, move the + probe of the meter to pin 7 and adjust the potentiometer connected to pin 6 of the ICL7665 until pin 7 just switches from V + to 0 volt. With this potentiometer set to this position, measure the voltage from pin 6 to pin 4. This is your Vs2 in the following equations.

To illustrate how to make the calculations, we'll assume the following:

B1: four Ni-Cd cells in series

Vs1, Vs2: 1.3 volts

AOv (alarm turn-on voltage): 4.4 volts (1.1 volts per cell)

LFv (load shut-off voltage): 4 volts (1 volt per cell)

LNv (load reconnect voltage): 5 volts (1.25 volts per cell)

Imax (maximum expected load current): 0.5 ampere

Values for *R1* through *R5*, *R8* and *R9* are chosen as follows:

(1) Select a value for R5. The exact value is not critical, but at least 100,000 ohms is recommended for R1 through R5 to minimize current consumption of the circuit. In our example, we will use a 100,000-ohm 1%-tolerance resistor for R5.

(2) Find the value of R4 by substituting Vs2 and the desired ANv in the equation: R4 = [R5(ANv)/Vs2] R5.

With Vs<sub>2</sub> = 1.3 and ANv = 4.4, *R5* rounds off to 238,000 ohms. The closest 1%'tolerance standard resistor value to this is 237,000 ohms.

(3) If you plan to include *LED1*, calculate the value of R8 by substitution in the equation: R8 = (ANv - 1.6)/0.02. In this equation, 1.6 represents the voltage drop across *LED1* and 0.02 is the 20 milliamperes that flows through *LED1* when the voltage of *B1* equals ANv. Because the value of *R8* is not super-critical, a 150-ohm 5% tolerance resistor will serve.

(4) As in step 1, select a value for R3 (at least 100,000 ohms). We will set R3 to a value of 200,000 ohms at 1% tolerance.

(5) Find the value of R2 by substituting Vs1 and the desired LFv using the equation:  $R2 = [(R3 \times LFv)/Vs1] - R3$ . With R3 = 200,000, Vs1 = 1.3 and LFv = 4, the value of R2 rounds off to 415,000 ohms. The closest 1% 'tolerance value to this is 412,000 ohms.

(6) Find the value of RI by substituting R2, R3,  $V_{S1}$  and the desired LNv in the equation:  $R1 = [(LNv \times R3)/V_{S1}] - (R2 + R3)$ . With  $V_{S1} = 1.3$ , R3 = 200,000 ohms, R2 = 412,000 ohms and LNv = 5, the value of RI rounds off to 157,000 ohms.





Fig. 4. The actual-size etching-and-drilling guide for the printed-circuit board for the Low-Battery Alarm.



(7) Finally, find the value of R9 by substituting in the equation:  $R9 = [(LFv - 0.6) \times 50]/I_{max}$ , where 50 represents minimum current gain expected at QI and 0.6 is the base-emitter voltage drop of QI. By selecting the value of R9 with this equation, you minimize base current of QIwhile allowing QI to provide sufficient current to power the load.

If  $I_{max} = 0.5$  and LFv = 4, R9 = 340 ohms, and a 330-ohm resistor at 5% tolerance will serve.

You can calculate resistor values for any ANv, LNv and LFv between 3 and 16 volts by following the above steps and substituting desired values in the equations.

In the Fig. 2 circuit, the alarm circuit is a simple level detector. The alarm is on when the voltage across BI is greater than ANv and off when the BI voltage is less than ANv. If you want the alarm to remain on once it is triggered, even if voltage across BI rises, you can add a resistor in series with R4 and pin 8 of ICI and connect the junction between these resistors to pin 5. This results in a three-resistor divider like that of R1/R2/R3. The added resistor raises the alarm turn-off voltage in the same way RI affects LNv.

#### Battery Types

The ANv, LNv and LFv voltages to use depend on the number and type of batteries used, since different composition batteries have different discharge characteristics. Normally, you will choose resistor values so that the Alarm sounds or lights its LED well before it disconnects the load, to give you plenty of time to change or recharge batteries. You can experiment to determine the values that work best for a specific application, but here are some general guidelines.

Each Ni-Cd cell generally holds a steady 1.2 volts as it discharges. This voltage drops rapidly only when most of the cell capacity has been consumed. For Ni-Cd cells, recommended circuit voltages are: ANv = 1.1 volts per cell, LFv = 1 volt per cell and LNv = 1.25 volts per cell.

In contrast, the voltage on leadacid batteries drops steadily as these cells discharge. To prolong the life of a typical deep-cycle lead-acid cell, recharge the cell or battery when 80%of its capacity has been exhausted. The voltage at which this occurs, however, varies according to the discharge current of the battery or cell.

For discharge rates of C/10 ( $\frac{1}{10}$  of the ampere-hour rating of the cell), set ANv to 2 volts per cell, LFv to 1.9 volts per cell and LNv to 2.2 volts per cell. Shift the values slightly lower for higher discharge currents and slightly higher for smaller discharge currents.

For alkaline and carbon-zinc cells, an ANv of 1.2 should give plenty of low-battery notice before battery voltage drops sharply.

The output of lithium cells varies from 2.6 to 3.6 volts, depending on cell type. Like Ni-Cd cells, lithium cells have a flat discharge curve with




Fig. 5. The wiring diagram for the pc board.

a sharp drop-off when cell capacity is low. For lithium cells, set ANv to about 90% of specified cell voltage.

Since alkaline, carbon-zinc and lithium cells are not rechargeable, over-discharging is not a concern, but you may want to include the load-disconnect circuit to prevent your load from attempting to operate on less than its recommended supply voltage. If you do not need the loaddisconnect circuit, eliminate R1, R2, R3, R9, Q1, C1 and S1, and connect jumper wires where R3 would connect and between the points where the emitter and collector of Q1 would connect into the circuit.

A final consideration is temperature. The voltage of most batteries drops slightly as temperature drops below room ambient. If your circuit will be used at low temperatures, you may want to slightly lower your alarm and shutoff voltages to take this into account.

#### Construction

There is nothing critical about the construction of the Low-Battery Alarm. Therefore, you can use just about any construction technique that suits you, including printed-circuit board, point-to-point soldering and Wire Wrap. One admonition, though: Do *not* use small-diameter Wire Wrap wire for connections between LOAD, QI and BI unless load current is less than 100 milliamperes. Shown in Fig. 4 is the actual-size etching-and-drilling guide for the pc board for this project. In Fig. 5 is

shown the wiring guide for this board. If you use point-to-point wiring, use Fig. 5 as a rough guide to component placement.

Since the Low-Battery Alarm is meant to be an add-on to another circuit (LOAD and its battery supply), how and where you mount the circuit-board assembly will vary. A separate enclosure for the Low-Battery Alarm is not necessary but can be used if desired. If used, LED1 can be mounted on the circuit board. Alternatively, you can mount it off the board for better visibility (on the enclosure of the project or product in which the project is installed, for example) and connect it to the circuit board with hookup wire.

Decide whether you want audible alarm BZ1 or visual indicator LED1 and R8, and use the procedure described above for calculating resistor values for your circuit.

If you are using a pc board, fabricate it using Fig. 4. Then install and solder into place sockets for IC1 and IC2 and follow up with the rest of the components.

Use hookup wire to connect B1 and LOAD to the circuit. Prepare three lengths of wire. (The exact lengths will depend on your circuit and battery supply, how these are arranged in their enclosure, and where the low-battery alarm will mount.)

Listings and database

for major BIOS types

Dever Supply LEDs

E For IBM AT & comp-

Only \$59.00

Comprehensive

plug Included

Only \$89.00

**Diagnostics and Utilities** 


Universal Loopback

Identify Addresses

MicroSystems Development 4100 Moorpark Avenue, #104 San Jose, CA 95117

Fax: (408)296-5877

atibles including Compaq



# Affordable 8031 Development

Single Board Computers, Assemblers, Compilers, Simulators, and EPROM Emulators. Ask about design and manufacturing services for your product!

The Control-R series of single board computers make prototyping and one-of-a-kind projects easy and affordable. Both feature 8K EPROM, RS232 port, Port 1 & 3 access plus:

Control-R Model 1 \$49.95 5vdc operation, 3"x4", assembled.

Contrl-R Model 2 \$79.95 Model 1 features + 8K RAM and expansion bus. 3.5"x4.5"

8031 "C" Compiler \$200.00

Full featured K&R style C development system includes compiler, assembler, linker, documentation and complete library source code. High level language plus in-line assembly code gives you the best of both worlds, 5 memory models allow code generation for any 8031 design-even those with no external RAM! MSDOS 360K disk.

**Cottage Resources Corporation** Suite 151, 10271 South 1300 East Sandy, Utah 84094 USA VISA/MC, COD. Call to order: (801) 269-2975 Strip ¼ inch of insulation from each end of the wires and solder one end of each to pads B1, LOAD and GND on the pc board. Then plug ICl and IC2 into their respective sockets.

#### Checkout & Use

If you have a variable-voltage supply available, you can test your circuit before installing it permanently. To do this, use alligator-clip jumpers to connect your variable supply to the BI and GND wires on the pc board and connect your load (or a substitute, such as a LED and currentlimiting resistor similar to R8 and LED1), from LOAD to GND on the circuit board.

Adjust the power supply to the desired LMv, and the load should be powered. Slowly adjust the supply voltage downwards, and your alarm should sound or flash when the output voltage of the supply drops to ANv. Continue to adjust downwards, and verify that the load and the alarm switch off at LFv.

If you experience problems, verify that your wiring and component values are correct, using Fig. 2 as a reference.


When all appears to be okay, install your Alarm circuit permanently. Disconnect the normal + battery connection for the LOAD circuit (if any has been wired previously), and solder the free end of your LOAD wire in its place. Solder the free ends of the wires to Bl and GND to the + and connections of your BI supply.

When wiring is complete, mount the Low-Battery Alarm in the device it will monitor and install the battery. Now when battery voltage drops, your alarm will warn you. And if you ignore the alarm, the load will automatically disconnect until a safe battery voltage returns.



Jan Axelson

**CIRCLE NO. 93 ON FREE INFORMATION CARD** 



 
 3279
 \$36.95
 2613P
 \$17.

 All books are hardcover unless number is followed by a "P" for paperback.

A shipping/handling charge and sales tax will be added to all orders. If card is missing, use this address to join: ©1992 ELECTRONICS BOOK CLUB, Blue Ridge Summit, PA 17294-0810 2883P \$18.95

(Publishers' Prices Shown) © 1992 ELECTRONICS BOOK CLUB

3145P \$12.95

# WInvoice: Time & Billing for Windows

By nature, computers excel at quick manipulation of the tedium of data. This means that they are accurate, or can be, depending on the software that drives them. Accuracy is a quality that's mandatory in all forms of business.

After assigned work is done for a customer, say your customer, an invoice must be sent. The invoice should contain a detailed accounting of time, charges and materials, if any. Large businesses normally have hard and fast (and usually expensive) procedures in place that take care of time and billing. Smaller businesses, too, know the need for accurate billing but can have trouble tracking the right information all the time. If your business is wasting time, losing money or aggravating customers because of poor time and billing, a product named WInvoice can help.

WInvoice is specifically a time tracking and billing software program the runs under Microsoft Windows 3.0. It's simple to install, as is generally the case with Windows applications, and is surprisingly complete in scope.

During installation, you can customize some aspects of *WInvoice*. One of the customizable items is Terminology. It defines, on a system-wide basis, the kind of language used to refer to customers, professional workers, job activity, and so on. Terminology is important because you have to define your environment before you can build it—which is organization.

To illustrate, a business that provides medical services might use the terms Patient for customer, Physician for worker, Procedure for work done and Program for assigned project. To a worker who is routinely involved in medical services, the above terminology is self-explanatory. On the other hand, legal services might have terms more like Client, Attorney, Activity and Matter. *WInvoice* has a list of readyto-use terminology so that you don't have to spend time creating definitions.

The first thing to do with *WInvoice* is add new information to build a database of clients, professionals, activities and projects. If you already have a large client base, it might take a long time to enter all your data into *WInvoice*. But if you want to turn everything over to *WInvoice*, some initial work has to be done. *WInvoice* has some import and export facility.

Users of TimeSlips can look forward to

lime


-30

Sugram Manager


delta.

Que

na john Cancel



Setting Winvoice terminology.



A sparse but important Address Book.

Handy tools: Rolodex and Timer.

Window Hel

1-0

Writer

Salsberg, Art

larm thi	t View Rep	Winvoice offs System Window H	lerigi	
e	Files		ine III	-1
	- 43 	Billing options Computed call None	Hore 2002000 Houas 600.000 front Female	
₩		Hoursdawy method Maximum Talladar Sociala Balladar Sociala Balladar Sociala	C. Lawahie Down to 174 Na UR 00 198 00 \$1600 00	
\$		Dute Errom 01/04/%2 Eromments	to 01/04/92	
		Wouldn't it her great if water much asserption one activity Some	2	4

Example of a Time Forum. Actual data shown is imaginary.

a special conversion utility that changes *TimeSlips* data into *WInvoice* data. The utility goes to beta test at the time of this writing and will be available in a future release of the product.

Data from other sources might be indirectly converted through use of a commadelimited ASCII file. If your present system can save its database in this format, *WInvoice* can read it. The catch with ASCII imports is that the format you create in *WInvoice* must exactly match your ASCII file. Chances are that when trying to move a large client database in this manner, you'll have to do careful planning and then some alert housekeeping before a transfer is perfect.

Another utility feature of *WInvoice* lets users set defaults for client billing. You can specify default rates of payment, minimum billable hours and even the preferred method of rounding used to calculate untidy fractions of hours. Furthermore, certain dollar amounts can be set for other expenses incurred, like tolls, parking, mileage or any charges normally incurred in your kind of work. For example, computer consultants will have charges for long-distance telephone calls and floppy diskettes. A default rate can be set for these. If need be, all defaults can be overridden.

#### **Important Forms**

Documentation is also very important in the business world. Therefore, businesses like to have a form for just about everything. *WInvoice* has three different kinds of forms: Time, Expense, Fixed Charge.

Time forms are most common. They take care of normal billing at a certain rate of pay. Expense forms document additional expenses while doing a job. Fixed charge is for a one-time cost of something related to the main job. All these forms are managed by *WInvoice* so that documenting potentially numerous items during long term assignments is made much easier.

Once a job assignment is finished, an invoice is issued. *WInvoice* automates creation of the invoice. The invoice lists all the proper forms with all the correct information and totals. At this point, you can group together certain items to enhance orderliness.

The automated invoice scheme uses a color-coding system to easily identify one client from another. If you don't like the color system, you can opt not to use it. The automatic invoice method is good for quickly coming up with a detailed invoice. But if you want to spend more time on it, or you don't like the automated format, you can customize an invoice to your own preferences. Then before the invoice is finalized, you can check it for accuracy.

WInvoice also handles the unpleasant business of credit memorandums, partial payments, refunds, late fees and writeoffs. Credit memorandums can be viewed as negative invoices. When a WInvoice invoice is finalized, it can't be changed or deleted. So you must be absolutely certain of accuracy before finalizing it. When you need to reverse a finalized invoice, a credit memo effectively cancels the invoice and keeps track of what it's doing.

Partial payments are common in the business world and exist often as standard parts of business contracts. *WInvoice* tracks these, too. You can include type of payment made, along with check or creditcard numbers.

#### Reports

Organizing data in various ways helps to get a better picture of what you and your business are doing. *WInvoice* reports both paid and unpaid invoices and other items. One report is the Age Trial Balance report, which identifies all transactions during the period based on the invoice itself. This is called aging. Unpaid invoices are aged according to due date.

A Cash Receipts report lists all payments, early payment discounts and writeoffs. A Client Analysis report summarizes period-to-date and year-to-date information for each client. You can select specific clients, all clients or a group of clients.

As you can see, there are reports for various usage, and they can become quite detailed. The right report at the right time is worth its weight in bank notes. *WInvoice* gives you wide latitude on reporting.

A few more *WInvoice* features need mentioning. Its Address Book stores a lot of information about your clients. Its Rolodex stores information about workers in your company. An especially handy extra feature is the Timer, which is simply a *Windows*-based stopwatch you can use to accurately track time-sensitive activities. Using the clock wisely will ensure precise billing so that you can conscientiously render fair work for cost. The Timer is started, stopped and reset at the click of a mouse button.

In traditional *Windows* fashion, all the various *WInvoice* functions run in windows that can be sized, enabling you to jump from one task to another. So you can jump from Work Forms to the Timer to Expense Form without trouble.

All this *Windows* graphical magic especially helps when managing a large client base with a large pool of professionals. This is when the Rolodex, Address Book and the Activity List save time. But if you

#### Fact Box

WInvoice, \$279 Infinity Software 5215 N. O'connor, Ste. 200 Irving, TX 75039 Tel.: 214-556-1395; fax: 214-556-1483 Requirements: Microsoft Windows 3.0 with 2M of RAM, hard drive and mouse.

#### Evaluation

Documentation	Good
Graphics	Windows-dependent
Learning Curve	Short for computer-
	literate users with
	accounting
	experience
Complexity	Windows graphical
	interface
CIRCLE NO. 159 ON I	FREE INFORMATION CARD

have only a few clients or professionals, you could find yourself clicking up empty pages before finding a lonely name or address. If this prospect bothers you, turn the default icon presentations into straightforward line-by-line listings.

A recent upgrade to *WInvoice* offers more features. Users can now send monthly account statements to clients. If a statement isn't really needed at the time, a simple mentioning of previous balance can be sent instead.

For the professional who has a laser printer, WInvoice prints forms in dazzling Windows font. If you don't have a laser printer, you can still use whatever fonts your printer will handle—they just won't look as good as when printed on a laser printer. Something like font improvements may seem small to some users, but this kind of improvement shows that Infinity Software is responding to user needs.

Do you run a business? Is your somewhat inept tracking and billing procedure wasting valuable time and effort that could be spent elsewhere? It's easy to let a haphazard billing system get out of control. *WInvoice* helps to tame the ill nature of time and billing. It does so at a price that won't send you into bankruptcy.



### Joseph Desposito



A Sleep-Mode Op Amp; a New A/D Board for the PC/AT; a Fast SCSI Controller; a 14-ns RAM Cache; and a Programmable Multiplexer

Semiconductor companies are always looking for new ways to extend battery power, without trading off performance. This month's first device showcases Motorola's new Sleep-Mode<sup>TM</sup> that circumvents previous design limitations by allowing the chip to operate fully only when it's needed.

#### Sleep-Mode Dual Op Amp

Motorola's (EL340, 2100 Elliot Rd., Tempe, AZ 85284) dual Sleep-Mode operational amplifier IC offers two separate modes of operation, resulting in very low standby power operation. In "sleepmode," the MC33102 op amp operates at a very low current drain. Each amplifier automatically changes to "awakemode" when an input signal is applied to the amplifier, causing it to sink or source sufficient load current. The dual Sleep-Mode amplifier uses industry-standard pinouts, and each amplifier has independent sleep-mode capability, with no extra pins or external components required (see Fig. 1).

The MC33102 will find use in a wide range of applications, including consumer products, cordless telephones, portable computers, automobiles, sensors, handheld equipment, cordless appliances, baby monitors, tape recorders and battery-operated test equipment. Key applications will require improved energy efficiency, where the amplifier can operate in a mode that consumes just enough power to detect incoming signals and then shift to a higherperformance mode upon demand.

The MC33102 is the first product to incorporate newly-developed Motorola Sleep-Mode technology, which is also being applied to other ICs typically used in low-power applications.

Other key product features and specifications include: changes from sleepmode to awakemode in 4.0  $\mu$ s when output current exceeds 160  $\mu$ A; automatic return to sleepmode when output current drops below threshold; use as a fully functional micro-power amplifier in low-current sleepmode state; independent Sleep-Mode function for each op amp; no deadband crossover distortion as low as 1.0 Hz in awakemode; ESD clamps that protect the inputs, increasing reliability without affecting amplifier performance. ė

ę

ŵ

5

This Sleep-Mode device will also be available from Motorola's Military Products Operation. It's fully qualified under Mil-Std-883 for use over the full military temperature range.

The MC33102 is presently available for commercial applications in both eight-pin




Fig. 1. Motorola's MC33102 Sleep-Mode op amp operates on very low current drain.

plastic DIP and SO-8 surface-mount packages.

Pricing for either package option is \$1.60 each in quantities of 10,000 and up.

To gain a better understanding of Motorola's new Sleep-Mode, you need to consider that many operational amplifiers are designed to consume very low drain current. With their fundamental design limitations, they typically have poor frequency response and low output-current drive capability.

In many applications, an amplifier isn't required to drive the output load continuously. In these applications, power is wasted while maintaining the amplifier in a maximum performance state during periods when it would be sufficient to operate the amplifier in a lower power-consuming standby mode. From a system viewpoint, it's more energy efficient to operate in a mode that consumes just enough power to detect incoming signals and subsequently shift to a higher-performance mode on demand.


Motorola's Sleep-Mode technology is designed to overcome the low-power-consumption-versus-high-performance dilemma for applications where better frequency response and higher current drive are required only part of the time.

As Motorola's first integrated circuit incorporating this new technology (for which a patent application has been made), the new MC33102 Sleep-Mode dual operational-amplifier IC functions in either of two distinct current/performance states. This device minimizes current consumption in sleepmode state (typically, 45  $\mu$ A per amplifier) until an input signal is detected that requires the amplifier to source or sink 160  $\mu$ A or more. Once this condition is detected by the amplifier, it transitions to awakemode within a few microseconds. Each amplifier consumes approximately 750  $\mu$ A when operating in awakemode, with a  $\times 10$  improvement in bandwidth and slew rate.

When the input signal is removed, the amplifier returns to sleepmode following a delay. An on-chip delay circuit prevents the amplifier from returning to sleepmode at every "zero-crossing" of the output voltage waveform. This delay circuit also eliminates crossover distortion, which is a problem in most conventional low-power amplifiers. Frequencies as low as 1.0 Hz can be processed without the amplifier returning to sleepmode condition.

#### A/D Board Samples Simultaneous Channels

Many applications need multiple analog channels sampled at exactly the same time. Examples include phased sonar arrays, correlation from multiple receiver chan-



Datel's PC-414A analog input board provides four simultaneous sample/hold amplifiers multiplexed into a 1.5-MHz 12-bit A/D converter and is optimized for A/D continuous non-stop streaming of millions of data points with no sample loss to PC/AT memory.

nels and de-skewing of simultaneous signals. The Datel (11 Cabot Blvd., Mansfield, MA 02048) PC-414A analog input board satisfies these requirements with four simultaneous sample/hold (SSH) amplifiers multiplexed into a 1.5-MHz 12-bit A/D converter. Board design is optimized for A/D continuous non-stop "streaming" of millions of data points, with no sample loss to PC/AT memory.

A/D data is passed through an on-board, first-in, first-out (FIFO) 4K memory and then to the PC/AT bus. The board can be installed in IBM-PC/AT, PS-30, EISA and compatible host computers.

The PC-414A's analog input section is designed for low noise and excellent harmonic characteristics to -72 dB THD. FIFOed analog data can be sent to RAM memory, tape, RAM disk or hard disk using DMA or block transfers at greater than 1 MHz speed. A/D output data can also be sent from the FIFO through an onboard parallel port at rates of up to 4 MHz. This port completely offloads the PC/AT bus and can be used as a "front end" to array processors or other vector math systems.

For precise A/D triggering in DSP applications, crystal-stabilized software-programmable on-board counter/timers control the A/D sample rate, number of samples and frame rate. External analog or digital triggers can also be accepted. Analog triggers use an on-board comparator and D/A converter to set a threshold trigger level. The 12-bit D/A converter can also be used as an analog output channel. The PC-414A is ideal for filling blocks

The PC-414A is ideal for filling blocks

greater than 8M of extended memory without sample loss. In four-channel mode, each input channel may be continuously sampled at 250 kHz. Single channel sampling extends up to 1.5 MHz. Typical applications include long baseline studies in astrophysics and precision high-resolution image scanning.

Optional software includes a windowed setup-and-go program to save data to disk or memory and the *PC-DADiSP* windowed graphics DSP display and math package. A source code library is available. The PC-414 includes a comprehensive user manual with software examples.

The PC-414A uses + 5 volts dc at 3.5 amperes from the PC/AT bus. Pricing starts at \$1,850 in single quantity. PC-414SET setup software (executables only) costs \$95; setup source code with the window library (PC-414SRC) is \$395; and graphics DSP-math package (*PC-DADiSP*) is \$1,695.

#### Fast SCSI Controller

NEC Electronics' (401 Ellis St., P.O. Box 7241, Mountain View, CA 94039)  $\mu$ PD72611 is a fast Small Computer System Interface (SCSI) for 32-bit CPU-based systems. It supports a maximum datatransfer rate of 10 M/s over an eight-bit SCSI bus. The product also provides a selectable host bus for support of 32-, 16-, and 8-bit widths.

In addition to the width-selectable host bus and fast data-transfer rate, the  $\mu$ PD72611 also provides an on-chip arbitration sequence control. This allows it to



"Chip" experts agree with Dr. Munk. TECI's PC based microcontroller development tools are the most cost effective for veterans or beginners.

Ľ TECE CALL TOLL FREE 1-800-336-8321 The Engineers Collaborative, Inc. Rt #3 Box 8C, Barton, TEL:(802)525-3458 VT 05822 USA FAX:(802)525-3451 CIRCLE NO. 85 ON FREE INFORMATION CARD Computer Science ALL COURSES BY CORRESPONDENCE Increase your earning power AMERICAN Join students from leading INSTITUTE computer companies Ada course available COMPUTER For free information call SCIENCES





be used as either a SCSI initiator or a target.

Other features include a 24-bit transfer counter and FIFO for high data throughput. On-chip single-ended SCSI bus drivers and Schmitt-type receivers minimize space and overall system cost. Differential drivers are supported externally.

NEC has reduced the host overhead required for interrupt servicing by incorporating its proprietary "Complex Commands" feature. These compound SCSI commands are issued by the controller and incur only one interrupt to the host throughout the entire process. In addition to Complex Commands, the  $\mu$ PD72611's tag-queuing scheme optimizes file and resource management by allowing the host (or target) to assign individual tags to each SCSI operation.

The  $\mu$ PD72611 was designed specifically for 32-bit CPU applications. Due to its width-selection capability, it can also be used in 8- and 16-bit designs. The microcontroller is EISA compatible and provides necessary features for PCs, voicemail systems and networking applications.

An EISA-style demo board and DOS device drivers are offered by NEC. The support tools are intended to assist engineers in both design and evaluation stages of system development.

The controller is packaged in a 100-pin plastic quad flat pack and is priced at \$17.50 each in 10,000-piece quantity.

#### Fast Cache RAM

Cypress Semiconductor's (3901 N. First St., San Jose, CA 95134) 14-ns 256K BiC-MOS cache RAM is customized to attain the fastest available cache memory performance for 486 machines. The synchronous  $32K \times 9$  CY7B173 cache RAM delivers zero-wait-state memory access needed by systems designers to unleash the full performance of 50-MHz, i486-based systems. The CY7B173 integrates a high level of control logic with the cache RAM, allowing designers to eliminate performance bottlenecks and the cost, design-time and board-space penalties of external logic in cache systems.

Specifically, the CY7B173 sweeps the i486 burst counter, address and data registers and synchronous, self-timed write logic all on-chip. On-chip decoding logic simplifies expansion from one bank of four devices (128K bytes of cache) to two banks of four devices (256K bytes of cache) with no performance penalty.

This chip provides caching at 50 MHz through a combination of fast 14-ns access times and a glueless interface to the i486, cache controller and system clock. Separate pins for processor and cache controller address strobes enable the CY7B173 to switch control from the i486 to the cache controller during cache misses. Because the i486 doesn't relinquish control to the cache controller during cache misses, designers using previously available cache RAMs required external logic to accomplish this. By eliminating this multiplexing logic, the CY7B173 enhances system performance.

Cypress also has a 14-ns synchronous BiCMOS TTL cache RAM that supports linear burst sequences. The CY7B174 is designed to support the burst sequences of such CISC processors as the Motorola 68040/30 and Intel 80960CA up to 50-MHz. For RISC processors operating at up to 50 MHz, the CY7B174 delivers the speed to complete a new access each clock cycle.

The CY7B173 and CY7B174 are each priced at \$69 in 100-piece quantities.

#### 12-bit DAS With Programmable MUX

Maxim Integrated Products' (120 San Gabriel Dr., Sunnyvale, CA 94086) new MAX180 is a complete 7.5- $\mu$ s (100-kHz sampling rate) data-acquisition system (DAS) that combines a 1/2 LSB integral nonlinearity (over temperature) 12-bit analog-to-digital converter (ADC), wide-bandwidth (6-MHz) track/hold, 25 ppm/°C voltage reference, fast parallel  $\mu$ P interface and Flex-Mux (Maxim's flexible eight-channel analog multiplexer), all in a single package.

Flex-Mux allows independent programming of each channel for differential or single ended, unipolar + 5-volt or bipolar  $\pm 2.5$ -volt operation. Maxim's monolithic CMOS design reduces power consumption (110 mW), component count, cost, board space and design time.

For applications requiring signal conditioning, such as programmable-gain amplification or filtering, Maxim's six-channel version of the MAX180, the MAX181, gives access to the Flex-Mux output and the ADC's input.

Track/hold's full-power bandwidth permits undersampling of periodic signals with bandwidths exceeding the ADC's sample rate. The systems offer a reference input supplied by either an internal reference (reducing package count) or an external reference (providing optimum reference selection). Internal reference value and system offset are adjustable to allow nulling the overall system offset and gain errors. The control logic interfaces to either 8- or 16-bit-wide data buses.

The entire system is fully tested and guaranteed for both dc and dynamic applications and operates with +5- and -12-to -15-volt dual supplies.

Both devices are available in 40-pin DIP and 44-pin PLCC packages. Prices start at \$17 in 1,000-piece quantities.

# Joseph Desposito



## GeoWorks–Windows for the Rest of Us?

If you've been following this column for a while, you know that I've somewhat reluctantly bought into Microsoft's Windows. I say reluctantly, because even though I really like using some of the newest applications, many of which are available for operation only under the Windows environment, I'm not all that pleased with Windows itself.

Introduced with the largest advertising budget—\$10-million—ever targeted for a single-product launch, *Windo ws* 3.0 was supposed to make an MS-DOS-based PC as easy to use as a video game (or a Macintosh). Perhaps it succeeded in this (though I've never found my kids' Nintendo all that easy to play), but the price, in terms of machine resources needed to run *Windo ws*, is considerable. *Windows* will run on a 286 AT-class machine, though not in enhanced mode. But unless it's zooming along at 16 or 20 MHz, it doesn't run very well or very fast in an AT.

What do you do if you have an older PC, say an XT or an original AT, and want the advantages a graphical environment offers? You could upgrade your system with a new motherboard, or if it's a 286, with one of the new 386SX processor replacements. This will let you run *Windo ws*, but it will cost a minimum of several hundred dollars—before adding any software.

If it's just the graphical environment you want, and not specific applications like *PageMaker, Excel* and *WordPerfect* for *Windows*, you might consider *GeoWorks Ensemble*. Like *Windows, GeoWorks* provides a graphical user interface, called PC/GEOS, that offers WYSIWYG (What You See Is What You Get) equivalence between the output of an application and what's displayed on-screen. It also offers an icon-driven graphical interface that, while not identical to the one in *Windows*, is very easy to use, as well as the same type of accessories offered in *Windows*.

The big difference between the two packages, though, is that *Geo Works Pro* goes a bit beyond *Windo ws* in the accessories it offers, such as Borland's *Quattro Pro Special Edition* spreadsheet, and does it while requiring quite a bit less in the way of CPU resources. PC/GEOS runs on just about any MS-DOS PC, even the original 8088-based IBM XT. Of course, it runs much slower on a 4.77-MHz XT than it does on a 33-MHz 486, but it does run on the slower CPU, fast enough to be usable.

In its almost universal applicability to the Intel-based PC line, *Geo Works*' PC/ GEOS is more like the Mac's original operating system (consisting of System and Finder) than *Windows*. Until Apple released the last version, called System 7, the Mac's System and Finder ran on any Mac, from the earliest 128K machine to the most recent Quadra tower. The multi-tasking version, called MultiFinder, required more memory than the original Mac offered, as does System 7.

In at least one other way, PC/GEOS is more like the original Macintosh than *Windows*. As with those Macs running just System and Finder, it isn't a multitasking operating environment. *Windows*, on the other hand, can perform multitasking in enhanced mode. *GeoWorks Pro* can, however, work with MS-DOS 5.0's Task Switcher, should you want to put one application on hold to run a second task.

#### Easy Installation

Installing Geo Works Pro is easy, but there are a few caveats you should be aware of before you start. PC/GEOS, the operating environment part of the package, doesn't require much in the way of machine resources. It will run on a plain-vanilla version of the original 4.77-MHz 8088 PC with at least 512K of RAM. It doesn't need a full 640K of DOS-addressable memory, though it will run a bit faster with it, or the large amounts of expanded memory required by Windows.

Nor does *GeoWorks Pro* require an EGA or VGA display card and adapter. It will run with monochrome graphics or a Hercules card if that's what you've installed in your system, though the VGA screens are much more readable and much closer to actual output.

What Geo Works does need, though, is disk space—and lots of it! The documentation, some of which is for the original Ensemble, varies on this exact requirement from 3M up to the 7M requirement printed on the software's box. The packaging also notes that 9M of disk space is recommended. When I tried installing the entire package on a Bernoulli drive with a bit more than 10M of free space, I got a message that Quattro Pro SE couldn't fit. I installed



Quattro onto a different drive, but it's a good idea to budget at least 12M to 14M of disk space for *Geo Works Pro*, especially if you intend to use both the spreadsheet and word processor. Remember, both applications also create data files (documents and worksheets) when used. In comparison, *Windows* usually doesn't take up more than about 2M or 3M of space on a hard disk.

Installation takes about a half-hour, 20 minutes of which are spent inserting the four installation disks to copy files to your hard disk. The software is provided on 1.2M high-density  $5\frac{1}{4}$ " floppies. If you need a different format, a card is included in the package for requesting it by mail, and a toll-free 800 number lets you request it by phone. If you have an older system with 360K drives, or one that uses  $3\frac{1}{4}$ " diskettes, don't plan on buying *Geo Works* and installing it the same day. Even if you call immediately for a different disk format, it will take a week or more to receive it.

The earlier version of Geo Works Pro, GeoWorks Ensemble, was provided on 360K 5¼" disks, which greatly increased the disk swapping needed to install the software and added about another 15 or 20 minutes to the installation process. However, considering that a lot of users of older systems will be interested in the product, it would have made more sense going this route than selling a package that can't be immediately installed on many machines for which it will be purchased. Lots of other software products provide both  $3\frac{1}{2}$ " and  $5\frac{1}{4}$ " disks in the package.

On the plus side, GeoWorks doesn't charge you for the new diskettes, nor does the company make you return the original disks, which would add another week or more to the exchange process.

Installation goes very smoothly once you log onto the floppy drive and type INSTALL. Other than prompting you to swap diskettes when necessary, the only other operator interaction comes at the end of the process when the software asks if you want your CONFIG.SYS and AUTO-EXEC.BAT files altered. Too many packages these days blithely make changes to these files without alerting you to what they're doing. You can let Geo Works' installation process make whatever changes it deems necessary, or you can (as I did) look at the proposed changes and accept or reject them. In my case, I let Geo Works increase the FILES statement in my CON-FIG.SYS file and declined having it insert a command that would always run PC/ GEOS on starting up my PC.

Once installed, Geo Works must be configured for your particular system. This is done automatically the first time you run it, either by rebooting the system (if you've specified that the software is always to be run on boot) or by changing to the correct subdirectory and typing in PCGEOS.

The configuration processes asks you to type the program's serial number (found on the registration card), verify the type of video display, specify what type of mouse is connected to the system and choose a printer. Printer support is extensive, with more than 450 different printers from which to choose, including some color PostScript models, though GeoWorks offers no support for daisywheel printers.

#### What You Get

The package touts Geo Works Pro as "The Easiest Integrated Solution for Small Business." Considering what the software provides for a \$200 list, this might not be hyperbole. Firstly, there's the PC/GEOS operating environment. When you first start up PC/GEOS, you're presented with a choice of three "workspaces"-Beginners, Intermediate and Advanced. Each of these varies in the capabilities and utilities it provides. For getting used to Geo Works, the Beginners and Intermediate workspaces are somewhat less complex, but the Advanced workspace isn't really going to intimidate anyone who has used a PC for a few hours or so.

All workspaces are icon-based, and the Advanced workspace also uses the commonly found pull-down-menu approach. If you always want to go directly into a particular workspace, you can set this from the Preferences menu in Advanced.

As with Windows, Geo Works has both small utilities and scaled-down applications. They are somewhat similar, though not identical, to those in Windows, such as GeoDEX, which stores names, addresses and phone numbers. GeoDEX can autodial your phone if a modem is attached and print phone books and address labels. Another utility, GeoPlanner, is a calendar/ scheduler. GeoComm is an easy-to-use communications package that requires a Haves-compatible modem (a special offer for American Online, an on-line service where the official GeoWorks forum resides) is packaged with the product.

I found the foregoing utilities similar in functionality to their counterparts in Windows, but they're a bit easier to use. As with Windows, GeoWorks comes with extensive printed documentation and on-line help. There's even a feature called "GEO-HELP" that can help you on-line with installation problems if you're having trouble getting Geo Works up and running.

GeoWorks Pro does lack several of Windows' utilities, most notably the Macro Recorder, which memorizes keystrokes, and the Notebook, a scaled-down editor. It does offer GeoDraw, a somewhat generic draw program that provides a bit more in the way of file import than Windows Paint. In addition to .PCX and .TIF formats, GeoDraw can handle the .EPS (Encapsulated PostScript) file format that Quattro uses for its charts and graphics.

Where GeoWorks Pro shines is in the


two applications it provides-GeoWrite and Ouattro Pro SE.

GeoWrite is a quite serviceable graphical word processor. It doesn't quite have all the bells and whistles that Word for Windows, WordPerfect for Windows or Lotus' Ami Pro provide, but it does take WYSIWYG word processing a step beyond the Windows Write word processor.

In addition to nine scalable typefaces provided, you can include graphics, create tables and multiple columns and use such text effects as drop outs (white text on black background), colored text and even create title pages automatically.

Lots of document templates are provided, and there's even a banner-making utility. GeoWrite provides multi-line headers and footers and permits complete paragraph formatting. You can import and export text in ASCII format, which provides compatibility with other word processors. Most importantly, GeoWrite has a good 100,000 word spelling dictionary. Many users will find that GeoWrite more than satisfies their requirements in a word processor.

Borland's Quattro Pro Special Edition spreadsheet tops off the package. The Special Edition, or SE, version of Quattro Pro was designed as a high-value, low-cost spreadsheet and normally sells for \$99 by itself. It can read Lotus 1-2-3 worksheet files and offers commands that are largely compatible with 1-2-3. While the size of the worksheets you can create isn't as large



GeoWorks Pro Viewer screen.

as those in more-expensive versions of Quattro (and 1-2-3), they should be sufficient for most users who aren't superheavy power spreadsheet users.

In addition to the spreadsheet, Ouattro Pro SE offers a flat-file database that can give you 254 characters per field, 256 fields and 8,191 records per database. Macros (which are a series of linked commands) are available, and you can link cells in different spreadsheets to produce consolidated reports. Most impressive, though, are Quattro Pro SE's graphics. It offers 14 chart types (variations of bar, pie and line charts), some in 3D. Quattro Pro SE even comes with its own thick manual.

#### How They Compare

I have to admit that I'm very impressed with Geo Works Pro. Not only does it give a lot of functionality at a very reasonable price, it can run on a fairly minimal system. It's also compatible with many networks, such as Novell and Lan Tastic. If the Windows-like applications (Ouattro Pro SE. GeoWrite) and utilities that come with GeoWorks Pro can satisfy your needs, the \$200 list price makes Geo Works Pro a very attractive alternative to Windows.


On the other hand, much of the attractiveness of the Windows environment is the large suite of applications that run under Windows. No similar choice is available for GeoWorks, though the company does offer stand-alone versions of GeoDraw (called GeoWorks Designer), GeoWrite and the utilities (called Geo Works Desktop) with a run-time copy of PC/GEOS, and several font packages. If you just want to try out some of the features and don't need the spreadsheet, this may be the way to go.

The volume of documentation is also somewhat daunting. There are thick manuals for Quattro Pro SE and Ensemble and several smaller booklets for new features added since the last release, customer service policies and procedures, and getting started. While I prefer well-documented programs, it's difficult to figure out just where the answer lies when you have a problem or question about the program.

On the whole, though, Geo Works Pro is a terrific product. It's easier to use than Windows, offers better included applications and will run on many PCs too anemic to support Windows. You'd better have lots of disk space available, though!


GeoWorks Pro, \$199.99 GeoWorks 1218 Massachusetts Ave. Cambridge, MA 02138 Tel.: 617-661-0590; fax: 617-661-0488

**CIRCLE NO. 160 ON FREE INFORMATION CARD** 



# MICONA-196KC for only \$245.00 "16-BIT Personal Controller KIT"TM

**COMPLETE DIGITAL CONTROL SOLUTION** 



**MICONA-196KC offers:** 

1. A HARDWARE KIT containing:

- 1(one) CPU MODULE (3.5"x3.5") with 80C196KC processor (16 MHz), 8 ADC channels 10Bit resolution, 3 PWM outputs (DAC), one DMA channel, 6 High-Speed Output channels, 4 High-Speed Capture Input channels, 40 Digital I/O ports, one full duplex RS-232 serial port;

- 1(one) MEMORY MODULE (3.5"x3") with 64K Memory space RAM / EPROM; - 2(two) Connectors BUS MODULEs;
- 1(one) PROTO MODULE (3.5"x3.5")
- 1(one) Power Supply and
- 1(one) RS232 Communication Cable.

2. A SOFTWARE KIT containing: - PC based SYSMON - System Monitor; - 80C196 Machine Language Assembler; · User's Guide and Application Programs.

MICONA CORPORATION 1885 Surveyor Ave., Bldg. 102 Simi Valley, Ca 93063, U.S.A.

Tel. 1-805-522-9444 Fax. 1-805-522-9779

P.O., Visa & MC accepted. Immediate delivery.

**CIRCLE NO. 71 ON FREE INFORMATION CARD** 





## FREE CATALOG **TESTINSTRUMENTS**& HARD-TO-FIND TOOLS

Packed with over 10,000 quality products for testing, repairing, and assembling electronic equipment. A full selection of test instruments, power protection equipment, precision hand tools, tool kits, soldering supplies, and much more. Products are shown in full color with detailed descriptions and pricing. All products come with a 100% satisfaction guarantee. SAME-DAY shipment program.


In a hurry to receive your catalog?

Call (800) 225-5370 In Massachusetts call (508) 682-2000

Contact East, Inc., Dept. R500 335 Willow St., No. Andover, MA 01845

CIRCLE NO. 59 ON FREE INFORMATION CARD April 1992 / COMPUTERCRAFT / 79

#### The World On-Line By Stan Veit



Portable Wireless Modems, a 14,400-bps Modem, Previewing Software for Free, Going to School on AOL and Virtual Reality

We're rapidly approaching a time when we'll cut the wires from our modems to the telephone and make our laptops truly portable. Motorola has been working toward this for some time and has built internal radio packet modems that work with portables. I was quite impressed with these at the Fall 1991 Comdex. Motorola has reduced the size of these devices by 25%. The new RF Modem, RPM405 Si, is small enough to fit into a Laptop computer and costs no more than the previous models.

Having this portable wireless modem is somewhat like having a cellular packet radio without a repeater—except that the entire infrastructure for radio packet, widearea networks, doesn't yet exist. Also, there isn't even a specification for it. Nevertheless, it's surely coming on fast.

Meanwhile, Motorola is letting no grass grow in this potential goldmine. It has produced *Wave Guide* software that permits development of application links to the wide-area radio-link system. *Wave Guide* lets developers adapt their DOS or *Windows* applications work over radio links. They can also use it to develop communication systems that allows technicians and representatives in the field to access inhouse databases. Motorola hopes this software's Application Programming Interface (API) will form the base for an evolving standard.

Both modem and *Wave Guide* software should be released by the time you read this. However, the complete radio-packet, wide-area network system will take a few years to perfect. Until then, many of its elements can be used for wireless LANS.

Meanwhile, in the world of cabled telecommunications (wired and fiber-optic) the transmission speed rate is rapidly approaching what was previously considered the maximum rate of 19,200 bps. Image Communications Inc., manufacturer of Twincom modems, has announced availability of the new 14,400-bps Twincom 14.4 DF Modem that features 14,400-bps fax and 14,400-bps data rates. This advanced external modem operates at 14,400 bps V.32bis, V.42, V.42bis and MNP 2-5 standards.

#### 14,400-bps Modem

While offering a data throughput to 57,600 bps via compression, the modem is

equipped for auto-fallback and auto-fallfoward to CCITT V.22bis and A/B Bell 212/103. It's supplied with DOS software. For use as a fax modem, the Twincom 14.4 DF operates in both send and receive modes of operation at 14,400 and 9,600 bps. It connects to all fax machines and fax boards and offers background operation.

The modem is equipped for Epson and Hewlett Packard print capture, as well as ASCII, PCX, TIF, BMP and other graphics formats. *Windows* software is available for fax operation.

This new ultra-fast modem is made in the USA using the latest Rockwell chip technology. It's an example of how US innovative technology can lead, given a level playing field.

It should be noted that this speed-advance technology is wasted on most of small fax machines in which input and output are limited by the scanning and printing speed of fax documents. However, for large companies that have a steady stream of fax transmissions and data flow, the rise to 14,400 bps will result in a much-reduced cost per unit. Perhaps this additional rise in modem speed will result in on-line services lowering what they charge for 9,600bps operation.

#### Free Software Preview

Right now, more and more computer resources are available via on-line networks. Ziffnet has just put the Ziff-Davis Software Demos on-line. Any subscriber to Compuserve or Ziffnet can freely download any of the software demos from hundreds of ones that are on-line at any time. The only cost for this service are on-line and telephone charges. The idea of being able to actually see and work with a demo version of a program that interests you is more than worth the tariff.

In addition, you just might download an alternative to the program you set out to investigate and find it better suited to your needs. Previously, these software demos were available only on CD-ROM; to see any of them, you had to buy the entire CD ROM, even though you might be interested in only a few programs.

#### Going to School

The America On Line (AOL) network has

established Programmers U, which offers free on-line courses in programming. It's located in the Developer's Forum section of the Computers & Software Department on AOL. The catalog of courses is growing, and the subjects seem to be exactly what's wanted by tyro programmers.

The current course is ANSI C, which is based on *The C Programming Language*, Second Edition, by Brian W. Kernighan and Denis M. Ritchie. This textbook, which served as the original specification for the C Language, is complete and easy to understand. Almost any compiler for ANSI C can be used for the course.

In addition to being one of the first to put interactive programming courses online, Programmer's U is attempting to provide double tracks for the course, one is for Mac users, another for PC users.

More than 300 people signed up for the C programming course, which led to some confusion at the first sessions. But the wrinkles are being ironed out, and it's to the credit of America On Line and the instructors that they're doing something that has never been done before. This is truly interactive computing at its best.

The interactive format of America On Line is what makes such courses possible. It's hoped that this will be the forerunner of many such educational ventures. If you miss part this course, the lectures will be available for downloading in the Programmer's U Library. Other courses are given in the same format.

#### Virtual Reality

We hear a great deal about Virtual Reality these days. This technique enables one to project into a computer scene as if the viewer were actually part of the action. This is usually accomplished by having the viewer wear a helmet or headpiece that has small CRTs in front of each eye. In simpler setups, stereo glasses equipped with position detectors are used. In addition, the user is equipped with a glove fitted to detect every motion of the hand in six axes. The 3D video and sensor glove give the wearer the sense of being inside a video graphic scene, or in place of a video-generated environment.

The video transmitters could be mounted as oculars of a robot, and the sensor gloves could control the arms and end ef-

fectors (hands) of a remote robot. Thus, an operator could control a mobile robot at a distance and have a sense of being on the scene. This type of operation is still in the future, but the means to do it already exist in current technology.

The reason why so many people are interested in this technology, which seems to be directed at games, is that its development will affect many other fields, like robotics and the development of prosthetic devices for disabled people. The study of virtual reality also offers insight to our perceptual abilities and the way we react to external stimuli.

There are experimenters on the cutting edge of virtual-reality technology who are taking glasses made for video games that are now available from Sega, the manufacturers of video games, and Matell's glove, which was developed for playing Nintendo games. VR experimenters are adapting theses items, available from toy stores, for use with Macs and PCs to produce VR graphics and games.

If you sign onto the Virtual Reality Forum that's part of the Graphics Forums on Compuserve, you can learn more about converting these "toy" devices for use with your PC to experiment with VR. Every Sunday night at 9:00 P.M., there's a conference on Compuserve (Go Comart) at-


**TEACHES:** 

FEATURES:

**OPTIONS:** 

tended by some of the most experienced experimenters in field. Even if you've missed the earlier ones, you can catch up with previous messages because the proceedings of previous conferences on virtual reality are available in Library 13 of the Forum. You can download them to find out what went before. The schematics for converting the eyeglasses and gloves are also available in the Forum libraries.

If you feel there's nothing new for you to take part in because development was in the hands of big companies, get involved in virtual reality. This discipline is just at the stage where the personal computer was in 1975. It combines graphics, communications and programming and represents a challenge to all cutting-edge types. If you just want to experience a similar effect, try the program Virtual.Zip available, for downloading on America On Line in the Graphics Library. This demo does give you the effect of virtual reality with nothing more than VGA.





**CIRCLE NO. 70 ON FREE INFORMATION CARD** 

NOW - THE ALL NEW URDA®, INC. **SDDK-386** INC. **SDDK-386** INC. <sup>3</sup>366 is a trademark of Intel Corporation. Used by permission. **32** BIT MICROPROCESSOR TRAINER AND DEVELOPMENT SYSTEM With optional 80387 Floating Point Coprocessor, 16 Kbytes of EPROM for Monitor, Utilities and User Expansion, 32 Kbytes of Static RAM, 5x8 Metrix Keypad, 40 Character x 2 Line Dot Matrix Liquid Crystal Display with Optional Accesssories. Also available: the 8 Bit SDK-85 and the 16 Bit SDK-86 Coming in 1992: the 8 Bit SDK-51 Microcontroller CALL URDA®, INC. 1-800-338-0517 or (412) 683-8732 URDA®, Inc. Has Additional Single Board Products:

8086 68000 68020 68030 32010 DSP With Cross Assemblers for MS-DOS Computers

**CIRCLE NO. 86 ON FREE INFORMATION CARD** 

## Computer Games (from page 87)

Playing against the clock, as it were, is fine for practice. This is a level of play that's good for gamers who are unfamiliar with data-gathering and Earth-romping. However, increasing levels of stress and subtly urging players to more fervent success is the game's antagonist, none other than the infamous Otto Von Slinkenrat, who secretly plans to keep all the artifacts for himself. It's, therefore, imperative you beat Von Slinkenrat and his buffoons to the punch. Missed clues and unfruitful destinations become much more critical.

Helping lesser-experienced scavengers is a basic map that outlines the travel routes for hopping across states, countries and continents. Its use cuts down guessing and enables a keen player to carefully plot his clue-searching. The map can be an invaluable item in staying abreast of Von Slinkenrat.

Another aid is a Finder's Log that lists all of the hidden artifacts by name. Almost every item available to the imagination is there, from a box of lava rocks to a Yeti footprint keychain—and those are the lesser exotic items.

Comparing BushBuck to Carmen Sandiego, it's easy to see that Carmen is generally a better game. It has better graphics, more integrated documentation and a stronger platform for game execution. Accordingly, a gamer tends to get more involved in game play. This isn't intended as a slight against BushBuck or its designers. It's also a fun game and a welcome complement to the Carmen series. If a players tires of one game, he can go to the other and back again to skillfully prolong the play life of both games.

## Personal Memory Tool

Remember those pesky exams you had to take in high school and college when there seemed to be too many tests and too few hours in the week for preparation? A traditional preparation technique for tests, still used today, is to cram as much data as possible into an overworked brain. Hopefully, during test time something coherent came out.

A better way is offered by *Quiz Control* from Quick Study Software. This educational utility is a helpful software package that can be a powerful memory tool. To illustrate, imagine that you're cramming for an upcoming physics exam. Wouldn't it be great to have all potential test information on flash cards? And wouldn't it be great if family members or friends could ask you the questions and flash the answers? Then you could go over the information as many times as it takes to get everything nailed down tighter than the beam of a helium-neon laser. This sounds great, but it's so tedious to sit down and design a plethora of flash cards that could cover every potential aspect of the test, and it can be difficult to convince even a loving family member to flash hundreds of answers at you.

Use Quiz Control and do it yourself. The software has several optional study sets, including Basic Science, American History, English, Writing Skills and Computer Literacy. As you might expect, most of these ready-made study sets are generic, but it's surprising how dumb one can become after just a few years being out of school. So a brush-up on the basics is a good springboard to specialized disciplines.

Before jumping into Quiz Control, though, there's a problem that must be noted in connection with the ready study sets. The answer given to a question may be correct and still turn out to be incorrect. For example, during one of my quiz sessions on basic physics, Quiz Control put this before me: "The time it takes for 1/2 of radioactive nuclei to decay." The answer to this definition, as any junior high school physics student will tell you, is called the "half-life" of a given material, which was my response. But Quiz Control said I was wrong. A little investigation revealed that my answer was correct but that I'd left the hyphen out of my answer. Other questions fell victim to similar mis-communication. This indicates that Quiz Control's parser needs to be smarter when it comes to using the ready study sets.

A way to beat the problem of mis-communication is to make your own quiz sets, which is pretty easy to do if you use *Quiz Control*. Just gather up your source material, select the items that are likely to appear on your exam and enter the questions and appropriate responses. It may take a couple of hours to get all your information correctly entered. Afterwards, you can cram and flash until your brain locks up. As long as you quiz the right information, you're bound to ace that next exam. Well, if you don't ace it, at least you'll be better prepared.

Uses for this kind of computerized selfquizzing aren't limited to school students. Working adults can use it, too, especially those who work in the rapidly changing field of computer technology. Field engineers and technicians can use it to keep up with new products. Field trainers can tailor their own instruction courses. Whether learning MS-DOS, Unix, Netware or anything else, it pays to quiz yourself. *Quiz Control* makes quizzing a faster and more efficient process.

## Personal Planetarium

Stargazing is a popular hobby that seems to garner more followers each year. Don't look now, but even your next-door neighbor may be housing a little reflector in dark corners of his closet or garage. An astronomy program like *The\_Sky* from Software Bisque can prompt renewed interest and force even ex-astronomers to dust off their old eyepieces (other astronomy programs were reviewed in the June 1991 issue).

The\_\_Sky is a well-written astronomy package that suits the needs of novice and expert astronomers alike, though it tends to favor more avid users who go beyond occasional viewing with binoculars and think a little 3" instrument just doesn't cut the ether. This bias is shown by the program's ability to electronically link to a telescope via data encoders, providing a system that makes it easy to find, identify and observe those intriguing points of light we call stars. The\_\_Sky works especially well with the STG-MAX, which hard-core astronomers will appreciate.

Another feature indicating The\_Sky's leanings toward a more-experienced audience is that users can import databases of their own design into the program for viewing. Custom databases may include information that describes locations and magnitudes for stars, NGC or other objects and even comets. Technical information required for proper placing of custom objects is the kind of data that only serious astronomers would enjoy tracking. Casual

gazers wouldn't want to get as deeply involved as this.

Creating comet data is an interesting item. Values required include those for inclination, period and eccentricity. While needed, star charts and catalogues may or may not give all the information directly. For those times, the included manual teaches users how to calculate unknown values from given values.

A favorite of many astronomers are the Jovian moons. *The\_\_Sky* computes the positions of Io, Europa, Ganymede and Callisto and displays them from one of two views. After plotting, the moons can be set to leave a cosmic tail, clearly indicating orbital path. Additionally, the viewing angle may be widened or narrowed.

The\_Sky has all the nifty features computer users might expect in an astronomy program, such as bright starry display, dynamic scrolling, variable time incrementation, animation of lunar and solar eclipses and common names for stars, planets, Messier and NGC objects. Handy as these features are, sophisticated users kind of expect such utility. The\_Sky offers the utility and further proves its quality and worth with advanced features that would appeal to an enlightened crowd that tracks meteor showers, hand grinds their own mirrors and thrills at the thought of making magnitude estimates and light curves of events like last year's supernova.

More than enough for any amateur stargazer, *The\_\_Sky* works well for advanced astronomers and, with its capability to display more than 10,000 objects, it staunchly holds its own against any competitor. Again, advanced users might like the opportunity to upgrade the initial Level I program or Level II. The advanced levels can display more than 46,000 objects and 271,000 objects, respectively. Clearly, *The\_Sky* is an excellent personal planetarium.

## Typing Tutor

One of the most helpful things I ever did in school was take a typing course. It didn't become apparent how important this skill was to become until my entry into computer technology. Maybe you've had a similar experience. If so, you may be smiling right now for having good judgment. If not, you may be wondering how you can improve your typing skills and get away from the lumbering method called "hunt-and-peck."

The only way to improve your typing is to practice, practice and practice some more. That's easy to do when you're still in school because somebody forces you to do it. At home is another story, though it's



**ORGANIZE AND PROTECT YOUR** COPIES OF ComputerCraft Custom-made titled cases and binders, designed to hold a year's issues, provide the storage system to help protect your valuable copies from damage. Reinforced board covered with durable leather-like material in (color), title hot-stamped in (gold/silver), cases V-notched CASE for easy access, binders have special spring mechanism to hold individual rods which easily snap in. Cases: \$ 7.95 1. \$21.95 \$39.95 6-Binders: 1-\$ 9.95 3-\$27.95 BINDER 6-\$52.95 ComputerCraft Jesse Jones Industries, Dept. Mod-E 499 East Erie Avenue, Philadelphia, PA 19134 Add \$1 per case/binder postage and handling. Outside USA \$2,50 per case/binder. (U.S. funds only.) Please send \_ cases; \_ binders Enclosed is \$\_\_\_\_\_ Charge my: (Minimum \$15) American Express Visa MasterCard Diners Club Card # Exp. Date Signature Charge Orders: Call TOLL FREE 7 days, 24 hours 1-800-825-6690 Print Name Address No P.O. Box Numbers Please City/State/Zip\_ PA Residents add 7% sales tax \_\_\_\_ SATISFACTION GUARANTEED \_\_\_\_

one that can be helped by your own personal computer. The software is *Mavis Beacon Teaches Typing!*.

*Mavis* isn't the first computer-based typing tutor. Also, all typing tutors essentially do the same thing: force you to practice. Unlike the methodology used in schools, computerized typing teachers try to make practicing fun so that you'll actually want to practice. The key difference lies in the technique used.

*Mavis* opens on a classroom setting, complete with chalkboard. This is where you learn proper hand and finger placement and correct keying. On the computer's screen, a pair of shadowy hands work along with you, demonstrating technique. You follow along, typing what you're told to type. The trick is to watch the shadow hands and not your own hands—a difficult but necessary principle to learn.

When you feel confident enough, you can test yourself for speed and accuracy. A time clock, metronome and digital display track your performance. Other performance tests include the Arcade, which correlates typing efficiency to driving a race car. The faster and more accurate your typing, the faster your car goes. If you're good enough you can win the race. Later, if you're on a real hot streak, you can try 10-key.

Ordinarily, one wouldn't expect the manual for a typing tutor to be anything more than just a manual. *Mavis*' manual has all the instructions to run the program, and they're easy to follow. Its tour of the history of typewriting is plain fascinating.

A History of Typewriting kicks off in 1828 with William Austin Burt who came up with the first crude "typographer." The hulking device didn't catch on, though it began an evolution of shapes and sizes. Early models resembled a baby grand piano. Eventually, the portable typewriter showed up in 1891.

The typewriter as we know it wasn't hit upon until Charles Latham Sholes, who was the 52nd man to attempt a design. Sholes' "Type-Writer" was klunky and had a severe problem with jamming keys because the device didn't allow time enough for one key to return to its mooring before another key came up. Sholes addressed the problem in the inimical style of one who prefers a quick fix.

Instead of engineering an appropriate solution he redesigned his keyboard to make it so difficult to type that no typist would get to speeds fast enough to cause key jamming, creating the "QWERTY" system with which we're all familiar. In fact, after going through all the trouble of learning to type, I know some typists who'd like to get into a time machine, go back and tell Mr. Sholes a thing or two.

One valiant soul name August Dvorak

embarked on a redesign of Sholes' convoluted mess of a keyboard. His humanized, more-sensible approach proved to have an accuracy increase of nearly 50% and speed increase of 15% to 20%. Unfortunately, the Dvorak keyboard fell to hard economic times and bad sales ventures, although there has been a modern resurgence of interest in it.

**Bird's Eye View** 

BushBuck Charms, Viking Ships & Dodo

Tel.: 602-730-9000; fax: 602-968-7196

Requirements

512K

Evaluation

Good

Poor

Short

Easy

Easy

In Brief: Fun to play and educational

**CIRCLE NO. 136 ON FREE INFORMATION CARD** 

**Bird's Eye View** 

Requirements

**Evaluation** 

Good

N/A

Short

Easy

Good

In Brief: Easy to operate and very effec-

**CIRCLE NO. 139 ON FREE INFORMATION CARD** 

384K

Text Based

Keyboard

Computer Speaker

world-spanning scavenger hunt.

VGA, MCGA,

AdLib controllers

EGA, CGA

Eggs, \$49.95

Memory

Graphics

Documentation

Learning Curve

Quiz Control, \$49.95

Study Modules, \$19.95 each

170 Hamilton Ave., Ste. 319

**Ouick Study Software Inc.** 

White Plains, NY 10601

Memory

Graphics

Graphics

Complexity

**Playability** 

Controllers

Documentation

Learning Curve

tive aid to memory.

Sound

Sound

Graphics

Complexity

Playability

PC Globe, Inc.

4700 S. McClintock

Tempe, AZ 85282

If you want to learn Dvorak, you can buy a Dvorak-style keyboard or Dvorak templates to go over your QWERTY keyboard. *Mavis* will help you with learning Dvorak, too. But expect to put in extra effort because in typing, its difficult to teach old fingers new tricks.

## Bird's Eye View

*The\_Sky*, \$75; Level II \$99; Level II, \$175 **Software Bisque** 912 12 St., Ste. A Golden, CO 80401

Requirements		
Memory	640K	
Graphics	VGA, EGA, CGA	
Sound	N/A	
Controllers	Mouse	

#### Evaluation

Documentation	Good	
Graphics	Good	
Learning Curve	Medium	
Complexity	Medium	
Playability	Good	
In Brief: Astronomy program that sports		
advanced featu	res for experienced	
stargazers.		
CIRCLE NO 137 ON F	PEE INFORMATION CARD	

#### CIRCLE NO. 137 ON FREE INFORMATION CAI

## Bird's Eye View

Mavis Beacon Teaches Typing!, \$49.95; \$59.95, Windows version **The Software Toolworks, Inc.** 60 Leveroni Ct. Novato, CA 94949 Tel.: 415-883-3000; fax: 415-883-3303 or call Electronic Arts: 800-245-4525

## Requirements

Memory Graphics	512K VGA, EGA, CGA,	
	Hercules	
Sound	Computer Speaker	
Controllers	Keyboard	

#### Evaluation

Documentation	Excellent	
Graphics	Good	
Learning Curve	Short	
Complexity	Easy	
Playability	Good	
In Brief: Effective help for improving		
typing skills; handles both QWERTY		
and Dvorak keyboard layouts.		
CIRCLE NO. 1 ON F	REE INFORMATION CARD	

## Computer Speed (from page 22)

If your computer has a new MCA or EISA bus, cards made for its expansion bus will be able to run at your computer's full speed. But if your computer has an old-style ISA or "AT" bus, you'll have to be concerned with both its bus speed and the speed of the peripherals you add to it. And even if you have cards that can work in a fast bus, it doesn't mean they're running at full speed. Every expansion card can create wait states while it's being accessed if it needs extra processing time.

Another consideration for almost all cards installed in the expansion bus is the number of bits they use for communication with the CPU. Older cards that can work in both an XT and AT, and most serial- and parallel-port expansion cards, restrict themselves to eight bits of communication at one time. These cards fit into a short slot on the AT bus, which matches the original XT bus connector. Bus speed is rarely a consideration with parallelor serial-port cards because the devices you're likely to connect to them, like a printer or modem, are relatively slow and won't use even the limited bandwidth on a slow eight-bit bus.

The bus-based devices that have the greatest effect on system speed are the video and disk controller. If you use graphics-mode programs, including Microsoft *Windows*, your system makes extensive use of the bus to draw on the screen. Even a simple line requires several communications between the CPU and graphics card.

"The video card and disk controller are the two busbased devices that have the greatest effect on system speed."

Font-based characters, icons and other accouterments of a graphics interface require almost constant communication between the CPU and the video card.

If you want to use graphics-mode programs, make sure your computer has a fast bus and that you use a video card that can keep up with the speed of the bus. If you spend most of your computer's time running *Windows*, you may also want to investigate the *Windows* accelerator cards that move many of the required calculations from the main CPU to the video card to cut down on bus use and help the video run faster.

On the other hand, if you spend all your time with monochrome, character-based applications, an eight-bit video card may be all you need. It takes very little time for a program to manipulate character-based screen text because the character generator on the video card does all the work of forming each character.


Most systems also have a hard-disk controller on the expansion bus. Here again, speed is crucial to total system performance. A slow hard disk will make your entire computer seem sluggish, especially if you run large applications that use overlays, virtual memory on the disk or lots of data files. expanded memory format that's on an expansion board on the bus will also be limited to the speed of the bus. For this reason, most modern computers have a special memory bus, usually on the motherboard, that lets the machine use memory much more quickly than the expansion bus allows. Make sure you use all available memory sockets on your computer's motherboard before you even consider adding an expansion memory card.

If you go shopping for the cheapest 386 or i486 computer, you'll probably end up with a cheap computer that doesn't run efficiently. It will be faster than the 80286 or 8088/8086 computer you used before, but you could do better than that.

If you want best possible performance from your computer, make sure all of its components are designed to run at top speed. You may have to do

"If you get the cheapest 386 or i486 computer, you might end up with one that doesn't run efficiently.... Make sure all components run at top speed."

The fastest hard-disk controllers for ISA computers use a full 16-bit-wide data path to communicate with the system. They also include their own built-in disk cache to speed up operations. A hard-disk cache is much faster than a software caching utility because it can fill while the CPU is attending to other tasks. Also, it doesn't use any valuable RAM space for the cache. Extra memory in either extended or some research and ask some tough questions when you go shopping for a computer and/or add-in cards. But you'll end up with a machine that will keep up with your work and the demands you place on it for several years to come. Even if you pay a few extra dollars, you'll be much happier than if you bought a computer that seems slow the first time you give it a challenging task to perform.



**CIRCLE NO. 58 ON FREE INFORMATION CARD** 

HEAR THE TONES..SEE THE NUMBERS! DTMF DECODER/DISPLAY AND ASCII CONVERTER Model TDD-8 decodes and displays all 16 DTMF digits and ovides an ASCII serial output. Digits are displayed on eight LED's 32 character buffer can be scrolled. It will accept LEDS. 32 Character buffer can be scrolled. It will accept almost any audio source such as a tape recorder, telephone answering machine, scanner, etc. **Perfect for remote computer data** entry using a telephone keypad. Serial output can be connected to your computer. IBM compatible software included for displaying, storing/printing time, date and number for automatic logging. Assembled/tested circuit board, ready to use! 30 day money back guarantee! VISA/MC ACCEPTED TDD-8 DTMF DECODER/DISPLAY/ASCII \$99.00 CAB-1 AUDIO & COMPUTER CABLES \$20.00 PS-12 110VAC TO 12VDC POWER PACK \$10.00 PMK-1 PLASTIC MOUNTING KIT \$15.00 Add \$5.00 S/H USA/Canada, \$10.00 foreign MoTron Electronics, 310 Garfield St, #4 Eugene, OR 97402 ORDERS: 800-338-9058 (USA/Canada) INFO: 503-687-2118 FAX: 503-687-2492

**CIRCLE NO. 73 ON FREE INFORMATION CARD** 





**COMPUTER VIRUS SURVIVAL GUIDE** 

Published by THE NATIONAL COMPUTER SECURITY ASSOCIATION

What causes viruses?
 How do they operate?
 What do I do if my computer becomes infected?
 How do I choose anti-virus products?
 What policy and procedures should be implemented?

This 75 page booklet gives managers and users the key facts they need to know about how to Prevent, Detect, Identify, and Recover from Viruses.


FOR YOUR COPY OF "Computer Virus Guide" Send \$7.00 to: National Computer Security Association 227 West Main Street, Mechanicsburg, PA 17055

Don't forget to ask about NCSA's other valuable publications and membership information.

**CIRCLE NO. 75 ON FREE INFORMATION CARD** 

Order Back Issues of

## **ComputerCraft**



B & B Electronics has the most complete line of RS-232, RS-422, RS-423, RS-485, RS-530, and Current Loop interface solutions in the industry. We also sell smart switches, data generators, isolators, cables , and much, much more. If you don't find a solution to your problem in our catalog, contact our technical support department for a custom-designed solution. You will be surprised how affordable it will be.

Write or call for your FREE B & B catalog today!

Phone (815)434-0846

FAX (815)434-7094

Next, still monitoring J3, set the OFFSET switch to IN and vary the setting of OFFSET ADJUST control R3 and note this control causes the dc offset should swing between +10 and -10 volts. This done, power down the Frequency Counter.

To accomplish final adjustment of C15, R4 and R5 through R8 requires use of an oscilloscope. Set the Generator for a sine-wave output and connect the scope to J3. Adjust the settings of R6, R7 and R8 to obtain the most distortion-free, symmetrical waveform possible on the CRT screen.

With RANGE switch S2 set to position 2, set FREQUENCY ADJUST control R1 for maximum output frequency. Follow by adjusting trimmer control R4 until you obtain a peak in frequency and then back off just slightly. Readjust the setting of R1 for minimum output frequency and adjust trimmer R5 to obtain minimum frequency.

If you have a variable dc voltage source, test the SWEEP input at JI by applying -12 to +12 volts to the jack. With RI set to its middle of rotation, the varying voltage at JIshould cause the output frequency at J3 to sweep through its minimumand maximum-frequency range.

To adjust trimmer capacitor C15, disconnect any input to J1 and set R1 for maximum output frequency. Now set S2 to position 3 to select timing capacitor C13. Using a frequency counter or oscilloscope, determine and note down the actual frequency of the signal coming out of J3. Then set S2 to position 4, adjust R1 for the slowest rate and use a non-metallic tool to adjust C15 for an output frequency that is just below that of the previously measured maximum. This adjustment ensures a frequency overlap between the two highest ranges and eliminates possible "missing" frequencies from the selectable ranges. This completes adjustment of your Function Generator.

As you can see from the foregoing, the Function Generator described here provides all the functions and most of the features of a high-precision bench-top instrument. You'll soon come to rely on it so much that whenever you sit down at your testbench, you'll power it up at the same time you power up your oscilloscope and multimeter.

# BushBuck Charms, Viking Ships & Dodo Eggs ... and More



The fanciful title that appears at the head of this review is the name of an interesting scavenger-hunt game. It and the other games considered here are the kind of computer adventures that have something to teach. Children and adults can have fun playing them and learn while doing it. Frankly, this stimulating combination is hard to beat.

### **Global Scavenger Hunt**

Computer users know the name PC Globe, Inc., the software maker that came to fame based on its informative country and world PC USA and PC Globe atlas/almanacs. In contrast with these previous continentspanning databases, its new offering, *BushBuck Charms, Viking Ships & Dodo Eggs*, stretches the concept of world datagathering and bends it into a game similar in concept to Broderbund's farnous *Carmen Sandiego* series.

Normally I don't like to directly compare competing products unless there's a good reason. In most cases where I perform direct comparisons, the reason for doing so is provided by the manufacturer. Such is the case with *BushBuck Charms*. This game compares itself to the *Carmen Sandiego* series (which I reviewed in the November 1991 issue), albeit via advertised words by other reviewers.

BushBuck and Carmen Sandiego are alike in that they both stir up a melting pot of people, places and facts. BushBuck sets gamers as contestants in a global scavenger hunt. Exotic items, like Viking ships and Dodo eggs, are hidden in major cities throughout the Earth. As the contestant, you must use 60 airline tickets as wisely as possible in your world quest. You have to travel to far-flung cities, initially choosing sites on nothing more than a whim. As clues pop up, selection of potential destinations becomes more tactical.


(Continued on page 82)




PC Globe's BushBuck Charms, Viking Ships & Dodo Birds.



Quick Study Software's Quiz Control.



Software Bisque's The\_Sky.




The Software Toolworks' Mavis Beacon Teaches Typing!













## ComputerCraft Mart

**Classified Commercial Rates:** \$1 per word, 15-word minimum (\$15.00) prepaid. (Word count includes name and address; ZIP code and abbreviation each count as one word; P.O. Box number and telephone number count as two words each.) Indicate free category heading (Computers, Software, Electronics, Video or Miscellaneous). A special heading is available for a \$6 surcharge. First word only is set boldface caps at no charge. Add 25¢ for each additional boldface word.

Non-Commercial Rates: FREE to subscribers, as space permits; maximum 15 words. A recent COMPUTERCRAFT mailing label must accompany ad.

(All advertisers with P.O. Box addresses must supply permanent address and telephone number. Copy is subject to publisher approval.)

**Mailing Information:** Copy must be received by the publisher by the 25th of the third month preceding the cover date. Send Advertising material with check or money order or credit card information (Visa or MasterCard only) with number and expiration date to: **COMPUTERCRAFT**, Classified Department, 76 N. Broadway, Hicksville, NY 11801.

## COMPUTERS

20,000 + IBM-PC Public Domain and Shareware Programs. 1.2Mb Diskette Catalog -\$3.00. 400 + Page Catalog - \$17.95 (refundable). Individual programs / bulk. TELE-CODE P.O. Box 6426-CC, Yuma, AZ 85366-6426.

**80C52-BASIC** microcontroller board. BASIC interpreter, 32K RAM, 16K EPROM, EPROM programmer, RS232, expansion connector. Bare board with manual, schematics \$19.95 + \$3 P&H. 80C52-BASIC microprocessor chip \$24.95 + \$1 P&H. Assembled and tested \$119.95 + \$5 P&H. MD residents include sales tax. SASE for info. Prologic Designs, P.O. Box 19026, Baltimore, MD 21204.

**IBM SHAREWARE**, latest versions 1 to 10 disks \$1.99, 11 + \$1.49 plus \$3 S/H. Write for flyer: Major Electronics, 2930 Sepulveda, San Bernardino, CA 92404.

3.5" DISKETTE PUNCH. 1.44MB from 720K diskettes! 3.5" DD and HD diskettes are made from the same media. Heavy duty construction! 30 day money back guarantee! \$17.95. We pay shipping! COMPUCRAFT, 9391 Mentor Ave., Suite 113, Mentor, OH 44060. Call (216) 255-7027 Ext 113 for more information.

**IBM** PC AND LAPTOPS VIDEO DIGITIZ-ER, 640 BY 480 RESOLUTION. 256 GRAY LEVELS \$89.98. DEMO DISK \$3, INFOR-MATION \$1. COLORBURST, BOX 3091 NASHUA, NH 03061. PHONE (603) 891-1588.

**ELECTRONIC** Circuit and Construction Project References. PC/MSDOS software database, 1500 circuit and project citations compiled from 5 electronics magazines, 27 years publication. Search by subject or keyword, both disks included, HD required. \$19.95. JRH & Associates, 4255 S. Buckley Rd. 181, Aurora, CO 80013. (303) 699-5835. **QUALITY** SHAREWARE - Diskalog with samples, \$1 (refundable), low prices. Info-Share, Box 176, South Lyon, MI 48178-0176.

ATTENTION TECHNICIANS. If you need to know Tracks, Sectors, Access Time, and MUCH more; Order this Technical Manual. Specifications for over 800 Hard Drives, plus tips and techniques used by technicians in the field. 30 Day Money Back Guarantee. Send \$25.00 to Prism Software, Unit 2, 602 Cook Street, Yukon, Canada Y1A 2R6.

MICROCONTROLLER Kit, complete with its own keypad style programmer. Nothing else required to build and program microprocessor controlled projects. 2K EEPROM and up to 88 I/O and 1K RAM. Instructions and "Help Telephone Hotline" included. Call 1-416-625-7185 for more details or send \$129.00 (US Funds) to: High Tech Of Canada, P.O. Box 41165, 4141 Dixie Road, Mississauga, Ontario, Canada L4W 4X9.

## SOFTWARE

**FREE** IBM PD and Shareware disk catalog. Low prices since 1988! ASP Approved Vendor. Finto Software, Dept CC, Route 2 Box 44, Rosebud, TX 76570.

## **ELECTRONICS**

SURVEILLANCE - COUNTERSURVEIL-LANCE. Guaranteed lowest prices! Unbelievable, Detectors, Jammers, Transmitters, Phone Security, Cameras, Personal Protection, Books, More! Huge catalog \$5.00 (Refundable) PROTECTOR P.O. Box 520294-B, Salt Lake City, UT 84152.

**VIDEOCIPHER II**/Satellite/Scanner/Cable Repair Manuals, Modification Books/Software. Catalog - \$3.00. **TELECODE** P.O. Box 6426-CC, YUMA, AZ 85366-6426.

Say You Saw It In ComputerCraft

CABLE TEST CHIPS. S-A 8550, S-A 8500 -310, 311, 320, 321 (specify) - \$33.95. S-A 8580/338 - \$69.95. TOCOM 5503/07 VIP -\$33.95. TELECODE P.O. Box 6426-CC, YUMA, AZ 85366-6426.

PC MOTION CONTROL KIT -Easy interface to IBM PC. Includes: Stepper Motor, Components, Plans and Software Tips \$29.98. Stepper Motors \$14.98. Send check including \$3.00 S/H to BST Co. P.O. Box 570, Bellingham, MA 02019.

**KENWOOD & ICOM** Service Bulletins. 175 + pages covering all models. \$33.95 Catalog - \$3.00. **CODs** 602-782-2316/ **FAX** 602-343-2141. **TELECODE** Box 6426-CC, Yuma, AZ 85366-6426.

UNITED STATES Frequency Allocations: Radio Spectrum, 32 by 50 color chart shows radio, tv, mobile, amateur, etc. zones. \$7 postpaid. PUBNETIX, Box 1022, Laurel, MD 20725-1022.

PC BOARDS ETCHED AND DRILLED FOR .70 CENTS PER SQUARE INCH. SEND YOUR REQUIREMENT TO JM ELECTRONICS, BOX 150454, ALTA-MONTE SPRINGS, FL 32715-0454.

KITS, LIGHT, SOUND, HIGH TECH AND UNUSUAL. SEND FOR FREE CATALOG. JM ELECTRONICS, BOX 150454, ALTA-MONTE SPRINGS, FL 32715-0454.

**NEW!** Pocket-sized electronic compass instantly and accurately shows direction on its electronic digital display. At only \$59.95 + \$2.50 shipping, get this high-tech version of this ancient device today! Entek, PO Box 72132, Albuquerque, NM 87195.

COMMUNICATION AT ITS BEST. AR-900 \$245, AR-1000XC \$405, AR-3000 \$969, IC-R1 \$549. We also sell a variety of CBs, Radar Detectors, SWL and accessories. FREE SHIPPING. V/MC, Diners. TURBO ELEC-TRONICS, P.O. Box 8034, Hicksville, NY 11802. Questions and Catalogs: (516) 938-1946. Orders: 1-800-33TURBO.

### VIDEO

VHS-VCR Repair Solutions Sets I, II, III, IV, V, VI. Each contains 150 symptoms and cures, updated cross reference chart, free assistance, \$11.95 each all six \$59.95. Eagle Electronics Box A, 52053 Locks Lane, Granger, IN 46530.

TV NOTCH FILTERS PHONE RECORD-ING EQUIPMENT, BROCHURE \$1.00. MI-CRO THinc. BOX 63/6025, MARGATE, FL 33063. 1-305-752-9202.

#### CABLE

ACTIVATE your Jerrold, Tocom, or Zenith Box (Fully) in just minutes. Test chips only \$50.00. No CA. Sales. Orders Call 1-800-452-7090. Information 310-867-0081. **JERROLD** Test chips for Starcom 6 and 7. Installs in just minutes only \$50.0). No CA. Sales. Orders 1-800-452-7090. Information 310-867-0081.

#### CABLE TV EQUIPMENT

CABLE TV converters and descramblers discount center. Jerrold, Tocom, Hamlin, Scientific, Atlanta, Oak, Zenith. Order your today 800-962-6836.

## MISCELLANEOUS

MORSE Code? No Problem. Ycu can increase your speed, no matter how many times you've failed before. Results guaranteed when you follow the instructions. PASS Publishing's CW Mental-Block Buster program helps you explode mental blocks that hold you back. Based on 40 years of research, the C'W Mental-Block Buster uses guided meditatior, dynamic visualizations, and powerful affirmations to blast through mental blocks. You can do code! That means new bands, more contacts, more fun! (This is not a CW practice tape.) The CW Mental-Block Buster audio cassette and practice booklet are only \$24.95 ppd. in the US (NY residents add \$2.00 sales tax). Info: 516-584-8164. PASS Publishing, P.O. Box 570, Stony Brook, NY 11780.

ASIAN LADIES want correspondence for friendship, marriage. SUNSHINE INTER-NATIONAL-Dept. TW, Box 5500, Kailua-Kona, Hawaii 96745. (808) 325-7707.

ATTRACTIVE ORIENTAL LADIES seeking correspondence, marriage. Professional introductions since 1984. Asian Experience, Box 12114TZ, Novato, CA 94948. (415) 897-2742.

COMPUTER PRODUCTS AND ELEC-TRONICS EQUIPMENT. Home and business. Catalog \$3. (Refundable) B&R Enterprise, P.O. Box 662, Portage, MI 49081.

ARE YOU MARRIED and jointly earn less than \$50,000? If so, you can get up to \$1,120 every year from Uncle Sam. This amazing fact in unknown to most people. Discover for yourself today!! Our booklet explains how. To order, please send \$7.50 to TMC Press, P.O. Box 6502, Huntsville, AL 35324-0502. Ask for pub. #302.

#### **IDEAS WANTED**

**INVENTORS!** Can you patent and profit from your idea? Call AMERICAN INVEN-TORS CORP. for free information. Serving inventors since 1975. 1-800-338-5656.

#### FOR SALE

**ZOOM** V.42bis 2400 baud error-correcting modem. Sacrifice \$100. Dan, (301) 498-8915 evenings.



## Advertisers' Index

RS#	Pa	ige #
51	AMC Sales	12
103	Altex Electronics	7
-	Amer. Inst. for Comp. Sci.	76
52	Archon	. 34
94	B & B Electronics	86
54	BG Micro	. 33
-	Binary Technology	. 81
-	Brunelle Instruments	. 88
-	CIE 90,Cov	л. Ш
55	C&S Sales	. 42
-	Cable Ready Company	. 88
56	Capital Electro	
57	Cedar Software	. 68
58	Computer Sys. Architect	. 85
59	Contact East	. 79
93	Cottage Resources Corp	. 68
60	Covox	. 13
88	Data HutCov	. II
61	Design Computation	. 79
62	EMAC	. 81
-	Electronic Book Club5	1,71
-	Grantham	
63	Hampshire Industries	
64	Hoops-Ware	
65	Interactive Image Tech	
66	Jensen Tools, Inc	
-	Jesse Jones Industries	
67	КСР	. 43
-	Kelvin Electronics	
68	Laser Group	
69	Lifeforce Technology	. 54
-	MK Electronics	. 89
70	Merrimak Valley	
71	Micona	
72	Microsystems Development	
73	Motron Electronics	
74	Mouser Electronics	
-	NRI Schools	
75	National Comp. Security	
- 76	Parrallax	
70	Photronics	
78	Pseudo Corporation Praire Digital Inc	.43
79,80	Print Products1	.49
81	R4 Systems	11
82	Radio Shack	
83	Safesoft Systems	34
-	Scrambling News	- 54
84	Sencore	IV
-	Skyvision, Inc	
-	Software Science	
85	Teci	
86	URDA	
87	U.S. Cyberlabs	
140	Unicorn Electronics	
89,90	Vail Silicon Tools	
91	Viejo Publications	
92	Worldwide Cable	

We'd like to see your company listed here too. Contact Eric Teitelbaum or Margaret Milanese at 516-681-2922 to work out an advertising program tailored to suit your needs.

# If You're Serious About a Future in Electronics, Ensure that Future with the Best Educational Training Available.



SEND FOR YOUR CIE HOME STUDY COURSE CATALOG AND RECEIVE A FREE 24 PAGE CIE ELECTRONICS SYMBOL HANDBOOK!

Includes hundreds of the most frequently used electronic symbols. Published by CIE exclusively for our students and alumni. Yours free when you request a CIE Course Catalog.

proced

diagonal in pointer and a second seco

- Monte est

245 547 4

#### Pio 17 Pin diog am his 74151A

- Martin A.
- ......

If you want to learn about electronics, and earn a good income with that knowledge then CIE is your best educational value.

CIE's reputation as the world leader in home study electronics is based solely on the success of our graduates. And we've earned that reputation with an unconditional commitment to provide our students with the very best electronics training.

Just ask any of the 150.000-plus graduates of the Cleveland Institute of Electronics who are working in high-paying positions with aerospace, computer, medical, automotive and communication firms throughout the world.

They'll tell you success didn't come easy...but, it did come....thanks to CIE. And today, a career in electronics offers more opportunities and greater rewards than ever before.

### CIE'S COMMITTED TO BEING THE BEST....IN ONE AREA....ELECTRONICS.

CIE isn't another be-everything-toeverybody school. We teach only one subject and we believe we're the best at what we do. Also, CIE is accredited by the National Home Study Council. And with more than a 1,000 graduates each year, we're the largest home study school specializing exclusively in electronics. CIE has been training career-minded students like yourself for nearly 60 years and we're the best at our subject ..... ELECTRONICS ... BECAUSE IT'S THE ONLY SUBJECT WE TEACH!

## CIE PROVIDES YOU WITH A LEARNING METHOD SO GOOD, IT'S PATENTED.

CIE's Auto-programmed lessons are a proven learning method for building valuable electronics career skills. Each lesson is designed to take you step-bystep and principle-by-principle. And while all CIE lessons are designed for independent study, CIE's instructors are personally available to assist you

with just a tollfree call. The result is practical training... the kind of experience you can put to work in today's marketplace.

LEARN BY DOING...WITH STATE-OF-THE-ART FACILITIES AND EQUIPMENT. In 1969, CIE


pioneered the first Electronics Laboratory course and in 1984, the first Mircoprocessor Laboratory course. Today, no other home study school can match CIE's state-of-the-art equipment and training. And all your laboratory equipment, books, and lessons are included in your tuition. It's all yours to use while you study at home and for on -the -job after graduation.

## PERSONALIZED TRAINING....TO MATCH YOUR BACKGROUND.

While some of our students have a working knowledge of electronics others are just starting out. That's why we've developed twelve career courses and an A.A.S. Degree program to choose from. So, even if your not sure which electronics career is best for you, CIE can get you started with

### WHY CHOOSE CIE FOR YOUR TRAINING?

- 150,000 successful graduates from every country around the world.
- Only CIE rewards you for fast study. CIE offers an Associate Degree program based on actual study time used. The faster you complete your degree the less your overall tuition.
- State-of-the-art laboratory equipment is yours to keep and it comes assembled, ready for hands-on experiments.
- Approved for educational benefits under the G.I. Bill for veterans and other eligible persons.
- Upon graduation, CIE offers free preparation to pass the Certified Electronics Technician Exams.




core lessons applicable to all areas of electronics. And every CIE course you take earns you credit towards completion of your Associate in Applied Science Degree. So you can work toward your degree in stages or as fast as you wish. In fact, CIE is the only school that actually rewards you for fast study, which can save you thousands of dollars.

SEND TODAY FOR YOUR CIE COURSE CATALOG AND WE'LL SEND YOU A FREE 24 PAGE CIE ELECTRONICS SYMBOL HANDBOOK!

<b>YES!</b> I want to get started. Send me my CIE school catalog includ- ing details about the Associate Degree Program. (For your convenience, CIE will have a representative contact you – there is no obligation.)		
Name:		
Address:		
City:	_State:	
Zip:	_ Age:	
Phone No. ( ) Check box for G.I. Bulletin Be Veteran 🗆 Active Duty	enefits	
CLEVELAND INSTITUTE OF ELECTRONICS 1776 East 17th Street Cleveland, Ohio 44114 (216) 781-9400	A school of thousands. A class of one. Since 1934 AO28	



## **Introducing The Only Complete Solution For All Your Monitor Servicing Needs!**








NEC/MultiSync 30



CM2000 Computer Monitor Analyzer Patented - A Sercore Exclusive!

Completely Test And Troubleshoot All High Resolution And Multi-Scan Computer Monitors From The Input Connector To The CRT... Guaranteed!

The Only Analyzer That Helps You Pinpoint Defects In All Computer Monitors!



Call 1-800-SENCORE ext. 506

Here's What The CM2000 Offers You:

- · Complete High Resolution Computer Monitor Analyzing
- Fully Programmable Scan Rate And Pixel Resolution
- Innovative Performance Testing Patterns
- Special Sync-Locked Substitution Signals
- Patented "Ringer" Test To Dynamically Analyze All:
  - Yokes
    - IHVTs/Flybacks
  - Switching Transformers
- Integrated 2,000 DCV And P-P Meter
- Exclusive "Hook-up" Adapters Available For All Popular Monitors
- Portable Troubleshooting For All Your Field Service Needs

3200 Sencore Drive, Sioux Falls, South Dakota 57107

CIRCLE NO. 84 ON FREE INFORMATION CARD