# ELECTRONI VOORLD FEBRUARY 2006 \$4.50

## SPECIAL REPORT: EMC

Calculate Reliability in Power Amplifiers

New Generation of Video Encoders





# DIGITAL STORAGE OSCILLOSCOPES



To see our full range of high quality wireless test equipment covering 802.11 / GSM / WCOM / TETRA and DAB from manufacturers such as Will'Tek, Litepoint and Tescom, visit www.mcstest.com

MCS also provides excellent rental rates and will consider the purchase / part exchange of any redundant equipment you have

Rigol DS 5000 Series D50 Priced from Only

- Outstanding performance @ an affordable price
- Range of 200Mhz, 150Mhz, 100Mhz & 60Mhz models available
- 1GS s/a real time sampling
- 2 channels with ultrazoom for detailed viewing
- Ultrascope PC software via built in USB device
- Automatic voltage frequency and time measurement plus user definable cursor measurements

# For further information, Please contact us. Tel: 01678 520 600





Mobile Communications Solutions Ltd, Unit 3, Bala Industrial Estate, Bala, Gwynedd, UK. LL23 7NL Tel +44 (0) 1678 520600 Fax +44 (0) 1678 521602 www.mcs-test.com sales@mcs-cymru.co.uk



Febuary 2006

Volume 112

41

1

easyRadio for all! ard or easy way when creating a wireless or system. By Barry Gillibrand icro Microcontroller CCF iccoP ochip PICDEM MC Developer Board for trol Design to Loeas red Electrostatic Loudspeaker Supply for Quad ESL57 and Braun LE1 sed metronome	42 46 49 50
ar system. By Barry Gillibrand ICTO MICTOCONTROLLER CCF OCCP ochip PICDEM MC Developer Board for trol Design lets t Ideas red Electrostatic Loudspeaker Supply for Quad ESL57 and Braun LE1	40
ECOP ochip PICDEM MC Developer Board for trol Design ets t Ideas red Electrostatic Loudspeaker Supply for Quad ESL57 and Braun LE1	40
trol Design HetS t Ideas red Electrostatic Loudspeaker Supply for Quad ESL57 and Braun LE1	
t Ideas red Electrostatic Loudspeaker Supply for Quad ESL57 and Braun LE1	
red Electrostatic Loudspeaker Supply for Quad ESL57 and Braun LE1	5(
chronometer Review S	58
ucts	58
CCP1 HVIN W (K)	Vour
	-Fi Finder – p49 Book Review – p55 $\int_{10^{\circ} \text{F}} \frac{V_{CC}}{V_{CC}} \int_{10^{\circ} \text{F}} \int_{10^{$

111



February 2006 ELECTRONICS WORLD

# PTH PCBs with solder resist and legend from just £30.00 lot price.

Deliveries from

CBTRA




## Visit WWW.pcbtrain.com for full details.

- NEWBURY ELECTRONICS, the home of PCBTrain, the UK market leader for low-cost prototype PCBs
- Exclusive UK representatives for Circuit Mission Ltd (China) - manufacturers of low-cost high quality rigid PCBs
- Exclusive UK representatives for Sunflex Ltd (Taiwan & China) manufacturers of flexible circuits

+44 (0) 1635 40347

NEWBURY ELECTRONICS LTD Faraday Road Newbury Berkshire RG14 2AD UK

## The colourful world of scopes



With the complexity of systems to be tested, grows the complexity of oscilloscopes with which to monitor and diagnose problems. It's good to know that innovation is rife in this market: we are seeing increasing sample rates, longer record lengths ('deep' memory) and increasingly faster capture of waveforms – and in real time, at that. The newest oscilloscopes offer the highest bandwidth, greatest timing resolution, lowest noise floor and thorough analysis capabilities for current and emerging serial data standards.

As engineers need to handle information on multiple channels – to monitor several signals simultaneously – the capabilities of oscilloscopes need to be expanded too. Capturing anomalies is one important reason why engineers need to capture signals in real time. Checking out the dynamic range of the signal is another.

Today there are two classes of oscilloscopes on the market: DSOs (digital storage oscillo-

scopes) and DPOs (digital phosphor oscilloscopes). Either of these two classes can offer realtime or semi real-time capture, but have different capabilities. The capture rate will vary however, from scope to scope. For example, the DSOs offer a much lower capture rate than DPOs do. DPOs are also about the acquisition rate and not just about improved sample rates, which have already entered the 40GS/s domain. Because of the high acquisition rate, the chance of seeing a rare event in the signal is increased. Oscilloscope makers are increasingly resorting to using more advanced technologies in order to meet the growing needs of engineers. Advanced silicon germanium processes are just one example. Tektronix has worked closely with IBM to ensure that the silicon germanium process can handle its requirements, such as being used in fast analogue to digital converters as well as for triggering purposes. In Tektronix's latest series of scopes - the DPO 7000 - the data that is input in the demux is as fast as 5Gbytes/s.

Such speed will allow users to capture even the most elusive of glitches or unstable conditions.

Fifteen years ago, oscilloscopes would allow users only a limited number of capabilities. Nowadays, bigger displays, different interfaces, different and larger capacity storage mediums and, indeed, interactive configuration control panels, allow the user significantly greater flexibility – all thanks to innovations in this field.

> Svetlana Josifovska Editor

EDITOR: Svetlana Josifovska E-mail: svetlana.josifovska@nexusmedia.com EDITORIAL E-mail: EWeditor@nexusmedia.com EDITORIAL ADMINISTRATION: +44 (0) 1322 611274 E-mail: EWadmin@nexusmedia.com PRODUCTION EDITOR/DESIGNER: Jane Massey SUBSCRIPTIONS: Customer Interface Ltd, Cary Court, Somerton, TA11 7BR Telephone: 0870 4287950, Fax: 01458 271146 SUBSCRIPTION RATES: 1 year: £45 (UK); €115 (Europe); \$150 US & worldwide DISPLAY SALES EXECUTIVE: Reuben Gurunlian +44 (0) 1322 611261 PRODUCTION EXECUTIVE: Dean Turner +44 (0) 1322 611206 E-mail: dean.turner@nexusmedia.com PRINTER: William Gibbons Ltd • ORIGINATION: Impress Repro A1 Parkway, Southgate Way, Orton Southgate, Peterborough, PE2 6YN NEWSTRADE: Distributed by Seymour Distribution Ltd, 86 Newman St, London W1T 3EX. • PUBLISHING DIRECTOR: Tony Greville If you are experiencing problems getting copies through your newsagent, please call Debbie Jenner on +44 (0) 1322 611210 Electronics World is published monthly by News Media Communications, Media House, Azalea Drive, Swanley, Kent, BR8 HU Nexus Media Communications is a trading name of Nexus Hakdings Limited. Registered in England. Registered Number 53446404. Registered Office: Hanover House, 14 Hanover Square, London W15 1HP

Disclaimer: We work hard to ensure that the information presented in Electronics World is accurate. However, Electronics World's publisher – Nexus Media Communications – will not take responsibility for any injury or loss of earnings that may result from applying information presented in the magazine. It is your responsibility to familiarise yourself with the laws relating to dealing with your customers and suppliers, and with safety practices relating to working with electrical/electronic circuitry – particularly as regards electric shock, fire hazards and explosions.

w

3


# WHAT BETTER CHOICE ?

FOR QUALITY, PERFORMANCE & AFTER SALES SERVICE





THE PROMAX SERVICE CENTRE 6 Caxton Centre, Porters Wood, St. Albans, Herts, AL3 6XT. TEL : 01727 832266 FAX : 01727 810546 www.albanelectronics.co.uk info@albanelectronics.co.uk SALES + SERVICE + CALIBRATION



### Single-chip DBS receiver ready

Silicon Laboratories has last month announced its fully integrated single-chip satellite RF front-end for direct broadcast satellite (DBS) – the SiRX.

Typically, satellite set-top box OEMs buy in the receiver front-end or the network interface module (NIM), but these contain several ICs and many discrete components. They also require functions for sending power and controlling the LNB via the coaxial cable to be implemented by the OEM outside the NIM. The SiRX integrates all of these functions into a single 6 x 8mm CMOS IC.

The integrated functions, therefore, include a satellite L-band RF tuner, a dual-mode DVB-S/DSS digital demodulator and a power-efficient, step-up supply controller for the LNB. The integration of the LNB supply controller is an industry-first and includes support for DiSEqC 2.x and legacy tone/voltage LNB signalling.

The SiRX receives input from the LNB, which is part of the satellite dish housing, and outputs a digital bit stream that carries the digital audio and video satellite services for further video/audio decompression and display by the baseband processor.

In addition, the SiRX also contains an on-chip hardware blindscan feature that improves channel scan time by a factor of 10 compared to many existing solutions. This feature reduces set-top box installation time for FTA applications where channel locations are unknown.

Samples of the SiRX family are available now in a leadfree, RoHS compliant 44-pin QFN package.

Full production is scheduled for the middle of 2006.

IBM says molecular transistors are the future

BM in Zurich is working on turning single molecules of between 5 and 50 Angstroms into working transistors. "You can use a single molecule as a rectifier, switch, logic or memory, for example," said IBM Zurich's Dr Walter Reiss.

One thing that might stop its quick deployment in commercial applications, however, is the electrode contacts. "The atomic electrodes have to be sharp and the chemical compatibility has to be there for the contact between electrode and transistor (molecule) not to be loose," said Dr Reiss.

One potential solution is to use a metal break junction (MBJ) on a flexible substrate as a contact. However, this is not the only challenge that will need to be surmounted to turn a molecule into a successful transistor.

"New technology is successful if allows new applications, it is cheaper to manufacture and it offers better performance," said Dr Reiss. "A perfect example of it is the [traditional] semiconductor transistor. It is reliable and cheap and easy to manufacture, as well as it offers better performance. But organic transistors will replace amorphous silicon [in the future] – it's most efficient technology."

"Sometime in the future, we'll probably see molecular atomic devices, but it will depend on how we control them on the nano and microscopic scale," he added.

### MED's P-OLEDs are deemed commercial success

Ccotland-based polymer Dorganic light emitting diodes (P-OLEDs) developer, MicroEmissive Displays (MED), has started shipping its first displays to a customer in the Far East. They will be used in a 'nightscope' type product. which will allow the consumer to 'see' in the dark. MED cofounder, Ian Underwood, says MED's displays are also suitable for MP3 players, digital still cameras, viewfinders in digital camcorder and as eyewear for games, mobile phones etc.

The plan is to attack the market initially in two directions: for electronics viewfinders (EVF) and wearable displays. "The market size for EVF for digital still cameras will rise from 80-plus million in 2005, to 100-plus million in 2010. For camcorders that number will rise to over 19 million in three years. The EVF share will grow from nine million now to 17 million units in 2010," said Underwood. "There's not much of a market today, but some studies sug-

gest that in the next two years



MicroEmissive Display's P-OLED is one of the smallest displays around

it will start growing thanks to the mobile phone. We are not tightly linked to the mobile phone market, but if the need for wearable displays emerges, we'll be ready," he said.

MED uses a CMOS technology and a polymer to create its displays. The combination offers good image quality, fast moving images and it does not need

polarisers. It also offers low power, small form-factor and light weight, since the CMOS allows high levels of integration and high pixel factor.

However, one big disadvantage is that when the P-OLED image is magnified, the defects that are part of that display are also magnified. "This has challenged and stretched us, said Underwood.

Equally, because of the close vicinity of the pixels, there's lateral conductivity, where the switching of one pixel leads to the switching of the ones close to it. In addition, there's optical coupling between the closely-knit pixels (blue coupling with red etc). "We are a small group and we can't address all of these challenges by ourselves. But, if anybody knows more about these issues then we'd like to hear from them," said Underwood.

MED's P-OLED displays are only 7 x 5mm large. Their usage is currently two hours per day, which Underwood says is sufficient for the operation of EVFs.

**Funkwerk Enterprise Communications (FEC) has** partnered with Ziehm Imaging to integrate its WLAN technology into Ziehm's line of mobile X-ray products in the medical field. With FEC's technology, X-ray units can communicate wirelessly with the network for image data to be fed directly over standard DICOM (Digital Imaging and **Communications in Medicine) to** archiving and communication systems, such as PACS (Picture Archiving and Communication System). FEC hardware and software have already been given medical approval as specified by European standard EN60601-1-2i. Ω

VaST Systems Technology (VaST), Gaia System Solutions, Toyotsu Electronics, Toyota Techno Service **Corporation and Fujitsu TEN have** announced the formation of the V-ECU (virtual electronic control unit) Club, an alliance that invests in virtual platforms for development of integrated electronics for the automotive industry in Japan. Industry research shows a sharp rise in the electronics content in vehicles, with complexity rising proportionately. Today's high-end models have up to 70 electronic control units (ECUs) connected by an average of five buses under the control of millions of lines of software interacting in real time. Recently, BMW reported that up to 70% of the development cost of an ECU is related to software and that some 40% of a vehicle's cost is determined by electronics and software.

#### Ω

Micron and Intel are creating a new company to manufacture NAND Flash memory. The devices are earmarked for use in consumer electronics, removable storage and handheld communications systems. The company will be called IM Flash Technologies. It combines Micron's NAND expertise and Intel's multi-level cell technology. Production will initially take place in manufacturing facilities located in Boise, Manassas and Lehi in the US. The new company will benefit from Micron and Intel's process technology expertise to aggressively convert to advanced 72nm and 50nm nodes. Initial production is expected in early 2006.

#### Join efforts to solve energy problems



Cir Richard OFriend (left), the creator of the first plastic transistors and founder of Plastic Logic, spoke of his

concern regarding the world's energy crisis at a recent event at St John's Innovation Centre in Cambridge.

"I am concerned that if we are to keep ourselves warm and fed in the years to come, we need to create new technologies and markets. What are we going to do about it?" he said.

"There are small examples of how to hamess natural resources. The powers of sunlight, wind, tide and biomass are amazing. With a fraction of sunlight hamessed, for example, we could satisfy all of our energy needs," he said.

Sir Richard carried on to say that the Cambridge area, with

MA-

its small firms phenomenon, its University and a concentration of VC funding, is good at providing niche solutions that have the potential to turn out "very big". However, he added, to solve the energy problem it will take more than just efforts at universities.

"Now is the time to do something about it and it is not enough to turn to universities to create new industries," he said.

De Montfort University in Leicester, UK, plans to set up a new threeyear degree course in Electronics Games Technology. This will be a BSc course, scheduled to start in September 2006. It aims to give students the skills required to work in three main disciplines of the industry - design, electronics and computing software. The course is a collaborative venture between the University's **Faculty of Computing Sciences** and Engineering and the Faculty of Art and Design. This course follows De Montfort University's launch of the BA (Hons) in Game Art Design degree, in September last year. This course focuses on the artistic elements of creating computer games and works closely with the industry.

#### Ω

The contamination control and cleanroom industry is in a buoyant mood, says a report from market research company McIlvaine. Some 80% of cleanroom industry professionals state the industry's mood as optimistic or very optimistic, while some 50% have made 'significant' investments in the past 12 months. Around 40% plan to do so in the coming year. The strongest demand is seen in the development of medical devices. Those operating in the semiconductor market have the most advanced procedures. Further growth in this industry is fuelled by nanotechnology applications such as miniaturised sensors and microsurgical instruments. The global cleanroom demand is expected to grow by 45% a year from the current \$11bn.

#### Ω

Swiss group Huber+Suhner has received the ISO/TS16949 certificate - a stringent automotive industry standard - for its facility in Tzcew/Gdansk, Poland. Here, Huber+Suhner manufactures customised RF components for use in vehicles, as well as radio basestations for mobile telephony. The automotive industry is a big user of RF components for navigation systems, pre-crash sensor systems, distance radar, tyre pressure monitoring, satellite radio and so on. Among the company's clients are Audi, Mercedes, GM, Renault, Volkswagen and specialised first tier suppliers such as Autoliv, Fuba, Harada, Bosch, Delphi and PKC. Huber+Suhner has been producing RF products at its subsidiary company in Tzcew since 2003.

# Power electronics can rely on diamonds

Scould replace silicon in power electronic devices, confirmed research carried out at the University of Cambridge. Out of several suitable materials, including silicon, GaAs and GaN, diamond has been found to have the best electric field,

better hole and electron mobility and better thermal conductivity than the

others. It is also a wide-bandgap semiconductor,

which means that its electrons will require much higher energies to change state and, hence, change the structure to a conducting one. Diamond, therefore, retains its electronic control at high voltage and high temperature.

............

However, costs associated with synthesising diamond are rather high and yields are rather low – only 5mm of highquality substrate can be made unlike with silicon, where substrate sizes have already reached 300mm.

These are the findings of the University of

> Cambridge team, lead by Professor Gehan Amaratunga, which also works closely with Element Six and Dynex Semiconductor, under the umbrella of

the Carbon in Power Electronics (CAPE) project. "You can use diamond in applications for voltages of above 10kV and currents of over 100A, or in amplification, where you'll stack them up in a power system," said Prof Amaratunga. "But, we are far away from having a diamond transistor."

The team is currently working on increasing the hole mobility in a diamond Shottky device. "If you dope the diamond with boron, you will get a higher hole mobility; it becomes almost metallic and this is a lot better than using SiC."

This diamond structure can be used as a unipolar device for voltages of between 800 and 1700V. "You can make good diamond Shottkys with gold contacts. It is a good device to replace silicon in power electronics systems," added Prof Amaratunga.

Element Six has already created Schottky-barrier diode (SBD) based on a sythesised diamond structure. The SBD is capable of operating at 1700V and a current density of 10A/cm<sup>2</sup>.

.....

No need to type SMS, just dictate it

Dictating SMS and emails and carry out searches on the Yellow Pages, Google or Yahoo by voice from your mobile phone will be available as early as next year in Europe.

Michael Thomson, VP of international marketing of speech recognition firm Nuance Communications, formerly ScanSoft, says that the processing technology, power-saving handsets, voice recognition cores and vocabularies are already here and that operators are asking for such services.


"This area is red hot right now," he said. "Dictation to a mobile phone opens up a lot of opportunities for operators and they are asking for this, they are the main driver."

Nuance builds the core technology and also provides the tools and services for such applications. "Only about a year ago, dictation was only available for PCs. Now, embedded dictation is all done in the handset. This is the largest single investment area for us and it requires dozens of engineers," said Thomson.

Europe is expected to see the first dictation-enabled mobile phones during 2006. However, the US is already leading the way with the launch of Samsung's P207 model, available from Cingular Wireless, which contains VoiceSignal's VSpeak full textto-speech (TTS) solution that can read emails, text messages, web pages or any other text aloud. This offers a complete speech interface solution to look up or dial a contact. dictate a text message or have a text message or other content read aloud. The software's footprint is only 300kB of memory. If combined with a Bluetooth headset, the solution can offer an entirely eyes-free interface. VSpeak is planned for all levels of handsets, including its availability in over 20 languages.

#### Technology

# Carbon nanotubes likely to drop out of the IC race



Conductive interconnects created with carbon nanotubes [Source NASA]

Carbon nanotubes (CNT) are a promising technology but there's a risk that they won't make it into commercial reality for high-density IC integration, says Dr Siegmar Roth of the Max Planck Institute in Germany.

"It is not down to technology but to economy – people get fed up with it [technology] and change. The Kondratiev Cycles imply that each technology starts slowly, then reaches experimental growth and then comes to saturation," said Dr Roth.

Nokolai Dmitrijevich Kondratiev was a Russian economist that lived in the 1920s. He first described economic cycles consisting of four stages – boom, recession, depression and recovery, in their typically 50-year long lifetime. Since the 1700s, four Kondratiev cycles have been observed.

Kondratiev also indicated how technology plays a role in leading the way out of the contraction stage in the cycle and into the next up-wave.

Dr Roth believes that even though some companies are working with CNT, not many are actually investing in it. "CNT interconnections and vias will come; CNTs transistors for toys and basic research will also come, but the risk is that [transistor] minaturisation will saturate for economic reasons before selfassembly methods for CNT will be ready," said Dr Roth.

"There is still a lot of work to be done to get high IC density with CNT. Research will take another ten years and we are already at 30 years in this [latest] 50-year cycle, so I'm not sure that CNT will be ready by then," he told *Electronics World*.

Carbon is a 'cousin' to silicon; they share the same group number in the periodic table, but with different atomic numbers (6 and 14, respectively). Since the covalent bonds are a lot stronger in carbon than in metal, this allows electrical conductivity that is 15 times stronger than in copper, for example. The current density in carbon nanotubes is better too, as electrons do not collide with imperfections – loose links in the metal.

Field emitting transistors (FETs) can be made from single nanotubes, but the dimensions of such a device will be a lot larger than in silicon. This means that transistor density in ICs will be limited. Infineon and Samsung have crated vertical CNT transistors to save on space, which will lead to better IC integration. However, Infineon has stopped any further investment in this field, for the time being.

"These devices [vertical transistors] exceed the ITRS roadmap for IC integration by 2016, but they require investment," added Dr Roth.



#### Software Design

- Begin every step in software design by asking, 'How should this information, this activity, this state, this relationship be represented?'
- Don't expect to get the representation right first time. Look for opportunities to improve code by re-representation
- ▶ Write no more than necessary
- Make the first version durable not functional and get it running early
- ► Localise information
- >> Test to discover information
- Design software to minimise the damage caused by changes to requirements
- >> Steer design by clear criteria
- >> Exploit existing solutions
- Shape your program around these six sufficient concepts: states, events, conditions, actions, objects and types

This month's Top Ten Tips were extracted from the book 'Sofware Design for Engineers and Scientists' by John Robinson and published by Newnes, an imprint of Elsevier.

To buy this book at 15% discount, please email us at EWadmin@nexusmedia.com

Also use this email address to send us your own top ten tips on any subject.

To evaluate this book, please contact the editor at the above address.

#### SERIAL COMMUNICATIONS SPECIALISTS Test and Measurement Solutions



#### featured products V



4 Port UPCI RS232 Serial Card with Spider Cable or COMBOX IO ( extra )

#### Affordable CAN Bus Solutions

CANUSB is a very small dongle that plugs into any PC USB Port and gives an instant CAN connectivity. This means it can be treated by software as a standard COM Port (serial RS232 port) which eliminates the need for any extra drivers or by installing a direct driver DLL for faster communications and higher CAN bus loads. CAN232 is a very small dongle that plugs into any PC COM Port, or any other RS232 port in an embedded system and gives an instant CAN connectivity. This means it can be treated by software as a standard COM Port (serial RS232 port) which eliminates the need for any extra drivers. Sending and receiving can be done in standard ASCII format.

priced from £61.00 (CAN-232)

#### USB Instruments - PC Oscilloscopes & Logic Analyzers

Our range of PC Instruments may be budget priced but have a wealth of features normally only found in more expensive instrumentation. Our DS1M12 and PS40M10 oscilloscopes have sophisticated digital triggering including delayed timebase and come with our EasyScope oscilloscope / spectrum analyzer / voltage and frequency display application software and our EasyLogger data logging software. We also provide Windows DLLs and code examples for 3rd party software interfacing to our scopes. Our ANT8 and ANT16 Logic Analyzers feature 8/16 capture channels of data at a blazing 500MS/S sample rate in a compact enclosure.

priced from £125.00 (DS1M12 & ANT8 )

#### 1 to 16 port USB to Serial Adapters

With over 16 different models available, we probably stock the widest range of USB Serial Adapters available anywhere. We offer converter cables, multi-port enclosure style models in metal and plastic, also rack mount units with integral PSU such as the USB-16COM-RM. Serial interfaces supported include RS232, RS422 and RS485. We also supply opto-isolated RS422 and RS485 versions for relaible long distance communications. All our USB Serial products are based on the premium chipsets and drivers from FTDI Chip for superior compatibility, performance and technical support across Windows, MAC-OS, CE and Linux platforms.

priced from £20.00 (US232B/LC)

#### **UPCI Serial Cards**

Discover our great value for money range of multi-port UPCI serial cards. Supporting from two to eight ports, the range includes RS232, RS422, RS485 and opto-isolated versions. Our 4 port and 8 port models can connect through external cables or the innovative wall mounting COMBOX.

priced from £21.00 (UPCI - 200L)

EasySync Ltd 373 Scotland Street Glasgow G5 8QB U.K. Tel: +44 (141) 418-0181 Fax: +44 (141) 418-0110 Web : http://www.easysync.co.uk E-Mail: sales@easysync.co.uk

\* Prices shown exclude carriage and VAT where applicable

#### Insight

New methodology for testing ASICs provides many benefits to designers says Gregor Siwinski

**lest** 

n recent years, hardware emulators have been used for testing ASIC designs at speeds that reach more than 1MHz. These emulators typically use an array of high capacity FPGAs and allow the ASIC team to run their design at close to realtime speed to verify the design before it goes to production at the foundry.

Such solutions provide many benefits but are very expensive. If the ASIC design needs to be tested in several locations or by several third party companies who will use the final ASIC, then each one needs to receive their copy of the emulator with the prototype design.

Emulators are also inflexible with partitioning of the design. Since the predefined arrays of FPGAs have fixed structures, the design has to be partitioned to fit this structure. This is often one the biggest problems since the modules cannot be fit into most optimal FPGA sizes and topologies.

Another problem encountered is retargeting ASIC designs to compile into FPGAs. With different FPGA architectures, the re-targeting process can sometimes take several weeks and require changes in the design to accommodate large memories, multiple clock domains and other FPGA specific limitations.

As a result of these issues, many ASIC teams are adopting a new methodology that includes a custom FPGA prototype for the ASIC design, planned from the beginning of the ASIC project.

At the beginning of the ASIC planning process, a team assumes that all of the code compiles to both ASIC and FPGAs, and that the compilations are tested with each new version of the code. If incompatible, the team can use modified code versions and test the functional equivalence ahead of time. The custom prototype can be simulated, based on the FPGA libraries to ensure that the functional and timing results are the same.

When custom hard macros are used in the ASIC, the FPGA prototypes can either include an equivalent IP – core optimised for FPGAs or in some cases, a hard macro can be added to the PCB design in an ASIC form (e.g. ARM processor, memory and others).

Partitioning the design can also be planned based on a module basis. The design team can select the best FPGA to fit each module for optimum cost and performance. In addition to par-

The biggest difference between FPGA and ASIC design techniques is the use of clock signals

titioning, the PCB layout for the prototype can be optimised for maximum performance, as well as customised for the required connectivity between FPGAs.

Ideally, the same synthesis tool is used for both ASIC and FPGA compilation, but if it's not possible, a separate FPGA synthesis program in the custom prototype can handle ASIC RTL code. Some ASIC design features can also be re-targeted to FPGAs automatically. The biggest difference between FPGA and ASIC design techniques is the use of clock signals. FPGAs use dedicated clock lines and can typically handle 16 to 32 clocks per device. In ASIC designs, a typical technique is to use multiple clock domains for better power usage. Most ASIC designs use 64 clocks or more. In such cases, automated software can be used to convert ASIC clock management to FPGA clocks.

In addition, high capacity memories cannot be easily accommodated in FPGAs. In such cases, an equivalent external memory can be used on the prototype board with an appropriate logic interface to provide a high capacity memory equivalent. For example, a DDR memory module can be used in the prototype board and configured through a logic wrapper to emulate SRAM or other types of memory.

Benefit

When the ASIC design is finalised and ready for hardware testing, a prototype board can typically be made within a few days and can include the latest version of the design for high speed testing. If needed, multiple copies of the prototype board can be made for simultaneous testing in several locations.

Connections between FPGAs need to be optimised in tools that can handle high pin count BGA packages. With FPGA packages reaching over 1000 I/Os, the connectivity between FPGAs can be customised to best fit the PCB layout. If needed, the I/O assignment can be customised in FPGA software to assign the signals to the closest pin to connect to the next FPGA device. There are several commercial I/O management tools that will also optimise the FPGA ports to work at higher speeds.

Custom FPGA prototypes promise to offer many benefits to the ASIC designer and complement the traditional ASIC development process with high speed verification solutions at an affordable cost. If project managers plan the FPGA process in the early stage, the verification in hardware can be preformed in a very short time.

Gregor Siwinski is Director of R&D for Aldec



# Are You Tuning into the New Video Buzz?

The video surveillance market, military systems and medical imaging stand to benefit from a new generation of video encoders

By Nick Flaherty

dvanced Video Coding (AVC) is slowly taking over as the dominant standard for digital video, at least in the broadcast world. Also called H.264 and MPEG-4 part 10, encoding in AVC produces a good quality standard definition video stream at 1Mbit/s to 2Mbit/s, compared to 2Mbit/s to 3Mbit/s for today's MPEG-2 technology. Similarly, in high definition (HD), instead of a 19Mbit/s stream in

MPEG-2, HD pictures can be broadcast at 10 to 12Mbit/s.

This is great for telephone companies looking to send video over telephone lines using the IP protocol and ADSL2, and for satellite and cable TV operators who want to squeeze more channels into their offerings without having to add new capacity.

As a result, AVC decoders are quickly reaching commodity. STMicroelectronics (ST), Broadcom and Conexant Systems are all shipping single-chip AVC decoders in set-top boxes in the first quarter of 2006, and the march of silicon technology and increasing integration of other devices on the board is bringing the costs down.

Sagem Communication in France is using ST's single-chip decoder, initially in SDTV boxes

for Canal+ for receiving digital terrestrial TV, but also plans to launch HDTV boxes before the end of 2005, with volume production in 2006.

However, that doesn't mean the death of MPEG-2 decoders, where the market will continue to grow, says market researcher In-Stat. The worldwide MPEG video chip market revenues for 2004 were \$3.8bn, and MPEG-2 unit shipments are expected to experience growth until 2009, though decreasing prices will cause revenues to decline says the company.

"Buzz is really all there is to MPEG-4 AVC currently," said Michelle Abraham, analyst at In-Stat. "We expect the market will be small in 2005, as many decoder IC suppliers have been conducting interoperability testing with encoder suppliers. We expect widespread availability of MPEG-4 AVC decoder ICs beginning in 2006."

A DVD claver

However, the encoding side of AVC is not so easy. The broadcasters use racks of encoders from suppliers such as Tandberg Television and Harmonic, which use high-end FPGAs from Xilinx and their own ASICs to encode the bitstreams in real time. Luckily, the latest silicon technology is allowing AVC encoding to

fit into significantly cheaper

devices.

At the broadcast end, a new company called Telairity has developed a single-chip encoder that will replace up to eight FPGAs in the encoder. "In the 1980s we had RISC and that was very exciting. I think video is the thing now," said Howard Sachs, Telairity's chief executive. Sachs is famous in the industry for developing the ideas behind Very Long Instruction Word (VLIW) technology while at Intergraph and was part of the development team for Intergraph's Clipper VLIW technology.

"The architecture we have is a five-processor architecture, which will give a high definition TV real-time encoder solution in

In the 1980s we had RISC and that was very exciting. I think video is the thing now JJ Howard Sachs, CEO, Telairity

eight chips and one FPGA, which is the same performance at 24 of TI's chips," he said.

Telairity's T1P2000 single-chip encoder combines five independent vector/scalar cores, a video controller and a DRAM controller supporting an I/O bandwidth up to 5.3Gbit/s. Each vector/scalar core features four vector pipes with independent hardware, an independent scalar unit, 128kbytes of on-chip vector SRAM, a 4kbyte vector SRAM data cache, an 8kbyte scalar scratchpad memory and a 32kbyte instruction cache.

Sachs is talking to the main encoder makers such as Tandberg Television and Harmonic, but he is not just aiming at broadcast video. "We expect to expand our architecture and software expertise into other markets that are very allied to the current

ELECTRONICS WORLD February 2006

one such as video surveillance, military systems and medical imaging," he said.

Korean chips designer Intime is also looking at this market, launching a single-chip MPEG-4 encoder and decoder that can handle up to four channels.


The IME6500 provides full standard definition TV resolution performance by using multiple programmable filters, which improve interlacing performance and image quality, whilst reducing noise distortion especially in dark or near dark conditions, which makes the particularly suitable for the surveillance market.

With a PCB footprint of only 17 x 17mm combined with an active power consumption of 300mW, the IME6500 is aimed not only at consumer personal video recorders, but also security, machine vision, medical equipment and CCTV.

The chip is also supported by high-level design software that enables engineers without specific knowledge of DSP or codec applications to implement their design ideas quickly with the IME6500, and there are two reference designs: a 4-channel PCI interface module and a standalone 4-channel digital video recorder.

Meanwhile, a Toronto-based start-up, ViXS Systems, has also developed an MPEG-4 encoder to distribute video between display devices. It is designed for integration in nextgeneration TVs, PCs, PCTV tuner cards, DVD-


Block diagram of Telairity-1



Video-Imaging Coprocessor (VICP)

Video Processing Subsystem

DM6443/6



m

13

R machines, set-top boxes and personal video recorders (PVRs). The company is already supplying consumer electronic manufacturers such as Sony, Philips, Funai and Daewoo. Its XCode II encoder is based around a MIPS processor core with hardware accelerators.

Texas Instruments (TI) also sees encoding capability as key. Its DaVinci platform combines an ARM core with the latest digital signal processing core in a wide range of applications, from portable video through surveillance systems to standard definition TV over phone lines and even high definition TV.

The first two part numbers stemming from the DaVinci platform are video devices aimed at IPTV and video surveillance applications, and general-purpose video. "TI wants to accelerate the development of the video market and we want the customers to add their value and not reinvent the wheel each time," said Jean-Marc Charpentier, European DSP business development manager at TI.

The DM6443 and DM6446 both include a 300MHz ARM 926EJ processor core, running MontaVista Linux, alongside a 600MHz C64x DSP core, handling a wide range of software video codecs that TI supplies.

The \$30 DM6443 is aimed at IPTV applications, mainly for standard definition TV but handling up to 720p HDTV for certain codecs, and includes interfaces to DDR memory and ATA hard disk drives. It consolidates seven other chips, including FPGAs, in a system design, saving at least \$70 of system cost, says Charpentier. But the \$35 DM6446 adds a video encoder for applications such as video surveillance, and the ARM core running Linux makes it easier to use without having to program the DSP directly. "We added the ARM9 because we want to add the Linux community that don't need to go into the details of the DSP," said Charpentier. "The main effort has been done on the software environment."

The key, he says, is having a complete software infrastructure, from low-level operating system drivers to application APIs, making it possible for developers to implement digital video without having to focus resources on writing and optimising codecs or programming a DSP. TI has developed Linux APIs that mask the complex hardware and software details of implementing codecs from developers, enabling them to interchange multimedia codecs without having to modify application code.

AVC is definitely taking off in 2006, and the popularity of AVC in broadcast is driving down the cost of the decoder chips. This, in turn, is driving more cost-effective encoders that can open up video applications in more traditional embedded markets, such as video surveillance and medical imaging.

Tel: 02476 650 702 For Web: www.telnet.uk.co All equipment is used - with 3	-user to	est & measurement equipment	R
Web: www.telnet.uk.co			
web; www.ieinet.uk.co		the second se	
All equipment is used – with a 1 Stoney Court, Hotchkiss Wa		ee and 90 days in some cases. Add carriage and VAT to all goods. trial Estate Coventry CV3 2RL ENGLAND	LNEI
Agilent (HP) 3314A Function Generator 20 MHz	£650	Agilent (HP) 54520A 500MHz 2 Channel Oscilloscope	£1000
Agilent (HP) 3325A and B function gen. from	£550	Agilent (HP) 54645D 100MHz Mixed Signal Oscilloscope	£3000
Agilent (HP) 435A/B, 436A, 437B, 438A Power Meters from	£100	Agilent (HP) 8713B 300kHz - 3GHz Network Analyser	£4500
Agilent (HP) 3561A Dynamic Signal Analyser	£2950	Agilent (HP) 8566B 100Hz - 22GHz High Performance Spec. An.	£7000
Agilent (HP) 3562A Dual Ch. Dynamic Sig. Analyser	£3000	Agilent (HP) 8592B 9kHz - 22GHz Spectrum Analyser	£7500
Aglient (HP) 3582A Spectrum Analyser Dual Channel	£1200	Agilent (HP) E4418B EPM series Power Meter -single channel	£1500
Agilent (HP) 3585A and B Spec. An. (40MHz) from	£2950	Agilent (HP) E9300A EPM series sensor for above(18GHz- 100mW)	£750
Agilent (HP) 35660A Dynamic Sig. An	£2950	Agilent (HP) 8648C Signal generator (100kHz-3.2GHz)	£4000
Agilent (HP) 4191A R/F Impedance analyzer (1 GHz)	£2995	Agilent (HP) 8347A R/F Ampliller (100kHz-3GHz)	E2000
Agilent (HP) 4192A L/F Impedance Analyser (13MHz)	£4000	Agilent (HP) 33250A Arbitrary Function Generator (80MHz)	£2150
Agilent (HP) 4193A Vector Impedance Meter	£2750	Agilent (HP) E4406A (opt BAH) Vector Signal Generator (7MHz-4GHz)	£11000
Agilent (HP) 4274A LCR Meter	£1750	Agilent (HP) E4404B (opts 1D5,1DN,A4H) Spectrum An. (9kHz-6,7GHz)	£10000
Agilent (HP) 4275A LCR Meler	£2750	Agilent (HP)34401A 6.5 Digit Bench DMM	£550
Agilent (HP) 4276A LCR Meter	£1400	Agilent (HP) 4194A (50 ohm) Impedance/Gain Phase Analyser	£10750
Agilent (HP) 4278A Capacitance Meter (1KHz / 1MHz)	£2950	Agilent (HP)5350B Microwave Frequency Counter (20 GHz)	£1200
Agilent (HP) 5342A Frequency Counter (18GHz)	£850	Agilent (HP) 5343A Frequency Counter ( 26.5 GHz)	£1400 £4700
Agilent (HP) 5351B Frequency Counter (26.5GHz)	£2750	Amplifier Research 10W1000B Power Amplifier (1 GHz)	£4700 £1200
Agilent (HP) 5352B Frequency Counter (40GHz)	£4950	ENI 320L Power Amplifier (250kHz 110MHz) 20 Watts 50dB IFR (Marconi) 2051 10kHz-2.7GHz) Sig. Gen.	£5000
Agilent (HP) 53310A Mod. Domain An (opt 1/31)	£3450	Rohde & Schwarz SMY01 9kHz - 1040 MHz Signal Generator	£1750
Agilent (HP) 54810A Infinium Scope 500MHz	£2995	Rohde & Schwarz CMD 57 Digital Radio Comms Test Set	£4250
Agilent (HP) 8116A Function Gen. (50MHz)	£1750	Rohde & Schwarz XSRM Rubidium Frequency Standard	£3750
Agilent (HP) 8349B (2- 20GHz) Amplifier	£1950	Rohde & Schwarz CMD 80 Digital Radio Comms Test Set	£3500
Agilent (HP) 8350B Mainframe sweeper (plug-ins avail)	£750	R&S SMIQ-03B Vector Sig. Gen. (3 GHz)	£7000
Agilent (HP) 85024A High Frequency Probe	£1000	R&S SMG (0.1 - 1 GHz) Sig. Gen.	£1750
Agilent (HP) 8594E Spec. An. (2.9GHz) opt 41,101,105,130)	£3995	Seaward PAT 1000S Computerised PAT Tester(New in Box) normally £845 now	£550
Agilent (HP) 8596E Spec An. (12.8 GHz) opt various	£8000	Tektronix THS 720A 100MHz 2 Channel Hand-held Oscilloscope	£1250
Agilent (HP) 89410A Vector Sig. An. Dc to 10MHz	£7500	Tektronix TDS 220 100MHz - 2 Channel Real - Time Scope	£650
Agilent (HP) 89440A Vector Signal Analyser 2MHz – 1.8GHz	£8950	Tektronix TDS 524A 500 MHz - 500Ms/s 2 Channel Scope	£3000
Agilent (HP) 33120A Function/Arbitrary Waveform Generator 15MHz	£850	Tektronix TDS 724A 500 MHz - 1 Gs/s 2+2 Channels	£3250
Agilent (HP) 53131A Frequency Counter	£750	Tektronix 2465B 400 MHz 4 Channel Scope	£1000
Agilent (HP) 53181A Frequency Counter	£750	Tektronix 11402 (Digitizing Mainframe) + 11A33 + 11A34 plug-ins	£1650
Agilent (HP) 4284A Precison LCR Meter	£5750	Tektronix 571Curve Tracer	£1250
Agilent (HP) 6031A Power Supply (20V – 120A)	£1250	Wayne Kerr 3260A+3265A Precision Mag. An. with Blas Unit	£5500
Agilent (HP) 6032A Power Supply (60V - 50A)	£2000	Wayne Kerr 3245 Precision Ind Analyser	£1750
Agilent (HP) 6671A Power Supply (8V - 200A)	£1350	Wayne Kerr 6425 Precison Component Analyser	£2000
Agilent (HP) E4411A Spectrum Analyser (9kHz – 1.5GHz)	£3500	Wavetek 9100 Universal Calibrator (Opts 100 / 250)	£9000
Agilent (HP) 8924C CDMA Mobile Station Test Set	£6000	W&G PFJ 8 Error & Jitter Test Set	£6500
Agilent (HP) E8285C CDMA Mobile Station Test Set	26000	Various other calibrators in stock. Call for stock / prices	



#### 341 Hickory Nut Court \* Pasadena \* Maryland Phone:410-437-7080, Fax:410-437-7081 Email:masc1@usa.net, Website:www.wesedu.com



A Complete electronics lab for \$450! Price does not include shipping of \$30.

#### **Includes 5 USB Instruments:**

- Digital Storage Oscilloscope (80 Ms/s, 2ch)
- 16 Channel Logic Analyzer
- Arbitrary Waveform Generator (100 Ms/s)
- 2 Programmable Power Supplies
- 2 Programmable Clocks

#### Plus...

- Probes & Cables
- PC Software
- Easy USB connectivity with Windows

Visit our website to purchase it.

# **Circuit Modelling** for EMC


**Ian Darney** identifies the analytical tools involved in deriving values for the L, C and R components from physical data

ack in the January 2005 issue of Electronics World, the article *"Understanding EMC"* on p14 described how to build a couple of transformers, calibrate them and use them for bench tests of interference coupling. One was an injection transformer, used to induce a voltage into a system cable. The other was a current transformer, used to

cable. The other was a current transformer, used to monitor current in the cable. The combination can be used to characterise the configuration under review, carry out conducted susceptibility tests, or perform conducted radiation tests.

It was shown that the results of bench tests can be used to create a circuit model of the equipment under review. Successive approximations to the component values enabled the response of the model to correlate precisely with the measured data. It was shown that a single model can be used to predict conducted emissions and conducted susceptibility.

Figure 1: Cross-section of three-conductor assembly



However, its applicability was restricted to low frequency coupling, where inductance and resistance have a predominant effect. It is a simple matter to build transformers that operate at a much higher frequency than those described, but there is little point in using them if the measured response cannot be simulated.

It is first necessary to establish a systematic method of deriving a circuit model of the configuration under review. The purpose of this article is to identify the analytical tools involved in deriving values for the L, C and R components from physical data. That is, to enable a model to be created before the assembly is built.

#### Three is a crowd

In general terms, it can be said that only one conductor is needed to transmit electromagnetic fields far and wide, it takes two conductors to transmit a signal efficiently from one location to another, but at least three conductors are involved in the creation of interference.

The analysis needs to be able to cater for the interactions between three conductors.

A simple configuration could be a two-conductor cable routed along a third conductor. This third conductor would represent the combined effects of structure and other signal conductors. Such a representation will not provide a perfect simulation, but it is infinitely better than one which assumes that all return conductors form an equipotential surface.

**Figure 1** illustrates one way of defining the crosssection of such an assembly. It is assumed that the cross-section is constant and that the length is *l*. This lends itself to the use of an array of numbers to record all the radial measurements.

$$\mathbf{r} = \begin{pmatrix} r_{1,1} & r_{1,2} & r_{1,3} \\ r_{2,1} & r_{2,2} & r_{2,3} \\ r_{3,1} & r_{3,2} & r_{3,3} \end{pmatrix}$$
(1a)

$$\boldsymbol{r}_{i,j} = \boldsymbol{r}_{j,i} \tag{1b}$$

Integers *i* and *j* are used to identify the conductors. If they are different, the measurement defines the separation between the axes. If they are the same, the measurement defines the conductor radius.

Calculating the resistance of each conductor is a relatively straightforward task, using:

$$R_{i} = \frac{\rho \cdot l}{\pi \cdot r^{2}} \tag{2}$$

where  $\rho$  is the conductivity of the conductor. Skin effect is likely to cause the resistance of the conductors to increase with frequency. However, there is no need to invoke this complexity, since inductive and capacitive effects predominate.

Inductance is a parameter used to relate the rate of change of current in the conductor to the voltage along the conductor. If it is assumed that the rate of change of current in an isolated conductor is constant along the length *l*, then a primitive inductance can be defined as:

$$Lp_{i,i} = \frac{\mu \cdot l}{2 \cdot \pi} \cdot \ln\left(\frac{l}{r_{i,i}}\right)$$
(3a)

This parameter can be used to relate the energy level of the conductor to the energy contained in the surrounding magnetic field. Similarly, the energy level in conductor *i* due to field created by current in conductor *j* is a function of the inductance:

$$Lp_{i,j} = \frac{\mu \cdot l}{2 \cdot \pi} \cdot \ln\left(\frac{l}{r_{i,j}}\right)$$
(3b)

These formulae are a little unusual, in that they contain the length parameter on both sides of the logarithmic term. They highlight the fact that the length of the assembly is of critical importance.

One characteristic of primitive inductors is that  $Lp_{i,j}$  is equal to  $Lp_{j,i}$ , since the radial separations are the same.

An assembly of two parallel conductors is illustrated in **Figure 2**. The voltages  $V_{P_1}$  and  $V_{P_2}$  are the absolute voltages along the conductors, since they relate the total energy to the rate of change of current. Since they are associated with primitive inductors, they can be described as primitive voltages. This keeps the terminology systematic. It is assumed that the currents in the two conductors are  $I_{P_1}$  and  $I_{P_2}$ , and that the positive direction is from left to right.

If it is assumed that the voltages are sinusoidal functions of time and that the angular frequency is




Figure 2: Primitive currents and voltages for a twin conductor




Figure 3: Loop currents and voltages for a twin conductor

 $\boldsymbol{\omega},$  then the primitive equations for two parallel conductors are:

$$Vp_{1} = j \cdot \boldsymbol{\omega} \cdot \left( Lp_{1,1} \cdot Ip_{1} + Lp_{1,2} \cdot Ip_{2} \right) \quad (4a)$$

$$Vp_{2} = j \cdot \omega \cdot \left(Lp_{2,1} \cdot Ip_{1} + Lp_{2,2} \cdot Ip_{2}\right) \quad (4b)$$

Voltages developed at source and load can be ignored at this stage of the analysis.

A more familiar picture of the configuration is shown in **Figure 3**, which defines loop voltages and currents. The relationship between primitive parameters and loop parameters can be defined by comparing Figures 2 and 3.

$$IL_{\gamma} = Ip_{\gamma} = -Ip_{\gamma}$$
(5a)

$$VL_{i} = Vp_{i} - Vp_{j}$$
(5b)

Substituting primitive currents with loop current and subtracting Equation 4b from 4a leads to the loop equation:

$$VL_{i} = j\omega LL_{i} \cdot IL_{i}$$
 (6a)

where

$$LL_{\rm I,1} = Lp_{\rm I,1} - Lp_{\rm I,2} - Lp_{\rm 2,1} + Lp_{\rm 2,2}$$
(6b)

Using Equations 3a and 3b to substitute for the primitive inductors relates the loop inductance to the physical parameters;




Figure 4: Curcuit currents and voltages for a twin conductor




Figure 5: Inductive components of a three-conductor line

$$LL_{i,i} = \frac{\mu \cdot l}{2 \cdot \pi} \cdot \ln\left(\frac{r_{i,2} \cdot r_{i,2}}{r_{i,i} \cdot r_{2,2}}\right)$$

This is the standard equation for the inductance between two parallel wires, in a slightly unusual form. Some important characteristics of this relationship can be highlighted.

First and foremost is the assumption that the current in the return conductor is equal in magnitude to that in the signal conductor. This assumption is not necessarily true. In fact, the more one thinks about it, the less plausible it becomes.

The second point is the fact that two different types of inductance exist. Both types have the dimension of 'henry'. Primitive inductors define the characteristics of the conductor when it is acting as an antenna. Loop inductance is a parameter that can be measured with electronic test equipment.

The third feature of this derivation is of critical importance when EMC of the system is analysed. Loop inductance can only be measured between adjacent terminals. In the case of **Figure 3**, the inductance of the wire pair could be measured by connecting an LCR bridge to terminals A and B, and shorting terminals C and D, or vice-versa. However, when loop inductance is used in a circuit model, vital information is lost. Voltages between A and C, or between B and D, become unknown quantities. Yet, it is precisely these voltages that determine the EMC of the configuration.

#### **Retrieving information**

Fortunately, there is an easy way to recover this information. If it is assumed that the inductance of the signal conductor between A and C is  $Lc_1$ , and that between B and D is  $Lc_2$ , then the simple circuit model of **Figure 4** emerges. Here, the circuit voltages are:

$$Vc_{i} = j \cdot \omega \cdot Lc_{i} \cdot lc_{i}$$
(8a)

$$Vc_2 = j \cdot \omega \cdot Lc_2 \cdot Ic_2$$
 (8b)

where

(7)

$$Lc_{1} = Lp_{1,1} - Lp_{1,2} = \frac{\mu \cdot l}{2 \cdot \pi} \cdot \ln\left(\frac{r_{1,2}}{r_{1,1}}\right)$$
 (9a)

$$Lc_{2} = Lp_{2,2} - Lp_{2,1} = \frac{\mu \cdot l}{2 \cdot \pi} \cdot \ln\left(\frac{r_{1,3}}{r_{2,2}}\right)$$
 (9b)

This introduces a third type of inductance – the circuit inductance. Parameters of type 'circuit' are the type that can be used in circuit models. Comparing Equations 9a and 9b with Equation 7 shows that, in this simple configuration, the sum of the circuit inductors is equal to the loop inductance. The process can be summarised:

- > define the primitive parameters
- > set up the primitive equations
- > set up the loop equations
- define the loop parameters in terms of the primitives
- > set up the circuit equations
- define the circuit parameters in terms of the primitive parameters.

Applying this process to three parallel conductors results in the circuit model of **Figure 5**. If the radial parameters are as defined in Figure 1, then:

$$Lc_{1} = \frac{\mu \cdot I}{2 \cdot \pi} \cdot \ln\left(\frac{r_{1,2} \cdot r_{1,3}}{r_{1,1} \cdot r_{2,3}}\right)$$
(10a)

$$Lc_{2} = \frac{\mu \cdot l}{2 \cdot \pi} \cdot \ln\left(\frac{r_{1,2} \cdot r_{2,3}}{r_{2,2} \cdot r_{1,3}}\right)$$
(10b)

$$Lc_{3} = \frac{\mu \cdot l}{2 \cdot \pi} \cdot \ln\left(\frac{r_{1,3} \cdot r_{2,3}}{r_{3,3} \cdot r_{1,2}}\right)$$
(10c)

These equations will be familiar to anyone who has dealt with three-conductor power lines.

There exists a capacitive component that is complementary to the primitive inductance:

18

$$Cp_{i,j} = \frac{2 \cdot \pi \cdot \varepsilon \cdot l}{\ln\left(\frac{l}{r_{i,j}}\right)}$$

(11)

This capacitance can be used to relate the energy stored in the electric field to the absolute voltage on the conductor. As such, it can be used with the primitive inductance to analyse the performance of antennae. But, it is best to take one step at a time.

Since the logarithmic terms in Equations 11, 3a and 3b are identical, it becomes possible to derive capacitance values directly from inductance values, using:

$$Cp_{i,j} = \frac{\mu \cdot \varepsilon \cdot l^2}{Lp_{i,j}}$$
(12)

Since this relationship exists with the primitive types, then it remains valid for loop components and circuit components.

Since each conductor possesses the properties of resistance, inductance and capacitance simultaneously, then any circuit model must include all three components, if it is intended to be at all representative. This leads to **Figure 6**, where the inductive and resistive parameters have each been split into two equal components.

#### **Avoid temptation**

It is tempting to apply a star-to-delta transformation to obtain values for interconductor capacitance, but this temptation should be avoided. Visibility of the zero-volt node at the junction of the capacitors will be lost. Such visibility is essential if the final, and probably the most important, step in the modelling process is to be achieved.

Electromagnetic theory indicates that currents and voltages vary continuously along a transmission line, and the effect is portrayed as the propagation of an electromagnetic wave in the space bounded by the two conductors. It is equally valid to visualise the propagation of energy as a current that travels along the surface of the conductors at near-light velocity. If this is done, then the three conductors can be treated as three separate transmission lines.

This leads to the model of Figure 7, where:

$$ZA_{i} = Zo_{i} \cdot \tanh\left(\frac{\theta_{i}}{2}\right)$$




Figure 6: Circuit model of a three-conductor line





Figure 7: Distributed-parameter model of a three-conductor line





(13a)

EMC




Figure 9: Correlation of circuit model with test results

$$ZB_{i} = \frac{Zo_{i}}{\sinh\theta_{i}}$$
(13b)

given that:

$$Zo_{i} = \sqrt{\frac{Rc_{i} + j \cdot \omega \cdot Lc_{i}}{j \cdot \omega \cdot Cc_{i}}}$$
(14a)

and

$$\boldsymbol{\theta}_{i} = \sqrt{\left(Rc_{i} + j \cdot \boldsymbol{\omega} \cdot Lc_{i}\right) \cdot \left(j \cdot \boldsymbol{\omega} \cdot Cc_{i}\right)} \quad (14b)$$

Since the ZA and ZB impedances are directly related to the circuit parameters Lc, Cc and Rc, and since these components can be related to physical parameters, it is possible to compute the impedance values at any particular frequency.

If the conductors are configured as a pair of wires to carry a signal, with a third conductor representing the structure, then the frequency response of the coupling between signal loop and common-mode loop can be simulated. This can be done over any range of frequencies where transmission line analysis is valid. **Figure 8** shows the model of the setup. At this point, the reader might well be sceptical. However, the proof of the pudding is in the eating. When the tests and analysis described in the article "Understanding EMC" were extended to cover a higher range of frequencies, the results were as displayed in **Figure 9**. The parameter YT in the graph is the term used for transfer admittance, in this case the ratio of common-mode current to input voltage Vin, in amperes per volt. The 18 blue circles identify the data points derived from test results.

It is possible to create an accurate circuit model of an actual wiring assembly at frequencies well beyond first resonance.

Using this process, anyone can predict the results of conducted susceptibility and conducted emission tests. Further development of the approach allows the prediction of radiated susceptibility and radiated emission.

This article's setups, tests and derivation of equations can be found on

www.designemc.info > contents

## Rechargeable batteries with solder tags.

£2.82
£4.70
£7.60
£4.95

NICAD	
AA 650mah	£1.41
C 2.5A	£3.60
D 4Ah	£4.95

## Instrument case with edge connector and screw terminals

Size 112mm x 52mm x 105mm tall.

This box consists of a cream base with a PCB slot, a cover plate to protect your circuit, a black lid with a 12 way edge connector and 12 screw terminals built in (8mm pitch) and 2 screws to hold the lid on. The cream bases have minor marks from dust and handling. Price  $\pounds 2.00 + VAT$  (=  $\pounds 2.35$ ) for a sample or  $\pounds 44.00 + VAT$  (=  $\pounds 51.70$ ) for a box.





866 battery pack originally intended to be used with an orbitel mobile telephone it contains 10 1.6Ah sub C batteries (42x22dia the size usually used in cordless screwdrivers etc.) the pack is new and unused and can be broken open quite easily  $\pounds 6.46 + VAT = \pounds 8.77$ 



Please add £1.66 + VAT = £1.95 postage and packing per order.

JPG ELECTRONICS Shaws Row, Old Road, Chesterfield S40 2RB Tel: 01246 211202 Fax: 01246 550959 www.jpgelectronics.com Mastercard/Visa/Switch

Callers welcome 9.30am to 5.30pm Monday to Saturday

### Suppression Techniques of Over Voltage Transients at Motor Terminals

**Chaiwat Choochuan** of the Electromagnetic Compatibility and Electrical Machine Drives Systems Laboratory, Shaffner EMC (Thailand), explains the suppression techniques of over voltage transients at motor terminals and conducted EMI in PWM drives systems

> he suppression of over voltage transients at motor terminals can be divided into the load reactor and sine-wave filter. One economical solution is the suppression of voltage transients by using a load reactor. The sine-wave filter is available to improve the inverter output waveform from a PWM type to a near sinusoidal waveform. Using an input EMI filter for the suppression of conducted electromagnetic interference (EMI) is also very effective. The experimental results show the effectiveness of these techniques for over voltage transients and conducted EMI in PWM drives systems.


#### Adjustable speed drives

Technology to control the speed of AC motors continues to develop at a fast pace. Adjustable-speed drives (ASDs) are a significant part of this development. Energy savings, less wear on the mechanical components and a better process control are the primary factors that push such rapid advancement. The evolution of high-speed switching devices, such as the IGBT has enabled us to increase the carrier frequency of voltage-source PWM inverter.

Since IGBT devices can switch at high carrier frequencies (up to 20kHz), there are several advantages:

 More low speed torque for applications where nominal motor torque is required close to zero speed;

(2) Quieter motor operation, which reduces audible noise;



(3) Improved low speed stability, which minimises low speed oscillations.

Unfortunately, the fast switching IGBT technology also generates high frequency common-mode voltage, which induces high shaft voltages, leads to bearing currents and a very fast voltage rise (dv/dt)in PWM-wave-caused EMI problems, and over voltage at motor terminals when using long cables.

These adverse effects need to be suppressed by some techniques. There are several solutions available to solve this problem, each offering a different degree of protection at a different price. In this paper, the conducted EMI of the PWM inverter, over voltage transients and its mitigation effort are introduced.

Figure 2 shows the simulation waveforms of inverter currents and voltage waveforms for cable lengths of 10m and 50m respectively. It was observed that the transient current spike may be higher than the fundamental current and with a cable length of 50m the motor voltage peak is at 1100V.

#### Suppression techniques

> Over voltage transient at motor terminals

Figure 1 shows the experimental results of output voltage inverter and motor terminal with long motor cables, high switching frequency and no filter installed. It can be seen that the over voltage (ringing) at motor terminals at each switching instant due to the presence of long cable. Factors affecting motor over-voltage are:




Figure 1: Typical voltage waveforms for an ASD with a long feed – left (a) inverter output voltage right – (b) motor terminal voltage

- 1. Motor and cable surge impedance
- 2. Motor load and load reflection coefficient
- 3. Cable length
- 4. Magnitude of drives pulse
- 5. Rise time of drives pulse
- 6. PWM switching frequency of inverter
   7. Modulation strategy (SPWM or Space Vector


PWM) and modulation index. Motor and cable surge impedance mismatch are


primarily responsible for the magnitude of peak per unit over-voltage. It has been observed that the amplitude of motor terminal over voltage can exceed 2-3 times the dc-bus voltage due to insufficient dwell time and polarity reversals (Figure 1). The simple output reactor reduces of the inverter output, which in turn reduces the over voltage transient of the motor terminal. **Figure 3** shows the proposed output reactor and power circuit.

The design considerations of the simple output reactor for over-voltage suppression are as follows: the effect of core saturation and the flux distribution in the high frequency range. If the core saturates, then performance of the output reactor and the reactor L and R values are changed. Then, the overvoltage suppression of the output reactor is also changed. The values of L and R depend on the flux. linkage and the core loss inside the reactor, which are related to the flux distribution inside the reactor core. In general, the simple output reactor is designed at fundamental frequency, having 1%-5% impedance and the over-voltage suppression is almost proportional to the reactor impedance. However, a higher value of impedance causes a rapid increase in cost and weight.

A higher value of impedance at the fundamental frequency causes a larger voltage drop across the reactor, which reduces the fundamental component of voltage at motor the terminals. A large voltage drop, especially at over load condition, may result in the insufficient torque due to the lack of supply voltage.

One of the methods for overvoltage suppression is the sine-wave filter. The sine-wave filter is an effective means of taming the output voltage waveform and protecting the motor. **Figure 4** shows the sine-wave filter with passive components L,C and R





for the inverter output terminals. The structure of RLC filter in 3-phase inverter is shown in Figure 4. The impedance of the inductor of the filter is usually designed as a fraction of the impedance of the motor in fundamental frequency, say less than 5%, thus the filtering characteristic of the filter can be written as (1): (Note: The load is considered as open)

$$H = \frac{j\omega \frac{R}{L} + \frac{1}{LC}}{\left(j\omega\right)^2 + j\omega \frac{R}{L} + \frac{1}{LC}}$$

current and voltage waveforms; inverter current (green), inverter voltage (blue), voltage at cable end (red). Top – 10m Bottom – 50m

(1)




Figure 3 (Lett): Photo of proposed output reactor; RWK305-24-KL and power circuit

Figure 4 (Right): Photo of proposed sine-wave filter: FN5010-24-99 and power circuit.


$$H = \frac{j\omega 2\xi\omega_o + \omega_o^2}{\left(j\omega\right)^2 + j\omega 2\xi\omega_o + \omega_o^2}$$

where

$$\omega_o = \frac{1}{1 LC}$$
 :resonance frequency

$$\xi = \frac{R}{\frac{2}{\sqrt{\frac{L}{C}}}} \quad \text{:damping ratio}$$

When the damping ratio is greater 1, there is constant attenuation in the low frequency, so the damping ratio is usually chosen as smaller than 1. The sine-wave filter can filter the PWM wave to a near sinusoid with THD lower than 5%. In addition, the sine-wave filter has the advantage of high relia-



bility and large capacity, so it is widely used in applications where large power capacity is needed but sine-wave filters for this purpose cost approximately 2-3 times the cost of a simple output reactor.

Another sine-wave filter circuit proposes a return to the DC-link, with the purpose of connecting the LC filter star point to a point in the DC-link, as shown in **Figure 5**. The solution of this topology has an important advantage over the classical sinewave filter: it reduces both common-mode (CM) and differential mode components (DM).

#### > Electromagnetic conducted emission

(2)


It is well known that conducted EMI noise is a major concern for inverter driven motor drives, especially for inverter drives using high speed switching frequencies. This improves the performance of PWM inverter-fed induction motor systems, such as those that the switching loss and increase the controllability of system. The higher frequency of leakage current by the commonmode voltage of the PWM inverter is the primary concern of the higher conducted and radiated EMI emission. This is because the conducted EMI noise may cause negative interference effects on electronic devices, such AM radio receivers and medical equipment. The power EMI filter is applied to solve these problems.

The EMI line filter is usually located between the AC input terminal and the diode rectifier, and is expected to provide the attenuation of common and difference-mode high frequency current components.

Figure 6 shows the standard three phase EMI filter schematic and photo of EMI filter.

#### **Measurement results**

The suggested mitigation techniques for over voltage phenomena include load reactor, sinewave filter and EMI input filter. The test results are



obtained on a 5.5kW 400V IGBT drive and an induction motor. A 50m shielded cable between the inverter and induction motor was employed. A line-impedance stabilising network (LISN) is connected between the AC power source and the inverter system to provide a stable source impedance to the inverter systems in frequency range of 150kHz-30MHz.

Figure 7 shows the motor terminal voltage without and with the output reactor. Figures 8a and b show the motor current with and without output reactor connected respectively.


As can be seen, the charging current or transient current spike can cause inverter over-current faults or poor operation, due to inaccurate current feedback measurements such as flux vector or sensorless speed control.

Figure 5: Photo of proposed sine-wave filter with return to the DC link; FN530-16-99 and power circuit

Figure 6: Standard three phase EMI filter schematic and photo of EMI filter; FN3258-55-52

#### Figure 7 (Far right): The

experimental results motor terminal voltage with long cable and high switching frequency (50m and carrier frequency 18kHz) Left - shows the motor terminal voltage without output reactor. Right - with proposed output rector RWK305-24-KL







Figure 8: The experimental results of motor current with long cable a) without output reactor (b) with proposed output reactor: RWK305-24-KL

Figure 9: Waveform at the motor terminal line-toline voltage and current



**Figure 9** shows the experimental results of motor terminal line-to-line voltage and current. It is shown that the sine-wave filter can eliminate the peak voltage at the motor terminals. Note that the application and design of inverter output filter is dependent on the cable length, and the losses of filter are dependent on the motor drives system kilovoltamperes.

#### Conclusion

In this paper, some application issues for PWM drives have been investigated. The effect of high rate

of voltage rise in inverter output (*dv/dt*) generates the excessive over voltage in the motor terminals and conducted EMI of the PWM inverter have been addressed and explained. Suppression techniques have been shown to significantly reduce the transient over voltages at motor terminals and reduce the common-mode EMI using passive filter. The reduction contributes to improved power quality and reliability of PWM induction motor drives systems.

EMC

# The Ground Plane: Lord of the Board

**Tim Williams**, a consultant with Elmac Services and author of *'EMC for Product Designers'* emphasises the importance of giving due care to the ground plane in all designs

> he way that a circuit is laid out on a PC board is critical to its EMC performance. At high frequency all tracks must be regarded as components in their own right, since the coupling of high frequency signals from one part of the circuit to another is mediated by their stray capacitance and inductance. The schematic rarely – if ever – tells this side of the story; PC tracks are nothing more than lines on the diagram joining pins of lumped components such as ICs, resistors and capacitors.

> Every track on a board exhibits its own partial selfinductance, and mutual inductance and capacitance to other nearby areas of copper. If these are uncontrolled then the performance of the board at high frequency – and that means the EMC performance of the circuit – is also uncontrolled. The simplest and most effective way of fixing the characteristics of all such tracks is to implement a ground plane on the board.

#### The workings of the ground plane

First of all, forget any notion of the ground plane being used for screening: it may do, but that is not its primary function. What you expect from it is to provide a high-frequency return path for every signal and power rail on the board.

Running a signal and its ground return close together – so that neighbouring currents flow in opposite directions – reduces the inductive impedance of the ground path by a factor equivalent to the mutual inductance between the two:

Effective inductance of signal loop = 2(L - M)where L is the self-inductance of each half of the loop, M is the mutual inductance between the halves.

This effect is critical to understanding PCB track routing at radio frequencies: you need to control the 0V current return path. Keeping the signal and 0V paths adjacent along their length – and therefore maximising their mutual inductance – will ensure not only minimum coupling with the magnetic fields around the PCB, but also minimum impedance of the return path and, therefore, minimum noise voltage developed along it. This will keep down the "noisiness" of the whole board, which is mostly responsible for common mode emissions. It will also improve its immunity to external interference, which is determined by the conversion of incoming common mode disturbances to differential mode within the circuit.

This is entirely possible to do with assigning a OV return track to each signal and running the two next to each other, or on adjacent layers, throughout the board. This is, of course, somewhat tiresome and awkward in a board with hundreds of such pairs and it isn't necessary. If you provide a OV (ground) plane as a continuous layer adjacent to each track layer, then the job is done for you. The return current for each high frequency signal track automatically finds its own preferential path through the plane, which will be that path that is directly underneath the signal. The geometry ensures that this path has the least enclosed loop area and, therefore, the least total path inductance. All you have to do is make sure that the component OV connections, which carry the return path through, have a short and direct connection to the OV plane - which is easy, and that the 0V plane remains unbroken along the length of any of these paths, which, despite also being easy on a multi-layer board, still occasionally suffers from poor implementation.

#### Ground planes in the xy direction

The effect of a slot in the direction of the current flow is to increase the OV return path inductance. There are two problems caused by extra inductance here: Any high frequency current passing through this

inductance will develop a voltage across it. This

EMC

voltage then appears across the two parts of the plane, each of which has a high capacitance to the environment due to its surface area. Even on its own, this structure forms an efficient radiating dipole, which is only enhanced when cables are attached to the board;

The inductance itself represents increased magnetic coupling to the environment through the enclosed loop area.


Therefore, either there should be no split within the plane to add this extra inductance, or high frequency currents should be prevented from flowing between the two separated segments. This can be achieved through careful circuit design for emissions control, but it doesn't address the problem of immunity to incoming RF fields. The magnetic and electric coupling is still present for these fields and so they will develop voltages between the two ground segments, which are likely to create circuit susceptibilities.

There is a convention, encouraged by many device application notes, to create different 0V planes for different parts of the circuit. For instance, analogue 0V and digital 0V, which are then linked at one point on the board, typically at an A-D converter. The purpose of this trick is to prevent digital noise currents from flowing in the analogue circuit and corrupting it, that is, it relates to internal EMC. Unfortunately, it creates problems for external EMC and introduces difficult questions that could be avoided by a single system-wide 0V plane:

- Where should you join the planes when there are multiple analogue-digital interfaces?
- What about power returns that are common to both analogue and digital?
- Where do you run signals that must cross the break between the analogue and digital sections? Any of these signals will be exposed to incoming interference that will appear between the planes, or will develop such interference themselves.
- If you are going to bond the 0V planes at RF to the chassis of the product, which is always a recommended practice to minimise common mode coupling into or out of the PCB, how do you choose which of the planes should be bonded? For all these reasons, a preferable way to proceed

is to use a single, system-wide 0V plane and carefully lay out the board so that digital noise is effectively segregated from low-level analogue circuits. Avoid as far as possible any discontinuities in this plane and make sure that you do not run any critical (noisy or low-level) tracks across any discontinuities that remain, such as slots formed by close-packed vias, or near to the edges of the plane. There is no merit in putting "moats" in this 0V plane.


In the centre of a plane inductive effects are minimal, but towards the edges fringing magnetic fields are created and the inductive impedance of the plane.



rises. A good rule of thumb is to keep critical tracks further away than 10h from the edge of the plane or the edge of any discontinuity, where h is the separation distance in the z-direction between the layer that carries the track and the layer that carries the plane.

This can also apply to power plane layers placed against a 0V plane. If the power and 0V planes were to have exactly co-located edges, the transmission line formed by the two planes would be terminated in a sharp open circuit and the problem of transmission line resonances would be potentially severe, leading to a high degree of coupling to and from the PCB at the resonant frequencies. Staggering the edges of the planes softens the impedance mismatch and reduces the Q of the resonance. In fact, in contrast to the recommendation not to split the 0V plane, it is a good idea to split power planes into several smaller planes each of which supplies a parFigure 1: Separation of signal and return

Figure 2: The effect of a discontinuity on return current






Figure 3: The problems of split ground planes

ticular application, and to decouple these from each other with small ferrite chip inductors.

#### Ground planes in the z direction

Successful implementation of a 0V plane on a PCB requires careful attention to the layer stack-up, that is, the order in which the different tracking purposes are assigned to different layers. In multilayer (four layers or more) configurations, the most important aspect is that every signal layer should be adjacent to a 0V or power plane layer. Also, power and 0V planes should be on adjacent layers, possibly with deliberately thin separation, to take advantage of the interlayer capacitance for high frequency decoupling. Critical tracks, for instance those carrying high di/dt signals such as clocks, should be routed adjacent to 0V rather than power planes. Such tracks should also not jump through vias from one 0V reference layer to another, unless the OV layers are tied together with vias near that point.

For boards with more than six layers, multiple 0V plane layers are needed so that tracks and power plane layers can always be located next to a 0V plane, but it is also essential to tie these together with grounding vias at small intervals – intended connections to 0V will provide this automatically, but in areas of the board where this doesn't happen, a 1cm spacing of such "stitching" vias will assure good performance of the planes up to about 2GHz.

One consequence of the dependence on layer separation is that the detail of the vertical sandwich construction of the PCB can be as important for its EMC as is the layout pattern. The separation is determined by the thickness of the pre-preg and core materials used in the build of the bare board. Very often, this is left to the PCB manufacturer and is not specified by the circuit designer, or anyone else. As a result, you end up with the default thicknesses used by a particular board supplier, which might be perfectly adequate for the EMC performance of the product and so is never questioned. But, if another board supplier is chosen during the product life cycle, it is entirely possible that a different set of thicknesses could be used which result in changed performance. To guard against this, make sure that you specify layer thicknesses in the PCB drawing, if necessary checking with your preferred supplier what their defaults will be.

#### **Constant impedance tracks**

It is becoming commonplace to find that some tracks, because they carry very high frequencies or are routed long distances, have to be treated as transmission lines so that reflections along their length are minimised. This contributes both, good external EMC in the form of lower emissions and good signal integrity, improving the reliability of the circuit. This means that the tracks have to avoid discontinuities in their linear and cross-sectional geometry. This in turn requires that:

They should only run in one layer, with no vias except at their ends

This layer should be adjacent to one (microstrip) or two (stripline) 0V planes

The track cross-section dimensions and dielectric constant of the layer should be defined and controlled throughout the layer to give the correct constant transmission line impedance

Changes in direction of these tracks should be gradual rather than abrupt.

This then requires that at least one layer on a PCB is devoted to these "constant impedance" tracks, and at least one adjacent ground plane layer (completely unbroken) is essential to maintain their characteristics.

#### Devoting a layer to ground

The ground plane has enough functions on any electronic circuit board to ensure that at least one layer needs to be devoted to it alone. For all multilayer boards, it can be incorporated as a matter of course. Even for low cost double sided boards, with care, a ground plane can be implemented on one side, provided that the rules about avoiding breaks are understood. When such a plane is implemented properly, the external EMC of the board is automatically improved. Even simple analogue circuits are susceptible to exposure from radiated RF fields in the environment and any designer who consciously avoids putting in a ground plane, on the grounds of cost, will find that satisfactory EMC performance will need greater cost and effort than if the plane had been implemented from the start.

'EMC for Product Designers' is available from Elsevier.



### Reader offer: x1, x10 switchable oscilloscope probes, only £21.74 a pair, fully inclusive\*

\*Additional pairs as part of the same order, only £19.24 each pair.

Please supply the following:

#### Probes

Name

Address

Postcode

Telephone

Total

Method of payment (please circle) Cheques should be made payable to Telivision

Access/Mastercard/Visa/Cheque/PO

Credit card no\_

Card expiry date

Signed

Please allow up to 28 days for delivery

Seen on sale for £20 *each*, these highquality oscilloscope probe sets comprise:

- two x1, x10 switchable probe bodies
- two insulating tips
- two IC tips and two sprung hooks
- trimming tools

There's also two BNC adaptors for using the cables as 1.5m-long BNC-to-BNC links. Each probe has its own storage wallet. To order your pair of probes, send the coupon together with £21.74 UK/Europe to **Probe Offer, Television, Nexus Media Communications, Media House, Azalea Drive,** 

Swanley, Kent BR8 8HU

Readers outside Europe, please add £2.50 to your order.

#### **Specifications**

Switch position 1 Bandwidth Input resistance Input capacitance Working voltage

Switch position 2 Bandwidth Rise time Input resistance

Input capacitance Compensation range Working voltage DC to 10MHz 1MΩ – i.e. oscilloscope i/p 40pF+oscilloscope capacitance 600V DC or pk-pk AC

DC to 150MHz 2.4ns  $10M\Omega \pm 1\%$  if oscilloscope i/p is  $1M\Omega$ 12pF if oscilloscope i/p is 20pF 10-60pF 600V DC or pk-pk AC

Switch position 'Ref' Probe tip grounded via 9MΩ, scope i/p grounded

# Power Conversion Topology

**Philip Lioio**, Senior Field Applications Engineer at Vicor Corporation, in Andover, Massachusetts, analyses the noise for different DC-DC converter topologies

In the systems throughout the world are powered by direct current (usually after AC rectification), which in most cases is converted by DC-DC converters to the voltages needed by each part of the system. Today, power conversion is usually accomplished by high-density DC-DC converter components based on high-frequency switching technologies.

Efficient high-frequency operation has long been recognised as the key to achieving high-power density and improved performance in switch-mode converters. High-frequency operation translates into smaller magnetics and capacitors, faster response times, lower noise levels and smaller filters.

Unfortunately, however, all DC-DC converters generate electromagnetic interference (EMI) or noise. This noise – common mode, differential mode and radiated noise – can vary widely among DC-DC converters from supplier to supplier and topology to topology. The reasons for this are diverse, but they include fundamental differences in the way noise is produced.

#### Knowing your noise

Although many different topologies are used, none is superior in every respect. Some applications have requirements that are best satisfied by a specific topology. Although the number of designs, or topologies, of DC-DC converter components certainly number in the hundreds, two are dominant: pulse-width modulation (PWM) and quasi-resonant zero-current switching (ZCS).

Full consideration of the large number of topologies available could be a daunting task, so it is helpful to consider the noise performance of the two main topological classes. Specifically, a comparison is made between DC-DC converters using fixed frequency PWM and variable frequency quasi-resonant ZCS.

PWM converters are power density limited because they inherently trade off efficiency against operating frequency. The problem is the switching losses – heat is generated in the switching element each time it discontinuously makes and breaks inductive current flow during its brief turn-on and turn-off transitions.

Power dissipation, due to switching losses,

increases directly with operating frequency in PWM converters until it becomes a dominant loss factor. At that point, efficiency declines rapidly and the thermal and electrical stresses on the switch element become unmanageable. Losses attributable to non-ZCS result in a "frequency barrier" which limits achievable power density in conventional converters.

Quasi-resonant ZCS converters overcome the frequency barrier by implementing a forward converter switching at zero current. Each switch cycle delivers a quantised "packet" of energy to the converter output, with switch turn-on and turn-off occurring at zero current. ZCS results in an essentially lossless switch.

ZCS converters can operate at frequencies in excess of 1MHz. By eliminating the fast current discontinuities, characteristic of conventional topologies, zero-current switching results in a virtually lossless transfer of energy from input to output, with dramatically reduced levels of conducted and radiated noise.

The noise generated by the switch is a major difference between PWM and ZCS converters. **Figure 1** shows a comparison of conducted input noise generated by ZCS and PWM DC-DC converters.




Figure 1: Conducted input noise for zero-currentswitching converter with a common mode choke (left) and conducted input noise for pulse-width modulation converter with filter (right). Both 48V input, 5V output, 30A Among other differences (because ZCS converters have sinusoidal waveforms rather than square waveforms), the lack of sharp edges and lower harmonic content results in much less excitation of the parasitic elements, resulting in less noise. With the pulse-width modulation approach, the input voltage is switched at a constant frequency (usually several hundred kilohertz) to create a pulse train. The width of the pulses is adjusted to provide the necessary power to the load at the correct voltage. At full load, the current waveform looks much like a square wave (see **Figure 2**).

#### **Designing filters**


Many designers intuitively assume that it's easier to design a filter for a fixed frequency converter than for a variable frequency converter. In reality, the opposite is true. The perception is, in all likelihood, attributable to the term "fixed frequency", which is actually a misnomer. Both topologies have frequency elements that are more or less fixed and frequency elements that vary as a function of operating conditions.

Figure 2 compares the waveforms of the current flowing through the main switch. In a module using a quasi-resonant topology, the pulse width (T1) is fixed, while the repetition rate (T2) is variable. In a module using PWM, the opposite is true; the repetition rate is fixed and the pulse width is variable. Each of these topologies generates characteristic noise spectra as shown in **Figure 3**.

In the variable-frequency design, however, there are no high-frequency components associated with the leading and falling edges of the current waveform (T3), because it is essentially a half-wave rectified sine wave. The spectral content of the variable frequency waveform is lower in amplitude and contained in a narrower band.

In PWM converters, most of the energy is at the fixed frequency and odd multiples (harmonics) of it. A 100kHz PWM converter will have most of its conducted noise at 100kHz and some at 300kHz and 500kHz. They also have significant harmonics at or above 10-30MHz, due to the shape of the current waveform, i.e. high *di/dt* that excite parasitic elements within the converter. The input conducted filter has to be sized to handle maximum power at 100kHz. In the fixed frequency waveform, the spectral content is higher in amplitude and spread over a broader range of harmonics.

It is clear that an effective first step to minimise noise generated by the DC-DC converter is to select a topology – such as zero-current switching – that is inherently lower in common mode noise. Incidentally, some products should be avoided in noise-sensitive applications. Control devices mounted on copper plates, for example, create par-



asitic capacitance from primary referenced control devices to secondary referenced control devices through the copper base, resulting in high common mode noise.

#### **Passive EMI filter examples**


Although component power modules usually incorporate some internal input and output filtering, additional external filtering is often needed to meet either system requirements or agency specifications. For example, FCC and European agencies specify the allowable levels of power supply noise that may be conducted back into the AC line. Many designers tackle these issues on their own, but most DC-DC converter manufacturers provide detailed application notes and offer the assistance of a knowledgeable, experienced and easily accessible applications engineering staff. In addition, some DC-DC converter suppliers also offer AC front-ends and EMI filters as modular accessories. These filters not only save time, they also are a means of risk prevention, as well. The EMI filter is designed to work with the supplier's converter modules, and, assuming proper layout, the combination is certified to meet the specified EMC directives.

Figure 2: Current waveforms produced by zerocurrent switching and pulse-width modulation

forms and spectral content for PWM (top) and ZCS (bottom). sions Note; waveforms not of drawn to scale

Figure 3: Current wave-

In the US and Europe, conducted noise emissions are governed by the Class A and Class B limits of








Figure 4: Input EMI filter for EN55022, Level B compliance





both FCC and VDE standards. In the US, the FCC requires compliance with Class A for equipment operating in factory settings and Class B – the stricter standard – for equipment destined for home use. In Europe, all countries require that equipment for both home and factory use meets the VDE Class B standard.

Most switching power supplies today operate in the frequency range between 100kHz and 1MHz. Usually, the dominant peaks in the conducted noise spectrum reflected back to the power line correspond to the fundamental switching frequency and its harmonic components. Conducted emissions standards such as EN55011 and EN55022 set quasi-peak and average limits on conducted noise reflected from the input of converters or power supply systems, back to the source over the frequency range of 150kHz to 30MHz. In order to comply, all of the conducted noise (the peaks in the spectrum) must fall below the specified limits.

EMI filters are most often constructed in a single package (with configurations similar to that shown in **Figure 4**). The EMI filter is a through-hole filter with a common mode choke and Y-capacitors (lineground), plus two additional inductors and an Xcapacitor (line-line). Transient protection is provided by Z1. This filter configuration provides sufficient attenuation to comply with the Level-B conducted emissions limit.

Nevertheless, capacitors, inductors and filters (both active and passive) are commonly used in power supply designs to attenuate the amount of conducted noise, both common-mode and normalmode. First, the effects on the noise spectrum of adding individual components or filters are shown leading up to the result with a full common-mode filter. Then, one approach to meeting EMI compliance in a contemporary application is discussed.

The 48V input DC-DC converter shown on the left in **Figure 5a** has a differential mode capacitor (C1) on the input. This single-mode electrolytic capacitor,  $120\mu$ F, 100V, is used to ensure low input impedance, stability and good transient response. It's an energy reservoir for the converter. To reap the most benefit, the capacitor must be as close to the input pins of the module as possible.

The module alone and that one capacitor provide a baseline from which to start. The spectra in Figure 5a on the right shows the harmonic content of the noise and the EMI limits, A and B levels, for this converter and differential mode capacitor combination. These measurements were made at 100% load, nominal line for a 48V, 150W DC-DC converter. With this differential mode capacitor only, the converter is clearly not meeting the limits, but the power component is not designed to meet any specific EMI limits. The effect of adding bypass caps to the converter and differential mode capacitor combination, shown in **Figure 5b** is rather dramatic. Notice the bypass cap on each input pin to the base plate, which is ground and each output pin to the base plate. These electrolytic capacitors are 4700pF, 100 V Y caps that are commonly used in the industry. The Y caps are very effective in attenuating the type of noise that the power component generates.

The 48V design with 100% load generates a little higher noise than a 3.3V design with a 50% load would, for example, but, nevertheless, the spectrum in Figure 5b shows some significant improvement.

Even with the addition of a  $27\mu$ H differential inductor (L1), **Figure 5c** shows that the 48V design is still not compliant at the lower frequencies, where noise is still present above the B limits.

**Figure 5d** shows the next stage. We're adding a common mode choke. The differential mode choke is eliminated because the common mode choke does have differential mode inductance. The common mode inductor accentuates the capabilities of the Y capacitor. That's because it provides high impedance to common mode noise being conducted out of the converter, therefore, the noise follows the path of least resistance to ground, which is through these Y caps.

The spectrum of the 48V converter is just peeking over the top of the B limit, so, a little more filtering would be needed on a 48V converter design. The noise spectrum of a 3.3V converter with a common mode filter would be below the B limit both at 50% and full load.

#### Active EMI filter example

The trend toward smaller devices with more functionality in smaller spaces continues unabated in the electronics industry. As spaces shrink, the potential interference between devices increases as systems contain more functions in densely packed boards and racks. As frequencies rise and voltage levels fall, the control of conducted EMI becomes an even more important design task. EMI control, a complex design task that is highly dependent on many design elements, makes use of filters, both passive and active, to manage conducted noise.

Active EMI filters, in contrast to passive solutions, reduce the volume of the common-mode choke, allowing the filter to be packaged in a 1" x 1" x 0.2" package, and provide a low profile, surface mount device. Smaller size saves valuable board real estate and the reduced height enhances airflow for better heat management.

Active EMI filters (labeled QPI in Figure 6) are available that attenuate conducted-mode and differential-mode noise over the frequency range of




Figure 6: Typical diagram for an active EMI filter (labeled QP1) for a DC-DC converter. Values of Cin and C1, C2, C3 and C4 are those normally recommended by the converter manufacturer





Figure 7: Conducted EMI profiles of a DC-DC converter with no filter (above) and with an active EMI filter (below)



150kHz to 30MHz, required by the conducted emissions standard EN55022 (CISPR22).

**Figure 7** shows before and after plots of a DC-DC converter noise profile to demonstrate the performance of an active filter. The plots were taken using the standard measurement technique and set up as defined in CISPR22. The results show the total noise spectrum for a standard DC-DC converter under load compared to the EN55022 Class B quasi-peak detection limit. The plot shows that an active filter is effective in reducing the total conducted noise spectrum to well below the required limits.

Designers should be aware that to select and qualify an EMI filter for conducted noise, they must test the filter in their product under the set-up and conditions specified in the applicable EMI standards. Filter selection or design must be based on the pre-filtered noise magnitudes and the frequency spectrum of concern. A product's conducted noise profile includes differential and common-mode noise. It may also include radiated noise, depending on the EUT shielding and cabling screening in the measurement setup. The IEC (International Electrotechnical Commission) special committee on radio interference specification CISPR 16-2-1 describes the methods of measurement for conducted disturbances.

Filter performance in the application is highly dependent on the input bus and load impedance and cannot be extrapolated from zero bias 50-Ohm insertion loss data alone. Final noise performance is a complex function of filter elements, equipment grounding and noise source impedances, which vary in magnitude and phase over the frequency spectrum of interest.

The active EMI filters provide active commonmode attenuation of conducted noise over the EN55022 range from 150kHz to 30MHz by sensing the common mode current flowing in the bus lines and creating a low impedance at the shield plane to re-circulate the noise back to the generating source. When connected as shown in Figure 6, the control loop will actively drive the shield pin and reduce the common mode current in the bus lines to values approaching the common-mode current ratio attenuation curve in Figure 7.

Easy-PC for Windows

Fully integrated Schematics & PCB layout in a single application complete with forward and back annotation. Design and rules checks at all stages ensure integrity at

all times. Professional manufacturing outputs allow you

to finish the design process with ease.

Stop press... Stop press... Stop press... Stop press...

Easy-PC imports Eagle files as well as Tsien Boardmaker 2 files

### No1 Number One Systems

#### The world beating PCB design software



#### Easy-PC version 9 just gets better

Winning accolades the world over, Easy-PC for Windows V9 is another major milestone in the evolution of this extremely popular software tool. Try a demonstration copy of Easy-PC and prepare to be amazed at the power, versatility and remarkable value for money.



#### Version 9 fetaures

- 3D Board View
- New Win XP User Interface
- Reverse Engineer SCM from PCB
- Track Fattening
- Interactive Schematic Routing
- New Sliding Toolbars
- Component Clearance Checks

Alphanumeric Pin Names Plus many more exciting features.....

you can also download a demo from www.numberone.com



Number One Systems - Oak Lane - Bredon - Tewkesbury - Glos - United Kingdom - GL20 7LR UK

call for a brochure, prices & CD on +44 (0)1684 773662

or e-mail sales@numberone.com



# **RoHS** what's all the fuss about?

RoHS (the Restriction of the use of certain Hazardous Substances) and WEEE (Waste Electrical and Relectronic Equipment) is the equivalent of Y2K for the electronics industry. The upcoming EU environmental directives are the most significant developments in electronics legislation to happen in many years and will

completely revolutionise the way electrical and electronic products are designed, sold, recovered and recycled. Worryingly, many design engineers are still not fully aware that the upcoming legislation will affect them. For those who are, many questions remain unanswered. Complicated exemption rules, uncertainty about how the directives will be enforced, obsolescence and component availability has left engineers unsure of what they need to do and when. The clock is ticking. With only several months to go there's no time to lose in the transition to RoHS. If compliant components aren't already part of the design cycle it could well be too late.

Will WEEE registration be required for producers of board-level products (e.g. printed circuit assemblies aimed at hobbyists, PC add-in cards, etc.)?

Steve Ridgeway, UK

A: This is a difficult question and currently under debate in the EC. PC cards are within scope but differences of opinion relate to whether or not they are finished products or components/accessories. This is important because if they are finished goods they must comply with RoHS. If not, they will be spare parts. Germany has decided they are finished goods but not all member states are of the same opinion.

At the subscription levels currently being suggested, WEEE registration might not be financially viable for very small businesses that occasionally produce bespoke items with electrical/ electronic content. What is the advice in this situation?

Steve Ridgeway, UK

**A:** Unfortunately, there is no de minimus level in the directive, so small companies as well as large have to register, otherwise the company may face a fine for noncompliance. It looks like a flat fee will be payable regardless of company turnover.

#### Q: Are cables covered by RoHS?

**A:** The current view of the Commission is that certain types of cable – whether included in EEE or sold separately – do fall within RoHS. However, the DTI takes a different position and is currently in discussion with the Commission over this.

## (): Can I import for own use?

A: No. The EC's 'Guide to the implementation of directives based on the

#### New Approach and the Global Approach' declares that imports for own use are still considered as 'placed on the market'.

#### Can I manufacture noncompliant EEE in-house for own use?

**A:** Yes. Products built for own use are, generally, not considered as being 'placed on the market' (The EC's 'Guide to the implementation of directives based on the New Approach and the Global Approach').

Will I be able to use non-RoHS compliant material for capacity expansion or an upgrade in electrical/ electronic products put on the market before 1 July 2006?

A: In principle, the use of non-RoHS compliant material in EEE products put on the market before 1 July 2006 for the purposes of capacity expansion/upgrades is allowed, providing that the EEE is not put on the market as a new product.

## Does RoHS and WEEE apply to ink cartridges?

**A:** The cartridge itself does not fall under the definition of EEE. It is considered to be a consumable and therefore the RoHS directive does not apply. However, if the cartridge is inside a discarded printer, it is considered part of the WEEE because it is a consumable that is part of the printer at the time of discarding.

# How do I find out about the latest new exemptions?

**A:** It is best to seek advice from DTI policy regarding the progress of exemptions. A full list of exemptions can also be found on the Farnell InOne website.

## What is the official definition for a 'Producer'?

A: The Directive defines a 'producer' as a party who:

Manufactures and sells EEE in an EU
Member State under their own brand

 Sells under their own brand equipment produced by another manufacturer

 Imports or exports EEE on a professional basis into an EU Member State.

# Does the wheelie bin symbol replace the producer identification marking?

**A:** No. The symbol requirement is in addition to the producer identification marking, which must appear on the product itself.

#### I understand that the Directive applies to medical equipment with the exemption of all implanted and infected products. What are infected products?

**A:** Infected products are understood to be products that have come into contact with blood or other biological contaminants prior to end-of-life.



Gary Nevison is chairman of the AFDEC RoHS team, board director at Electronics Yorkshire and head of product market strategy at Farnell InOne. As such he is our industry expert who will try and answer any questions that you might have relating to the issues of RoHS and WEEE. Your questions will be published together with Gary's answers in the following issues of Electronics World.

Please email your questions to EWeditor@nexusmedia.com, marking them as RoHS or WEEE.

**Power Amplifiers** 

# The New Standard of Reliability for Power Amplifiers

**Craig Andrews** from Silicon Laboratories analyses how to calculate reliability in power amplifiers and what the best methods may be

anufacturers of power amplifiers (PAs) have tried to address reliability issues over the years with differing results. Great improvements in factory yield were achieved by integrating power control into GSM PAs in 2001. Since innovations often come in five-year cycles, the next level of innovation is now due.

The thermal demands on mobile phones are increasing due to high duty-cycle transmission and the integration of antennas within the phone packaging. Industry changes make it necessary to eliminate the thermal sensitivity of PAs.

Further improvements in PA reliability are needed. Traditional reliability estimation methods rely on limited thermal modelling in combination with mean time to failure (MTTF) statistics, where reliability is typically quoted as MTTF at a specific temperature. This method is inadequate since the junction temperature is unknown during actual operation. It is necessary to move to the next level of quality to ensure the long-term reliability of PAs.

This paper will present MTTF calculation methods, thermal model construction and a circuit that removes the uncertainty of device lifetime. This paper will also suggest future steps to improve PA reliability.

#### MTTF or activation energy

Projected reliability in PAs uses a widely-accepted statistical method. Unfortunately, manufacturers use different parameters to project reliability. Some manufacturers quote only activation energy while others quote only MTTF. However, reliability is a multi-dimensional problem that cannot be quoted based on a single-dimensional property. Therefore, it is important to understand reliability calculations in order to understand product reliability. The Arrhenius equation is the basis for calculating device reliability:

$$\ln\left(\frac{t^2}{t^1}\right) = \frac{Ea}{k} \cdot \left(\frac{1}{T^2} - \frac{1}{T^1}\right) \tag{1}$$

where:


t1 = reference time to failure at reference T1

- t2 = time to failure at T2
- Ea = activation energy (unique to process)
- T1 = reference temperature for failure time t1 (temperature in Kelvin)

T2 = temperature to calculate failure time t2 (temperature in Kelvin) **Equation 1** calculates median time (t2) of failure, based upon a known median time (t1) of failure, failure activation energy (Ea) and failure temperature (T1). Activation energy is the amount of energy required to induce a specified failure mechanism in a semiconductor technology. Equation 1 can be manipulated to produce **Equation 2**, which expresses lifetime in terms of MTTF:

$$MTTF(T2) = MTTF(T1) \cdot e^{\frac{Ea}{k} \cdot \left(\frac{1}{T2} - \frac{1}{T1}\right)}$$
(2)

The temperature dependence on reliability can be seen by graphing Equation 2 as a function of temperature. **Figure 1** shows MTTF plots for two different manufacturing processes. Both processes have the same MTTF at 125°C. The only difference between the two processes is the activation energy. One



#### Figure 1: MTTF vs temperature

process has an activation energy of 1.0eV and the other process has an activation energy of 1.8eV.

After looking at Figure 1, it is clear that reliability is highly dependent on the device operating temperature. To put it in

(3)

perspective, when operating at 150°C, the process with the lower activation energy outlasts the other process by three billion hours of operation even though the process with higher activation energy has longer lifetimes at temperatures below 125°C. The slopes of the lines in Figure 1 are the activation energies for each process. Thus, higher activation energy results in a steeper slope with respect to temperature, showing an increased failure rate.


Some engineers characterise the quality of a process by the activation energy. Others simply quote MTTF at a specific temperature. From the previous analysis, it is clear that both views represent an overly simplistic approach to reliability. One must consider the device's operating temperature before making a judgment on the optimal activation energy. Likewise, MTTF must be quoted at the operating temperature under worst-case conditions. For reliability estimation, one must consider the device's operating temperature and the inherent failure rate of the process.

#### **Junction temperature**

The next step is to look at how junction temperatures in PAs are affected by their operating conditions and packaging.

A common technique for analysing peak junction temperature is a thermal model analogous to Ohm's law. Anything that creates heat is modelled as a current source with the units of watt. All materials are given a thermal resistance with the units of °C/W. These materials also have the ability to store heat, which is called the thermal capacity (J/°C) and are modelled as capacitors.

Figure 2 shows the model of a packaged single die PA. Looking at the static case where the capacitance is ignored, the





junction temperature is the sum of the ambient temperature,  $T_{A}$ , and the product of the dissipated power and the system thermal resistance as shown in **Equation 3**. In the dynamic case, the thermal capacity would have to be considered.

#### Tja:=P\_diss-(Rth\_ja+Rth\_jb+Rth\_jc)+Ta

Equation 3 can be evaluated using values from the RF3220 WLAN PA. Rth = 76°C/W; P\_diss = 0.997W; T\_A = 85°C. These values will yield a junction temperature of 160.8°C. As shown, the junction temperature is dependent upon dissipated power. If the bias current, output power or efficiency change, the dissipated power will also change. This will result in a different junction temperature.

These conditions are for a PA in a package with good thermal conductivity operating at an output power of 250mW. Since the output power levels for WLAN are low, it is easier to achieve acceptable temperatures that result in longer life.

All of the previous calculations assumed a  $50\Omega$  load condition. An example of worst-case conditions is shown in **Figure 3** where a mismatch (non  $50\Omega$  load) at the antenna causes power to be reflected back to the PA. Under high mismatch conditions, very little power is actually radiated. Since physical laws dictate that energy is conserved, the power reflected back to the PA is dissi-




Figure 3: Power flow in mismatch conditions

pated in the form of heat. Conversely, if the PA is heating due to reflected power, the phone is not radiating as much power. It is important to note that under these conditions, the phone will have trouble maintaining the call due to insufficient radiated power.


The sensitivity of this condition is dictated very much by the device technology. Thermal conductors, such as silicon, dissipate heat very efficiently due to their low thermal impedance. Thermal insulators, such as GaAs, tend to heat more under mismatch conditions due to their poor thermal conductance.

#### **Thermal management**

To fully appreciate the importance of thermal management, it is important to consider a GSM PA operating under worst-case conditions. This will help clarify how elevated temperatures impact device reliability.

The following case should be considered, as it will produce a worst-case situation:

- GSM PA transmitting 34.5dBm (for highest dissipated power)
- 50% efficiency (actual efficiency can be worse at high supply voltage)



38

ELECTRONICS WORLD - February 2006

≶

- Laminate package (for highest thermal resistance)
- 10:1 output impedance mismatch (worst-case load impedance)
- 50% duty cycle (GPRS class 12)
- Ambient temperature of 85°C

Industry leaders have known that laminate substrates are problematic since at least 1999. It is best to perform the calculation with the thermal impedance of laminate; however, since PA manufacturers do not publish laminate thermal impedances, the following calculation will be based on a lead-frame package. The data from the RF3220 will be used since it is a heterojunction bipolar transistor (HBT) in a lead-frame package.

Using Equations 2 and 3, the MTTF under ideal conditions is calculated to be 8 x  $10^5$  years. Under typical conditions, it is  $1.9 \times 10^3$  years. Calculating using worst-case conditions, the MTTF is reduced to about one year. Using the thermal impedance for laminate and the dynamic thermal model, the MTTF degrades even further.

An important note is that the MTTF reports a mean time to failure. To know when the worse-case failure would occur, one would need to consider the spread. Standard quality procedures dictate a process capability (Cpk) of 1.5, which corresponds to a spread of 4.5 standard deviations. For the process being discussed, the standard deviation of the time to failure is 0.6 on a logarithmic scale. Since one would subtract 4.5 standard deviations on a logarithmic scale, one divides on a linear scale. This would mean that all of the aforementioned MTTF values reported would have to be divided by  $4.5 \times 10^{0.6}$ . The worst time failure is actually 17.92 times worse than the average failure rates. These results show how a PA lifetime can go from thousands of years of life to less than a month, by considering the worst-case conditions and the distribution of lifetime due to the process.

The discussion of thermal modelling presented thus far does not address the true environment where the PA will be used. The real environment has the PA mounted on a circuit board in an enclosed package with high thermal resistance and on other heat generators coexisting with the PA.

To accurately model the junction temperature for the PA in a mobile phone, one must construct a model is shown in **Figure 4**. There must be a power source for each device that will dissipate heat.




Figure 5: Over-temperature protection circuit

It is easy to see that the thermal model for a mobile phone is too complex to estimate using a simple calculation. A threedimensional thermal simulator must be used to accurately predict the maximum junction temperature. Thus, accurately predicting the lifetime of PAs in a mobile phone becomes nearly impossible.

The accuracy of the results is further complicated when the PA is designed in a thermally resistive technology, such as gallium arsenide (GaAs). The thermal impedance of GaAs is three times larger than that of silicon (Si). Furthermore, the thermal impedance of GaAs is also temperature dependent, where the thermal impedance increases as the junction temperature increases. This could be very problematic if the thermal model is extracted under ideal conditions. Detailed analysis has shown that a number of device issues contribute to the complexity of this model.

- Spacing of emitter fingers greatly impacts thermal coupling
- Self-heating nature of GaAs HBT
- Bias circuits can cause part of the device to run hotter than some other of its parts
- Variations in bias current
- Longer emitter fingers introduce a greater thermal gradient across the device and can result in thermal runaway on only a limited portion of the emitter finger
- Asymmetrical device geometries are required to maintain uniform temperature distribution

The complexity of thermal models and the extreme sensitivity to heat show why PAs continue to have the highest defect rate of the various components in mobile phones. It is essential to improve PA reliability. There are two methods of addressing this issue. The first is to do complex modelling to accurately predict the junction temperature under worst-case conditions. However, modelling does not fix the problem, it only predicts the failure. The second method is to design the PA in such a way that these temperatures are never achieved. The latter should be the new reliability standard for PAs.

#### **Building temperature sensors**

An over-temperature protection circuit is an easy way to address this concern. The temperature sensor is placed on the die in such a way that it detects the maximum junction temperature. There are several ways to build a temperature sensor. An example of a temperature sensor is shown in **Figure 5**. The logarithmic amplifier senses the voltage, which changes based on the temperature-varying current through the transistor. The output of the logarithmic amplifier is linear with respect to temperature. Finally, an error output comes from a comparator circuit. When a pre-determined temperature is exceeded, the error output changes to indicate that the PA should be turned off. The output of this circuit can be used to drive a disabling circuit that limits the maximum temperature.

This circuit guarantees that the PA will never enter an unsafe region that would cause rapid degradation of the device's lifetime. It eliminates the need for complex modelling and provides a way of reducing the defect rate of PAs. With the coexistence of silicon in most PA modules, it should be the standard that PAs also integrate protection circuits to ensure reliability. The placement of the temperature sensor is dependent upon the device technology. In a technology that has low thermal resistance, such as silicon, the placement is not critical since the heat spreads evenly. However, in insulating technologies, such as GaAs, it is essential that the temperature sensor be placed near the hottest portion of the die.

If the PA does not have a thermal protection circuit, the modelling must be approached very carefully. As discussed, there are many elements the model must include to be accurate. Furthermore, the estimation of MTTF for certain processes is inconsistent.

Despite the advances that have been made, it is important to continue to look forward and think about the next steps in improving the quality of PAs. As mobile phones integrate more functionality, advances in the RF section must allow the development effort to focus more on added features and not the RF section. Some possible efforts that could contribute to this are:

- Ensure that all data sheet specifications are guaranteed across all conditions (temperature, voltage, etc.)
- 2. Improve the moisture sensitivity (MSL) rating of PAs.
- Implement over-voltage protection circuits that protect the PA during mismatch.

#### **New PA standard**

Modern standards of quality dictate that devices should be designed to avoid any mode that could be destructive to the device. This standard has been applied to all other circuits except PAs.

If one chooses a PA without a thermal protection circuit, the MTTF data from corner lots that include extreme combinations of bias current, output power and efficiency should be provided by the supplier. Additionally, PA suppliers should provide MTTF data from corner lots taken under worst-case conditions including 50% duty cycle and at the worst case current in a 10:1 VSWR. Suppliers should also provide confidence intervals, including confidence of the mean and standard deviation, which offer statistical calculation of the confidence of the data. This should include standard deviations for all MTTF data. Lastly, suppliers should also offer thermal impedance and thermal capacity of the complete package referenced to the hottest point on the die.

Collecting this extensive data is difficult, thus, an easier and more effective approach should be adopted. It should be required that PAs monitor their own temperature and reduce operation when acceptable conditions are exceeded. This should be the new standard for PA reliability.



111-

he European Commission (EC) launched the Radio and Telecommunications Terminal Equipment Directive (R&TTE), or Directive 1999/5/EC, in 2000. It had – and still has – the laudable objectives of making the European Telecommunications market more open while simultaneously reducing time and costs of entry for manufacturers.

Prior to R&TTE, the telecommunications regulator for each EU member state (in the UK, the Radio Communications Agency, now Ofcom) issued national performance standards, compliance with which was mandatory, obtained by submitting samples of products to an approved test house for testing against the appropriate standard, Success resulted in the issue of a Type Approval Certificate. This gave the supplier legal means to introduce his product to the targeted national market.

The procedure was criticised by industry as slow, inefficient and expensive, since every EU member state demanded compliance with its own stan-

# The R&TTE Directive – An Opening Too Far?

dards and regulations. Additionally, National Type Approval inevitably invited criticism by importers of protectionism to local producers.

Since a major objective of the European Commission was to develop an open 'common market', elimination of such potentially restrictive practice was a priority. National radio performance

standards were eliminated with the formation of ETSI (European Telecommunications Standards Institute), wherein technical committees formed from representatives of national regulators and industry produced EU-wide standards, with the accent on 'harmonisation'.

In parallel, the R&TTE Directive introduced procedures to make product placement on the overall EU market: simple, quick and cheap.

R&TTE introduced the concept of voluntary standards in which compliance with its 'essential requirements' alone was needed, together with the concept of 'presumption of conformity'.

Presumption of Conformity gives a manufacturer (or an

importer) of declaring that his product complies with the harmonised ETSI standard, thus allowing him freedom to launch a product into the whole EU, without the need to undergo Type Approval tests.

There is a requirement on such "self-declaration" suppliers to maintain technical files, supporting the product against the possibility of inspection from a regulator. There are severe penalties for wrongful declaration, but, in a budget-conscious world, where costs of maintaining inspection capability (UK, Radio Investigation Service) are high, inevitably there are those that will take the risk.

Thus, the EU market is wide open but the regulators have lost their main tool – the Type Approval Certificate – for identifying and tracking down suppliers exploiting dishonestly the freedom given to the industry.

At the same time, other world regions, notably the US and Far East, maintain Type Approval procedures. It is, thus, easier for unscrupulous suppliers to dump inferior products in Europe than it is to enter their own markets.

Unless these regions adopt an R&TTE-like procedure, and there are few signs of this to rebalance the situation, Europe is likely to become a happy hunting ground where local, conventional and honest suppliers are disadvantaged against non-compliant imports, while the regulators are impotent to support them.

This situation could lead to poor quality souring the market against radio products, particularly SRDs, which are increasingly used in consumer products, including toys.

Maybe a small step backwards is needed. No one wants to return to National Type Approval but maybe the re-introduction of a European Type Approval Certificate, valid in all member states and issued by any notified body (a test house – in this context) will provide ammunition for regulators and protection for bona fide suppliers.

Reader's views would be much appreciated on this subject, which is currently under discussion in the ECC (European Communications Committee).

#### Wireless Software Solutions Firmware revision 2.1 Jan 05

Designed and manufactured in the UK by LPRS Limited, Witney, OX28 4BH Tel: 01993 709418 Email: info@lors.co.uk If Bluetooth, 802.11, Zigbee, UWB etc don't suit your wireless application – "easy-Radio" will. ER modules are embedded with all the wireless software you will need to achieve a short range wireless link over several hundred metres at speeds up to 19.2K over air.

New robust software ensures stability of user selected frequency, data rates and output power, configurable via Windows based software.

Go to our website to order an evaluation/programming kit and use our online calculator to see how time is saved and revenue returned faster with "easy-Radio" software solutions.



444-



# easyRadio for all!

You can do it the hard way or the easy way when it comes to creating a wireless link for your system, says **Barry Gillibrand** of LPRS

L

o, the fact that you have made it past the title and are reading this, means that you either thought, "Hey! That looks cool or "With easyRadio, Rodney, next year we'll be millionaires!"

Well maybe not. At least you must have a little bit of interest in delving that bit deeper into the world of radio.

All too common, the sales meeting echoes time and again: "If only did this or that, we'd sell buckets-load more". As usual, a tired, stressed and usually 'already up to his neck in projects' designer is faced with that dreaded question: "How long will it take?"

For the instances of "this or that" being a wireless link, easyRadio has been developed to give a more positive answer to that very question, and this article aims to help you to see the reasons why it really doesn't have to be that difficult to enter the world of radio comms.

#### **Getting started**

If you have developed products with wireless links before, you will already know that integrating radio links into your application presents an obvious decision: make one or buy one.

For the gurus of this world, the first one will cause no lack of sleep, particularly if you have a team of designers around you as well. However, this option very often amounts to making a product on its own, so for the rest of us, the second option is undoubtedly the easier route.

Ready made modules also come in two varieties, dumb modules with which you have to control the power and full data modulation and a protocol system that can be reliably reversed within the receiver, without interrupting the actual function your product is supposed to do in the first place. Two-way communications naturally require both systems at each end. Then there are 'intelligent' modules where data is uploaded/downloaded in some form or another and this is where easyRadio comes into its own. Using well-supported communications found within most budget microcontrollers in the form of the much-loved RS232 UART interface. With this technology, gone are the days of time and resource-wasting routines to handle the mundane task of actually getting the data to where it is supposed to be. EasyRadio does for an application what visual basic did for Windows development.

#### Easy does it

Obviously, every project is going to be different and no 'how to' style article is going to give you an exact solution to your requirements.

So what we'll look at is a general, overall introduction to making a simple two-way radio link.




Figure 1: Schematic of a development board

We could just use a complete easy Radio evaluation kit, but that would be all too easy. Instead, setting up a microcontroller to link to a PC seems a bit more useful. On the PC end, however, we will use one of the boards from an evaluation kit, but it is simply to save time in putting together a board with an RS232 level shifter (MAX232) on it and a plug and power source, which is all it basically is. If you want to make one, you could use the schematic in **Figure 1**.

Incidentally, there are lots of development boards around these days. One of my favourites is the trusty millennium board from Elgar (Bluebird), where you have lots of sockets for your PIC processors, switches, LEDs, LCD, keypad, RS232 shifter and proto board.

An easy radio module would fit in there nicely. As I only have one to hand, we will use this development board for the microcontroller end, and the easyRadio evaluation kit PCB for the PC end.

I've decided to use a PIC16F627, although any PIC with a UART would be good for this, as would any from Atmel, Texas Instruments, Motorola and others. It just happened to be in my armoury of parts to have a go with (and it works on the Millennium board).

The modules on each end of the link are both ER400TRS-02. These are transceivers that operate on the 433-434MHz bands and have all the capabilities within to encode/decode, whatever RS232 data you throw at them. The '02' refers to a second generation of devices, which have eradicated the first generation issues of loss of setting in the EEPROM and frequency consistency.

#### **Easy PIC software**

What the application will do is quite simply an echo of whatever is transmitted from the PC back to the PC, with the text "Echoed from the PIC" added to it.

OK, so it's not the most useful application, but it demonstrates a point and it's quite easy to implement. For the code I've also used the CCS C compiler and the source code may be downloaded for reference from <u>www.lprs.co.uk</u>.

First of all, we have to check that it actually works without the radio modules in circuit. Then, we can see how easy it is to convert it over to a wire-free system using the easyRadio modules.

On the next page is a complete C code example of how easy it is to echo the data received from the UART on a PIC.

After compiling the software, we can program the part with either an ICD2 or PICSTART Plus from Microchip. The PIC can then be connected in the board as shown in **Figure 3**.

To test it we can connect this board directly to the PC and load up the easyRadio evaluation software. It is good to get familiar now with the software as you can use it later.

Opening the Communications tab, you



Figure 2: A development board with all the relevant sockets



Figure 3: Connecting the PIC correctly




Figure 4: Demo board with the power connected

can enter the text you wish to send from the PC. When the software is running on the PIC, anything you send to it will be echoed with the added text (see **Figure 5**).

All that is needed is to swap over the PIC connections from the MAX232 to the ER400TRS instead.

As the internal power rail of the ER400TRS is on 3.3V, it is advisable to buffer the 5V PIC with 1K resistors to the module. It prevents problems with the Schmitt trigger level on the PIC UART when supplied by 5V.

With the power connected to the module as well, our demo board would be connected as in Figure 4.

To complete the link, the second module would be connected directly to the PC, using the easyRadio evaluation kit.

You can do exactly the same again with the software and the result should be identical as before (see Figure 6).

So the two-way link is up and running but there are things to be aware of when communicating with the modules.

- > There is a 180 byte limit on any single transmission;
- > You will have to wait a period of time while the data is being transmitted before uploading more into the buffer. Simply monitoring the BSY pin can do this.

But what makes easyRadio great is the configurability of each aspect of the radio.

- > From the UART data rate to the overair-data rate
- > From the channel frequency to the power output
- > From the digital separation of channels to digital encryption.

All of which can be controlled through a simple command interface.

All easyRadio commands start with the text "ER\_CMD#", after which a function letter is specified, followed by the parameters required to operate it.

When an easyRadio module recognises a valid command stream, it echoes back the text. Then, as a safety mechanism against unwanted command operation, the host will upload the text "ACK" to make the module do what it has been told.

This is dead easy on a PC as the evaluation software demonstrates, but how easy is it to do on a microcontroller. The code function (again using the CCS C compiler) described in Code 2 is all that is really necessary to do it.

So, say you wanted to change the channel number from the default (7) to channel 3. The command you would have to send is "ER\_CMD#C3" (which is 9 bytes in length).

To use the above code simply make a call to the function:

Send\_ER\_Command("ER\_CMD#C3",9);

```
#include <16f627.h>
#device *=16 ADC=10
               INTRC,NOWDT,PROTECT
#FUSES
#USE DELAY(CLOCK=4000000, RESTART_WDT)
#ZERO_RAM
#use rs232(baud=19200, xmit=PIN_B2,rcv=PIN_B1,RESTART_WDT)
#include <stdio.h>
#include <stdlib.h>
#include <string.h>
int Send_ER_Command(char * Command,int Length);
char Buffer[80]:
main()
char
      i,a,TimeOut;
      set_tris_b(0x0F); //set all PORTB as inputs
      TimeOut = 255:
delay_ms(1000); // wait for 1 second (Only really need about 20mS)
//strcpy(Buffer, "ER_CMD#C5");
//Send_ER_Command(Buffer,0x9);
while(1)
      if(KBHIT())
               a = 0;
               while(TimeOut -- )//will stay in this loop until no more data
                        if(kbhit())
                        Buffer[a++] = getc();
                        TimeOut = 255;
```

ł puts("Echoed from the PIC:"); for(i=0;i<a;i++)

```
putc(Buffer[i]);
```

}//end if(KBHIT())

Code 1: Echoing the data received from the UART on a PIC

It's as easy as that. This code does all that's necessary to verify the reply from the module and to send the "ACK" string as required.

#### Other varieties


ł

Other varieties of easyRadio include a dedicated transmitter module for when a one-way link is all that is required and receiver only versions to complement them. A long awaited frequency hopping solution is being developed with the same user interface and development is moving swiftly on.

RF communications needn't be 'black art' for the digital engineer any more. This type of technology is coming of age now and should be taken seriously in any decision to introduce RF into your next project. Is it worth it? Well, try it for yourself and decide. What you'll get is the years of experience in RF data comms, conveniently wrapped up in a little gold (well, brass actually).

```
int Send_ER_Command(char * Command, int Length)
ł
int i;
long Timeout = 0xFFFF; // Long initial wait for the first byte from the module
char RX BYTE:
int Success = true:
      for(i = 0; i < Length; i++) // Send Command byte by byte
       {
                putc(Command[i]);
      11
                Receive the command back from the module
      // Compare the recieved buffr to the sent command
                // Reset
      i = 0;
       while(TimeOut--)
                if(kbhit()) // wait for a byte to appear in the buffer
                          RX BYTE = getc();
                          if(Buffer[i] != RX_BYTE)
                                    Success = false;
                                              //increment pointer
                          i++:
                          TimeOut = 255;
                                             // wait for end of data
       }//end While
      if(!Success)
                          // if replied text does not match then return false
                return false;
      if(i == Length)
      putc('A'); // Command complete
      putc('C'); // Command complete
      putc('K'); // Command complete
      return true;
return false:
1
```

Code 2: Issuing commands to the microcontroller



# What have you been missing?

Back issues of Electronics World

£4 including p+p (UK only) overseas readers – call for details

Please send correct payment to: Electronics World, Nexus Media Communications, Media House, Azalea Drive, Swanley, Kent BR8 8HU





There are a limited number of back issues from 2002, 2003 and 2004

Call Caroline Fisher on 01322 611472 for details


Figure 5: Message window to test the PC link

Figure 6: Test message window

## **Tips 'n' Tricks**

# **PICmicro Microcontroller CCP and ECCP**

The Capture, Compare and PWM (CCP) modules that are found on many of Microchip's microcontrollers are used primarily for the measurement and control of time-based pulse signals. The Enhanced CCP (ECCP), available on some of Microchip's devices, differs from the regular CCP module in that it provides enhanced PWM functionality – namely, full-bridge and half-bridge support, programmable dead-band delay and enhanced PWM auto-shutdown. The ECCP and CCP modules are capable of performing a wide variety of tasks. The tips below describe some of the basic guidelines to follow when using these modules, as well as suggestions for practical applications.



#### TIP 1: Generating an analogue output

Figure 1 Low-pass filter

Pulse-width modulated signals can be used to create digital-to-analogue (D/A) converters with only a few external components. Conversion of PWM waveforms to analogue signals involves the use of an analogue low-pass filter. In order to eliminate unwanted harmonics caused by a PWM signal to the greatest degree possible, the frequency of the PWM signal (FPWM) should be significantly higher than the bandwidth (FBW) of the desired analogue signal. Equation 1 shows this relation.

$$\mathsf{FPWM} = \mathsf{K} \mathsf{FBW} \tag{1}$$

where harmonics decrease as K increases.

R and C are chosen based on the following equation:


$$RC = 1/(2\partial FBW)$$
(2)

Pick a value of C arbitrarily and then calculate R. The attenuation of the PWM frequency for a given RC filter is:

$$Att(dB) = -10 \cdot \log[1 + (2\partial FPWMRC)^2]$$
(3)

If the attenuation calculated in Equation 3 is not sufficient, then K must be increased in Equation 1. See application note AN538, 'Using PWM to Generate Analogue Output in PIC17C42', for more details on using PWM to generate an analogue output.

#### TIP 2: Boost power supply





#### Hardware

Pulse-Width Modulation (PWM) plays a key role in boost power supply design. **Figure 2** shows a typical boost circuit. The circuit works by Q1 grounding the inductor (L1) during the high phase of the PWM signal generated by CCP1. This causes an increasing current to flow through L1 while VCC is applied. During the low phase of the PWM signal, the energy stored in L1 flows through D1 to the storage capacitor (C2) and the load. VOUT is related to VIN by **Equation 4**.

**Note:** Technical Brief TB053 'Generating High Voltage Using the PIC16C781/782' provides details on boost power supply design.

The first parameter to determine is the duty cycle based upon the input and output voltages. See Equation 4.

$$\frac{\text{VOUT}}{\text{VIN}} = \frac{1}{1 - D}$$
(4)

Next, the value of the inductor is chosen based on the maximum current required by the load, the switching frequency and the duty cycle. A function for inductance, in terms of load current, is given by **Equation 5**, where T is the PWM period, D is the duty cycle and IOUT is the maximum load current.

$$L = \frac{VIN (1 - D) DT}{2 IOUT}$$
(5)

# **Tips 'n' Tricks**

The value for L is chosen arbitrarily to satisfy this equation given IOUT, a maximum duty cycle of 75% and a PWM frequency in the 10kHz to 100kHz range.

Using the value chosen for L, the ripple current is calculated using Equation 6.

$$IRIPPLE = \frac{VIN DT}{L}$$
(6)

IRIPPLE cannot exceed the saturation current for the inductor. If the value for L does produce a ripple current greater than ISAT, a bigger inductor is needed.

Note: All equations above assume a discontinuous current mode.

#### Firmware

The PWM duty cycle is varied by the microcontroller in order to maintain a stable output voltage over fluctuating load conditions. A firmware-implemented PID control loop is used to regulate the duty cycle. Feedback from the boost power supply circuit provides the input to the PID control.

**Note:** Aplication note AN258, 'Low Cost USB *Microcontroller Programmer'* provides details on firmwarebased PID control.

#### TIP 3: Uarying LED intensity




Figure 3 LED drive

The intensity of an LED can be varied by pulse width modulating the voltage across the LED. A microcontroller typically drives an LED with the circuit shown in **Figure 3**. The purpose of R1 is to limit the LED current so that the LED runs in its specified current and voltage range, typically around 1.4V at 20mA. Modulating the LED drive pin on the microcontroller will vary the average current seen by the LED and thus its intensity. LEDs and other light sources should be modulated at no less than 100Hz in

order to prevent noticeable flicker.

The CCP module, configured in PWM mode, is ideal for varying the intensity of an LED. By varying the duty cycle of the PWM signal driving the LED, adjustments to the intensity of the LED can be made. This is accomplished by varying the CCPRxL register between 0 and 0xFF.

#### TIP 4: Generating X–10 carrier frequency




Figure 4: 120kHz carrier frequency mounted onto sinusoidal 60Hz power waveform

X-10 uses a piggybacked 120kHz square wave (at 50% duty cycle) to transmit information over 60Hz power lines. The CCP module, running in PWM mode, can accurately create the 120kHz square wave, referred to as the carrier frequency. **Figure 4** shows how the 120kHz carrier frequency is piggybacked onto the sinusoidal 60Hz power waveform.

X-10 specifies the carrier frequency at 120kHz (±2kHz). The system oscillator in Figure 4 is chosen to be 7.680MHz, so that the CCP module can generate precisely 120kHz. X-10 requires that the carrier frequency be turned on and off at different points on the 60Hz power waveform. This is accomplished by configuring the TRIS register for the CCP1 pin as either an input (carrier frequency off) or an output (carrier frequency on). Refer to application note AN236, 'X-10 Home Automation Using the PIC16F877A' for more details on X-10 and for source code for setting up the CCP module appropriately.

#### See overleaf for the MicroChip competition

# Tips 'n' Tricks

# Win a Microchip PICDEM MC Development Board for Motor Control Design



Microchip's PICDEM MC Development Board makes it easy for engineers of all experience levels to cost-effectively add the efficiency and reliability of electronic motor control to their embedded designs. The new PICDEM MC supports creation of both AC induction motor (ACIM) and brushless DC (BLDC) advanced motor control applications with the PIC18FXX31 family of MCUs. These devices feature three advanced motion control modules, including a built-in quadrature encoder interface. The PICDEM MC board is also constructed with complete electrical isolation from the power circuitry, allowing users to plug in the MPLAB In-Circuit Emulator (ICE 2000) or MPLAB In-Circuit Debugger (ICD 2) for full programming, debugging and emulation while high power is connected to the board. In addition, the PICDEM MC board's isolated serial-port PC interface to the MC-GUI software enables users to modify their application parameters on the fly. The PICDEM MC combines the above features with included hex, assembler and C source files to provide a complete reference design for ACIM and BLDC motor control applications.

Supported by Microchip's Motor Control Design Centre (<u>www.microchip.com/motor</u>) and the free to download MCGUI, engineers will easily be able to add electronic control to their motor-driven products, reduce development time and costs.

For the chance to win one of these boards, log onto www.microchip-comp.com/elecworld-picdemmc and enter your details into the online entry form For those wanting something a little different from their mobile phone, check out the design-led Serene from Samsung and Bang & Olufsen. The display and microphone are placed in the lower shell, the circular keyboard and loudspeaker in the upper shell and a thumb-operated wheel in the middle, taking care of all primary operations.

It comes with a triangular charger/docking station and,

if the phone is placed in the docking station or used in a table mode, it can m double up as a mini-laptop as the display turns 180 degrees for convenient use. As a special feature for Bang & Olufsen customers, a DECT docking station is also available, which enables Serene to synchronise its phonebook with the domestic cordless system of telephones from the company. From £677

www.bang-olufsen.com

The five models that make up the Humminbird 300 series enhance fishermen's experience on the water, enabling them to find and remember favourite spots. Using a combination of sonar and GPS to accurately map depth and bottom contours, then marking the position so the angler can return to productive locations, the Humminbird 300 series adds flexibility and improved performance to the fishing experience.

Featuring Sarantel's GeoHelix-SMP GPS antenna, this latest range will benefit from the antenna's size and omni-directionality, offering exceptional performance to anglers. Available now **Around £125-215** 

www.humminbird.com



With popularity in VoIP (voice over IP) growing all the time, USRobotics has introduced a USB Internet phone – the USR809600. Integrating seamlessly with Skype's Internet telephony application, it plugs into a USB 1.1 or 2.0 port and it's ready to go. Similar to a mobile phone, it features an LCD screen offering call status and caller ID.

Designed primarily for the Skype application, the USR809600 can be used with any

ZyXEL's AG-225H Wi-Fi Finder offers a dual-band 802.11a/b/g USB 2.0 tri-mode client adaptor and soft access point for quick and simple on-the-road access detection and connection.

Being pocket-sized, you can scan the local environment to detect potential public access hotspots or open wireless networks to connect to. Features include a


high definition LCD screen, which gives users the SSID (Service Set Identifier), channel, security settings and signal strength of all the visible wireless networks in the local area. It provides a secure wireless connection when working as a 54Mbps high-speed USB wireless adapter and also features a built-in soft access point that can allow a laptop to instantly share wireless access with others. Available now. **Around £51 plus VAT** 

#### www.zyxel.co.uk

platform with voice capabilities. Other features include echo cancellation and noise reduction, offering call quality on a par with traditional phone calling. Available now from Insight, Inmac, Misco, PC World Business, Watford Electronics, Dabs.com, Broad Band Buyer. Ebuyer, Nickknows.com and WStore. Around £29.99

other instant message

## Improved Electrostatic Loudspeaker Power Supply for Quad ESL57 and Braun LE1



These are real old-timers but, when kept in good shape, still sound excellent: the famous Quad ESL, from the late 50s and its sister model called LE1, which is the German version manufactured by Braun under license of Quad. The main difference between the two: in contrast to the ESL the LE1 cabinet is a typical Bauhaus design by Braun's chief designer, Mr. Rams.

One of the few things that affects the ears is the fact that the loudspeaker's high direct voltage (a must for the function of electrostatic loudspeakers) is generated by the mains voltage and frequency via a transformer, followed by several rectifying voltage doublers. When listening to quiet music, sensitive ears can easily identify the rather disturbing 50Hz or 60Hz hum (or higher orders of these frequencies) through the loudspeaker panels.

Replacing the existing 230V/110V - 50/60Hz power supply by a voltage generator that produces the required alternating voltage with a much higher frequency can solve this special noise problem. This frequency should be located far outside the human listening bandwidth (approximately 50kHz). To avoid reinventing the wheel, a nearly perfect solution could be found.


Several light adaptations to H. Bonekamp's Ionisation Circuit, (printed in Elektor Electronics, March 1998, p. 46-49), as seen In Figure 1, make the original circuit fit for service in a different environment. A Meissner oscillator (T1, T2) and a centre tapped transformer (TR1) generate V(w2) = 530Vrms for the ESL or V(w2) = 574Vrms for the LE1, both at 50kHz, set by C5 and w1a+w1b. This new block replaces the mains transformer and, in the case of the ESL only, it's 330k/2.2M network between transformer and rectifying block.

This high alternating voltage feeds the existing rectifier and voltage doubler block to generate the high direct voltages for the treble and bass panels (1.5kV (ESL)/1.625kV (LE1) and 6.0kV (ESL)/6.5kV (LE1)). The high direct voltages can be measured with a 10M $\Omega$  input resistance voltmeter in series with a 990M $\Omega$ resistor network (see figure left). Meter reading will be 1/100 of the desired value. Extreme care should be taken when working with such high voltages!

The oscillator is powered by a voltage regulation circuit around VR1. Trimming of P1 sets the output voltage of the oscillator at w2: V(w2). After removing the mains transformers inside the cabinets of both types of loudspeaker, there is enough space to fix the circuit boards of the oscillator and its internal voltage regulation.

Two standard mains adaptors (one for each loudspeaker, e.g. Egston 12V/6W) feed the loudspeaker's new internal power supply with the required direct voltage (min 10V) and current (min 80mA). The existing mains input sockets have to be replaced by low voltage types (B1). D3 prevents the circuit from wrong input polarisation.

I've been testing the LE1 with a 2 x 30W valve amp (Braun CSV60, power valves: PL504) and a 2x30W transistor power amp (Douglas Self blameless type - Self on Audio, p. 223 - with output stages formed by a pair of multi emitter transistors -2SC2565Y / 2SA1095Y driven by BD139/BD140). Both amps did an excellent job, no hum could be heard at all, the overall sound was and still is excellent - but better than before. **Burkhard Vogel** Austria



Part of a research study being conducted into athletic performance required athletes to perform shuttle runs between the front and back walls of a squash court. An adjustable timing system was required, which could be altered by the researcher to provide a beep denoting the start time for each run. Since each of the athletes being tested was allocated a specific time interval between each shuttle run, the timer had to be variable between 2.5 seconds and 4.5 seconds. Being unable to find a suitable off-the-shelf product to achieve this, a PIC-based metronome system that was

# PIC-based metronome

variable in 0.1-second steps between 0.3 seconds and 9.9 seconds was developed.

As can be seen from Figure 1, user input to the PIC 16F84 is achieved using a pair of Binary Coded Decimal (BCD) switches. A Darlington driver IC was used to drive the buzzer and a tricolour LED used to indicate the 'Stopped' and 'Running' states. The master clear (\*MCLR) signal is pulled 'high' through diode D1 and resistor R12, to ensure proper power on reset. (1) Testing was initiated by depressing pushbutton switch SW1.

Software for the PIC is shown in **Code 1**. At power up, the buzzer is turned off

/\* Program for metronome

/\* Metron.cpp

and the tricolour LED's red segment is turned on to indicate the 'Stopped' state. When the user presses and releases the pushbutton switch (SW1), BCD switch data is read into Port B (2), and the tri-colour LED's green segment is illuminated to indicate the 'Running' state. The entered BCD value is converted to an integer (bcd value), representing the number of 100 millisecond delays required to realise the specified time delay between successive beeps.

At the end of each beep cycle, the PIC's output pin A2 is taken 'high', allowing the Darlington driver to sink current through the buzzer. Since the duration of a beep is 200 milliseconds, then 'bcd value' is reduced by 2. In the event of a user keying a value less than 3 (the minimum time delay possible). then 'bcd value' is made equal to 3. The metronome then continues to produce beeps at the predetermined time interval set up on the BCD switches. The test protocol required time intervals to be alterable 'on the fly' and push-button switch SW1 was also used for this purpose. Setting a new value on the BCD switches and holding down SW1 until the end of a beep cycle allows a new value to be read in. The red seament of the LED will illuminate when the new value is read in, and when the tester releases the switch, the LED will return to the green 'Running' state.

The BCD switches used in the prototype are available from Rapid Electronics, part number 78-0805. Frank Kelly UK

References http://ww1.microchip.com/downloads/en/DeviceDoc/30430c.pdf

Custom Computer Services, Inc, PCB, PCM, and PCW PIC Compiler Reference Manual. (1999)

```
/* them into a single variable (bcd_value) between 0 and 99.
 The bcd_value variable is then used to calculate the
/* number of times that a 100ms delay is executed.
/* Frank Kelly 23rd September 2005
                                                  .1
#include <16F84.H>
#byte PORTB = 6
#fuses HS,NOWDT,NOPROTECT
#use delay(clock=1000000)
#define ALL_IN 0xff
#define MIN_TIME 3
                          Control value for Port B
                         /* Minimum time value possible
#define BEEP_TIME 2
#define LO_MASK 15
                          /* Time duration of the buzzer
                            Mask value to read lower nibble */
#define HI MASK 240
                          /* Mask value to read upper nibble */
int upper;
                                      The upper BCD value
int lower;
                                    /* The lower BCD value
                                                                 .1
int bcd_value;
                      /* The packed BCD value
int count;
                   /* Number of delays required
/* Function to turn on the Red LED
void RED_LED()
  output_high(PIN_A0);
                        /* Turn on red segment,
                                                       .1
  output_low(PIN_A1);
                       /* ...and turn off green segment
/* Function to turn on the Green LED
void GREEN_LED()
         output_high(PIN_A1); /* Turn on green segment.
        output_low(PIN_A0);
                             /* ...and turn off red segment
 Read in the BCD switches as an 8 bit binary value and convert*/
1.
/* it to its corresponding integer value
void get_BCD()
        lower = PORTB;
                             /* Read port B into lower.
                                                           ij
  upper = PORTB;
                       /* ....and also into upper
```


/\* Program reads in 2 BCD digits from a BCD switch and packs

```
lower =(lower & LO_MASK); /* lower contains lower nibble */
                                    /* upper contains upper nibble */
     upper =(upper & HI_MASK);
     swap(upper); /* move upper into bottom 4 bits */
upper =(upper*10); /* multiply * 10 to represent tens' */
bcd_value =(lower + upper); /* ..then add lower */
if(bcd_value<MIN_TIME) /* If user inputs value less than 3 */
             bcd_value = MIN_TIME; /* ...make bcd value equal to 3
                                                                            */
     void switch_press()
     while(input(PIN_A3)) /* Wait for switch press
            delay_ms(5); /*
while(!input(PIN_A3))
                                 /* Delay for debouncing
      delay_ms(5);
  main()
    output_low(PIN_A2);
                             /* Ensure that buzzer is off
    set_tris_b(ALL_IN);
                           1
                             Make all port B inputs
    while(1)
     RED_LED();
                                                             +/
                            Turn on the red LED
     switch_press();
get_BCD();
                            Wait for the user to operate switch*/
                             then get the BCD value
      GREEN_LED()
                            /* Turn on the green LED
      while(input(PIN_A3)) /* While switch not pressed
               count = bcd_value;
output_high(PIN_A2);
                                        /* Turn buzzer on
               delay ms(200);
               output low(PIN
                                 A21
                                         /* Turn buzzer off
               count=(count-BEEP_TIME);/* Subtract buzzer time
               while(count)
                         delay_ms(100);/* Count down number of delays
required */
                   -count;
               1
      1
    )
                                                                            Code 1
```

# **Digital chronometer**

Here, I describe a low-cost digital circuit used to determine the time taken by a vehicle or any other moving object to cross two given points separated by a desired distance. The time found out can be used to determine the velocity of the vehicle or for any other purpose. Two laser torches, which are easily available, operate this device.


The block diagram of the unit shown in **Figure 1** depicts the overall arrangement of this system. Two laser torches are installed at the required points on one side of the path and their corresponding LDRs are placed on the other side of the path, such that the laser beams from the torches fall directly on the LDRs. This forms a



part of two different receiver circuits. The outputs of the receiver serve as two different sources of triggers to a bistable multivibrator (J-K flip-flop in toggle mode). The output of the bistable is given to an astable multivibrator such that it produces pulses spaced at 1ms only, while the output of bistable is high. These pulses of astable multivibrator given to a counter come seven-segment display driver are then counted and displayed on the seven-segment display.

#### Operation

The working of the circuit is as follows: Initially, when the laser



#### Fobruary 2006 ELECTRONICS WORLD

beams fall on the LDRs without interruption, this causes their resistances to move to low values, which compels the transistors of the receiving circuits to go into saturation, making the output of these circuits zero. However, when a vehicle interrupts the laser beam, the bias point of the circuit gets disturbed, forcing the transistor into cut-off mode, thus making the output of the circuit go high. The variable resistors R1 and R2 are used to calibrate the device for various intensities of surrounding light.

As per the above discussion, whenever a vehicle interrupts the first beam, a pulse is produced by first receiver circuit, which gets applied to the J-K flip-flop (74LS109) in the toggle mode as the first trigger causes it to go high. After crossing the first beam, the object interrupts the second beam and the trigger from the second receiver circuit causes the flip-flop to toggle and go low. Thus a vehicle passing through the two points in time T activates and deactivates the flip-flop. The

flip-flop produces a pulse of duration equal to the time taken (T) by the vehicle to cross the two given points, separated by a desired distance.

Since the output of the flipflop is connected to the reset pin of IC555 in astable mode, in this interval of time T, when the output of flip-flop is high, the 555 produces pulses spaced at 1ms. The counter (CD4033) counts these pulses and the counter is incremented every 1ms. The time T taken by the vehicle to cross the required distance is displayed

on the seven-segment display in milliseconds.

#### Application

The circuit can find many applications. For example, it can be used to determine the speed of a vehicle or to determine the time required by an athlete to complete a race. With only a few modifications, the same circuit can be used as a stopwatch too.

**Dhirender Singh** Hyderabad India

#### Send new circuit ideas to:

The Editor, Nexus Media Communications, Media House, Azalea Drive, Swanley, Kent BR8 8HU

or email to: ewcircuit@nexusmedia.com

#### PLEASE ENSURE YOU TELEPHONE TO CHECK AVAILABILITY OF EQUIPMENT BEFORE ORDERING OR CALLING.

#### SPECIAL OFFERS

#### OSCILLOSCOPES

TEKTRONIX 2247A 4 Channel 100MHz	
Counter/Timer/ Voltmeter TEKTRONIX 2335 Dual Trace 100MHz Delay Sweep	£275
TEKTRONIX 2335 Dual Trace 100MHz Delay Sweep	£125
TEKTRONIX 485 Dual Trace 350MHz Delay Sweep	
IWATSU 555711 4 Channel 100MHz Delay Sweep	
PHILIPS 3065 2+1 Channel 100MHz Dual TB/Delay - Autos	
PHILIPS 3055 2+1 Channel 60MHz Dual TB/Delay - Autose	£150
PHILIPS PM9217 Dual Trace 50MHz Delay Sweep	£125
PHILIPS PM9217 Dual Trace 50MHz Delay Sweep KIKUSUI COS6100 5 Trace 100MHz Delay	£150
TEKTRONIX 475A Dual Trace 250MHz Delay Sweep	£175
TEKTRONIX 475 Dual Trace 200MHz Delay Sweep	
TEKTRONIX 465B Dual Trace 100MHz Delay Sweep	£125
TEKTRONIX 465 Dual Trace 100MHz Delay Sweep	695
PHILIPS PM3209 Dual Trace 40MHz Delay	£125
PHILIPS PM3215 Dual Trace 50MHz	\$75
KENWOOD CS4035 Dual Trace 40MHz	. \$50
PANASONIC VP5564A Dual Trace 40MHz	
HITACHI V525 Dual Trace 50MHz Cusors	.£95
HITACHI V523 Dual Trace 50MHz Delay	.680
HITACHI V425 Dual Trace 40MHz Curson	\$75
HITACHI V422 Dual Trace 40MHz HITACHI V223 Dual Trace 20MHz Delay	960
HITACHI V223 Dual Trace 20MHz Delay	560
HITACHI V222 Dual Trace 20MHz	250
HITACHI V212 Dual Trace 20MHz	. \$50
HITACHI V212 Duai Trace 20MHz FARNELL DTV12-14 Duai Trace 12MHz	£40
STORAGE	
OHE IDE DUGSOD Dugs Trace SOONELLE SCONLUC	0000

STORAGE PHILIPS PM320 Dual Trace 200MHz 250Ms/S 1300 LECROY 9400 Dual Trace 125MHz 250Ms/S 2325 TEKTRONIX 466 Dual Trace 100MHz Delay Sweet Dipla Storand 2200 VELLEMAN HPS5 1MHz 5MHz Sampling Handheld U

;		ANALYSERS
1	£4500	ADVANTEST R3265A 100Hz-BGHz
- i	£2250	TEKTRONIX 492P 50kHz-21GHz
1.1	£3250	HP8560A 50Hz-2.9GHz Built In Tracking Gen
M	£2950	HP 8560A 50Hz-2.9GHz
M	\$950	HP 8569A 10MHz-22GHz
PH	£750	HP 8565A 10MHz-22GHz
20	£1100	HP 853A with 8559A 100kHz-21GHz
PA	£750	HP 182T with 8559A 100kHz-21GHz
FA		HP182T with 8558B 100kHz 1500MHz

#### of READING WANI 17A King Street, Mortimer, Near Reading RG7 3RS Telephone: (0118) 933 1111. Fax: (0118) 933 2375 www.stewart-of-reading.co.uk VISA

P 8754A N

Open 9am-5.00pm Monday to Friday (other times by arrangement)

.£300-£400 £500 £950 HP 182T with 8557A 10kHz-350MHz HP 140T with 8555A 10MHz-18GHz HP 140T with 8555A 10MHz-18GHz ADVANTEST TR4131 10KHz-0 5GHz WAYNE KERR SSA1000A 150kHz 2950 NI 2382 200Hz-400MHz High Re MARCONI 2370 30Hz 110MHz \$500 ork Analyser 4-1300MHz £500 MARCONI 5500A Amplitude Analyser with hisad HP 334A Distortion Analyser 5Hz-600kHz 12100 SIGNAL GENERATORS HP 8350B Sweeper with 82592B 10MHz/20GHz HP 8350B Xeweper with 82592A 10MHz/20GHz HP 8350B Main Frame Only HP 83592B FP Hugh for 8350 0.01-8 4GHz HP 83592B FP Hugh for 8350 0.20GHz HP 8660C 36 Gen 2 6GHz HP 8660C 36 Marking Sectors for 8680C HP86633B Modulaton Sectors for 8680C HP86632B Modulaton Sectors for 8680C HP866532B Modulaton Sectors for 8680C HP866542CH Sig Gen 2 9560MHz HP 8566 Synthesized 0.1-990MHz HP 85668 Synthesized 0.1-990MHz £1500 £1250 £125 £500 0083 £450 £750 £500 £325 £300 £200 HP 86565 Synthesised 0.1-990MHz HP 86565 Synthesised 0.1-990MHz HP 8640A AM/FM 500KHz-512MHz HP 8620C Sweep Osc with 86290B 2-18.6GHz HP8520C Sweep Osc with 86222B 0.01-2.4GHz £400 £15 £500 #820C Sweep Osc with 862228 0.01-2.4GHz
 8620C184 with any of the lotowing plug-ind
 #8202A Plug in 15-4GHz
 #9 6220A Plug in 15-4GHz
 #9 6220A Plug in 17-4.3GHz
 #9 6203A Plug in 17-4.3GHz
 #9 6203A Plug in 3-8-8 6GHz
 #9 6203A Plug in 5-9-12.4GHz
 #9 6203A Plug in 5-9-12.4GHz
 #9 6250A Plug in 5-9-12.4GHz
 #9 6250A Plug in 5-12.4GHz
 #9 6250A Plug in 12.4.1GHz
 #9 6250A Plug
 #9 6250 £150-£200 HP 86220A Plug in £95 .6225 MHz Freq Counter IEEE IASONIC VP8117A AM/FM 100kHz-110MHz 0-100kHz Digital Display etc. Unused

\$225

#### Programmable Signal Source Hz (Pulsel Function) HP 8165A Programmable Signal Source 1MHz-50MHz (Puise) Function) HP 3325A Synthesised Function Gen 21MHz HP 3312A Function Gen 0.1Hz-13MHz AMFM £325 £350 \$200 £225 £275 WAVETEK 23 Synthesised Function Gen 12MHz EXACT 529 AM/FM Function Gen 20MHz EXACT 529 AM/FM Function Gen 20MHz ANALOGUE 2030 Synthesized Mull Function Wawform THANDER TGS03 Public Mull Function Wawform THANDER TGS03 Public Mull Function Gen SMHz KRON-HITE 5200A Sweep Func Gen 0.00003Hz-3MHz HP 3310A Function Gen 0.01Hz SMHz Mull SP MISL32 Function Gen 0.1Hz/3MHz PHILIPS PMS132 Function Gen 0.1Hz/3MHz FEEDBACK FG801 Func Gen 0.01Hz/3MHz HP 8112A Public Gen S0MHz HP 8112A Public Gen S0MHz HP 8112A Public Gen S0MHz £150 \$250 £195 £150 £120 £80 £95 £75 £60 £750 HP BITLA Puise Geen Solvitz \$2750 HP BITLA Puise Generator 20Witz \$2400 LYONS FG73N Puise Generator 20Witz \$250 LEADER LACTOBS InsetS Audio Generativi 10Hs 1MHz \$250 EARINELL LFMM SnetSq. Osc. 10Hz 1MHz \$250 FARNELL LFM SnetSq. Osc. 10Hz 1MHz \$250 GOULD JB SneSq. Osc. 10Hz 1MHz \$250 MARCON SANDERS 6055 Strait Source 830-2000MHz \$125 MARCON SANDERS 6055 Strait Source 830-501Mz \$125 MARCON SANDERS 6056 Strait Source 840-501Mz \$125 MARCON SANDERS 60565 Strait Source 840-501Mz \$125 MARCON SANDERS 60578 Strait Source 84-65 Stolfur \$125 MARCON SANDERS 60578 Strait Source 84-65 Stolfur \$125 MARCON SANDERS 60578 Strait Source 84-65 Stolfur \$125 MARCON SANDERS 60578 Strait Source 84-66 \$125 FULKE 6011A Spritwised 11MHz \$126 PHUPS STAN Colour Bar Generator Yoboo \$156 ELACK STAR ORION Colour Bar Gene \$150 ELACK STAR ORION Later Version Metal Case \$175 £400 FREQUENCY COUNTERS/TIMERS

EIP 371 Source Looking Microwave Counter 10Hz-18GHz £325
EIP 331 Autohet Microwave Counter 825MHz-18GHz £195
HP 5386A Counter 10Hz-3GHz £350
FEEDBACK SC230 Counter 1 3GHz
RACAL 9916 Counter 10Hz-520MHz £75
RACAL 9906 Universal Counter 200MHz
RACAL 9904 Counter Timer 50MHz 550
RACAL 1991 Counter/Timer 160MHz 9 digit £195
MARCONI 2431A Frequency Meter 200MHz
MARCONI 2437 Counter/Timer 100MHz
HP 5340A Automet Microwske Counter 10Hz-18GHz £250

HP 5316A Universal Counter 0-100MHz HPIB	
THANDAR TF810 Frequency Counter 5Hz-200MHz Battery	1632
THANDAR TF200 Frequency Meter 10Hz-200MHz 8 digit	. £40
BLACK STAR Meleor 100 Counter 5Hz-100MHz	E50
BLACK STAR 1325 Counter Timer 1300MHz	£150
BECKMAN UC10A Universal Counter 120MHz	160
LEADER LDC9043 Digital Counter 100MHz	£125

#### DIGITAL MULTIMETERS ETC

SOLARTRON 7150 6% digit True FIMS IEEE	\$75
SOLARTRON 7150Plus As Above + Temp Measurement	£100
DATRON 1065 51/2 digit Autocal AC/DC Resistance IEEE	295
FLUKE 77 3% digit Handheld	£35
FLUKE 77 Series 2 3½ dioil Handheld	£45
FLUKE 8060A 41/2 digit True RMS Handheid	£75
BECKMAN HD110 31/2 digit Handheld in Carry Case	£30
TTI 1905A 51/e digit Bench.	660
SOLARTRON 7045 41/2 digit Bench	£30
AVO DA116 31/2 digit with Batteries & Leads	E20
AVO 8 Mk6 in Ever Ready Case with Leads etc.	\$75
AVO 8 Mk5 with Leads etc	E50
RACAL 9301A True RMS RF Millivolmeter	£125
RACAL 9300 True RMS Millivoltmeter 5Hz-20MHz	
usable to 60MHz	£30
RACAL 9300B as 9300.	E45
GOODWILL GVT427 Dual Chan AC Millivollmeter 10mV in	
12 ranges 10Hz-1MHz Unused .	£75
KENWOOD VT176 Dual Chan Milwolimeter	. £40

#### POWER SUPPLIES

ARNELL XA35.2T 0-35V 0-2A Twice Dioital	. 295
ARNELL LT30-2 D-30V D-2A Twice	\$110
ARNELL B30/20 30V 20A Variable No Meters	£110
ARNELL B30/10 30V 10A Variable No Melers	
ARNELL LT30-1 0-30V 0-1A Twice	\$75
ARNELL L30.2 0-30V 0-2A	£55
ARNELL L30.1 0-30V 0-1A	£40
ARNELL E350 0-350V 0-200mA	£125
ARNELL D30-2T 0-30V 0-2A Twice Digital	- 695
HURLBY PL330 0-32V 0-3A Digital (Kenwood bad	ged)£75
HURLBY TS3021S 0-30V 0-2A LCD	£65
HURLBY PL320 0-30V 0-2A Digital	255
AKASAGO GM035-3 0-35V 0-3A 2 Melers	\$45
AKASAGO TM035-2 8-35V 8-2A 2 Meters	. £35
SOLATING TRANSFORMER Yellow - 500VA with	
	0012

Used Equipment - GUARANTEED. Manuals supplied This is a VERY SMALL SAMPLE OF STOCK. SAE or Telephone for lists. Please check availability before ordering. CARRIAGE all units £16. VAT to be added to Total of Goods and Carriage

#### User Interface Design and Evaluation

Debbie Stone, Caroline Jarrett, Mark Woodroffe and Shailey Minocha

Newnes (Elsevier)



The blurb states that "Whether you are a professional new to the user-cantered design field, or an experienced designer who needs to learn the funda-

mentals of user interface design and evaluation, this book can lead the way". The preface states, "After studying this book, you will be able to develop an UI in a flexible, iterative manner, working in close collaboration with the users."

When this book dropped with a promising thud on to my doormat, the blurbs promised much. Sadly, I was very disappointed. Why?

First, there was the promise of a "supporting website". Good, I thought, let's go online and I can refer to it throughout. Sadly, the URL is not in the book.

I did a search for the publisher's URL, but had to go through five more links before I found, not a "supporting website" but a "companion website". I found that the documents available are intended only for lecturers and students taking the Open University course (in the UK); hardly a promising start.

A plus is the 'flick through' page numbering. A minus is that those colours are not repeated in the Contents for colourcoded access when flicking through. Another minus is the placing of the page numbers, which results in each left page having one wide margin. Thus, the small right margin rolls the text into the spine, which does not make it very readable.

I am sure that if the over-the-top margins were reduced it would be much lighter and easier to handle. Severe pruning would also help there, as well as clarify the ideas.

Generally, I found the book plodding and without any relieving sparks of humour. Maybe, the general problem is with having multiple authors. The plodding nature of the book is made worse by their habit of giving introductory sections in every Part and Chapter, with "what we have learnt" summaries at the end of even the shortest section. There are also many distracting little boxes alongside the text to tell you "You will learn more about X in Chapter Y".

Overall, I consider the content to be glib and facile. Glib, as it revels in jargon words, facile as it uses them unnecessarily and even badly. One basic example is the use of the word "affordance". They use it unqualified, but Norman (1988) states that it should always be qualified with either "perceived" or "real".

Another example is the Exercise 2.2. It uses a photo that is so badly out of focus that the question to be answered is meaningless.

The "Discussion" is equally meaningless as no explanation is given as to why the users acted in the way the authors state.

I also feel that the Preface and blurbs should be rewritten to make it clear that the book is not really intended for reference, but just to accompany the Open University course.

Once I understood in which direction the authors were heading, I browsed for highlights. I immediately found two glaring omissions regarding input/output UIs. A very brief mention is made that there is a subject called ergonomics, but nothing to make the reader appreciate how important it is. There is no discussion of the ergonomics of UIs anywhere in the book and there's no mention of kinesthetics either. Thus, very important design criteria are effectively ignored. (See the US Department of Labour check list for example.)

Likewise, although analysis of UI evaluations is of the utmost importance, even in the so-called case studies, the use and importance of statistical discipline in assessing evaluations is minimised.

In the section on input devices, most emphasis is placed on input to computers. The expected sketches of mobile phones and games consoles are there, but the extremely poor design of most, where the user is encouraged, or even forced, to use the thumb(s), is not even mentioned. Ignoring ergonomics again. Throughout, I got a definite feeling of academics writing for academics to teach students to be academics. Three of the authors are academics and the fourth runs courses and tutors for the Open University.

**Book Review** 

Finally – the case studies. They should have given readers a clear insight into the necessary procedures and the end results, but are so cursory as to make very little contribution. In the only two real cases presented, the authors were not part of the teams working on the separate studies and implementations. The text is simply interviews with some of the participants giving an inadequate summary of the work done.

In all four, they aren't any case studies ("a careful study/a detailed analysis").

Tokairo – the authors do not even give the reason as to why the redesign was considered to be necessary. Photos show the final design – the 'kiosk' – in place, but the authors do not comment on the unfortunate placing that shows how very awkward it must be for a right handed user to input data.

Fast – the early background at LATCC was firmly based on work study and engineering. This is not considered.

So, to an Electronics World reader I recommend to buy a good book on work study, with side helpings of job evaluation and website design. If you buy this book you will find a few useful nuggets of information, but as the engineering input is so sparse, you won't find many facts or data.

#### Anthony C Batchelor

If you want to buy a copy of any of the books features in Electronics World, you will receive a 15% discount and P&P free, by writing to us at the usual address or emailing us at EWadmin@nexusmedia.com

## Letters

**Move if you want to earn more** Your editorial (November issue, entitled '*Learning through light exercise*') throws light on the state of engineering.

You write: "Engineering is still not as well paid as some other professions and certainly it does not command as high a status in society". How little things have changed in 25 years. In 1980 I had the chance to move to continental Europe and set out to better my career chances. It was the best move I could have made. I can easily imagine my position now if I had remained: a £30,000 job in a small department, a terraced house, a large mortgage, a secondhand car and worries for the future.

Many times I have been asked why I enjoy my position in comparison to UKbased engineers and I, basically, illustrate it with a summary of the attitude in the UK to engineering and engineers: "Doctor? Ah, do come in. Let me take your coat. Judge, welcome, please make yourself comfortable. Engineer? Your entrance is down the side here, take off your boots and wash your hands first!?"

This attitude is, of course, to be expected, since in the UK, factory workers and other labourers who tighten wheelnuts on car production lines are also called "engineers" and are best known for taking "industrial (in)action".

Until this situation changes and engineers are recognised as the professional group they are, fewer students will opt for engineering courses and of those who succeed many will leave the UK to earn the respect they deserve – just as I did a quarter of a century ago.

F.C. Trevor Gale Netherlands



#### Mind the LHB that gives electric shocks

A month ago, I installed a (non-Sky) satellite system. Everything was going fine until I was fixing the dish to the wall of my garden. I was fixing the 'F' coupling to the LHB when I started getting electric shocks; not enough to cause damage but enough to make me sore. Using a Fluke 77, I measured an 82V ac. This made me check the masthead amplifier on the new wideband DTT aerial. It measured 79V ac, but as I was on the roof of my house and not on the ground I did not get an electric shock. Both units have the CE stamp.

In the 1950s, the regulations required that radios fed from a mains dropper resistor had to have no metal showing, plastic knobs had to cover the steel shafts, and aerial and earth sockets were fed via a small value capacitor.

Fifty years later we seem to be going backwards. I realise that SMPS have superseded transformer analogue supplies due to new design engineering, small transformers over heat and cause unit failures.

I would like to hear any thoughts on this subject. **D. Lucas** *UK* 

#### Problem solving challenge

want to be able to watch the weather forecasts on board my small trail-sail yacht using the 12V supply. I was told (Maplin) this combination would work through the aerial feeds, but it doesn't. When I phoned Digifusion they said it needed a Scart socket connection, but they didn't sound that convincing. The call engineer did suggest it might work through a VCR with the last connection via the aerial lead only, but space and power are very limited. However, Maplin said it should work using a Scart lead with two AV plugs that



would plug into the AV lead supplied with the TV.

I tried using a Scart lead from the digital box that had the red, yellow and white video and audio plugs leading from it. I plugged this into the TV using the AV lead supplied with matching sockets, but did not have any success.

Not wishing to thrash around in the dark or to damage the equipment, can you throw any light on the matter?

I am trying to receive digital Freeview on a Saka 5" TFT LCD colour, portable, television (12V), in conjunction with a Digifusion box which has the following:

S	aka TV
	Socket for external aerial
	AV in
	AV out
	No Scart
	C. SYS. Auto, PAL, P3.58, N3.58, N4.43, SECAM, SECAM-L, PALM, PALN
	S.SYS. M, BG, I, DK
T	he Freeview box is a Digifusion FRT 101 (12V)
	RFin
	RFout

AV Scart to VCR AV Scart to TV

If this setup is not possible, are there either past or present boxes that will work without a Scart socket on the TV? Or could I just use the relevant circuit from an old VCR? Ian Anderson UK


If you need help with a technical or practical problem please write to us at: **EWletters@nexusmedia.com**. The query will be published and answered by Electronics World readers.

# PicoScope 3000 Series PC Oscilloscopes

The PicoScope 3000 series oscilloscopes are the latest offerings from the market leader in PC oscilloscopes combining high bandwidths with large record memories. Using the latest advances in low power electronics, the oscilloscopes draw their power from the USB port of any modern PC, eliminating the need for mains power.

- High performance: 10GS/s sampling rate & 200MHz bandwidth
- 1MB buffer memory
- Advanced display & trigger modes
- Compact & portable
- Supplied with PicoScope (oscilloscope/spectrum analyser) & PicoLog (data acquisition) software.

## Tel: 01480 396395 www.picotech.com/scope326



50MH

2 Est trigg

Sns/div to 5

Süperin

PERK

0 to 25M

leoScope andwidth ampling rate (repatitive) ampling rate (langle shot) hannels Iscilloscope timebakes mebake accuracy pectrum ranges lectrit length lesolution accuracy anges C Connection/Power supply

c 2+Ext trigg s/div 2ns/div to 5 SOppim 0 to 50MHz 512K 8 bits, 10mV to

100MH

5GS/%

10mV to 2V/div



Pico

coscope

200MH

10GS/#

SDoor

1MB

2 Ext that

D to 100MH

Ins/div to 50s

## Forest Electronics – PIC and AVR C Compiler Products

#### FED's ANSI C Compiler for PIC or AVR processors

- Fully integrated editor with syntax highlighting, multiple pages etc.
  Full project support include and manage multiple source files, simulator, assembler files and notes/comments within one project
- Fully integrated simulator and waveform analyser step from C line to C line, or examine code in assembler form. View device pins using a logic analyser application.
- Simulator supports LCD modules, keypad, buttons, LED's, displays, analogue inputs, serial and asynchronous data and more.
- · Designed to ANSI C standards
- PIC Supports 18xxx, 16xxx, 12xxx series 14 and 16 bit core processors
- · AVR Supports standard and MEGA core processors
- Generates MPLAB/AVR Studio projects and source files and completely standard hex output files.

#### WIZ-C / AVIDICY Drag and Drop rapid application development using ANSI C for PIC and AVR

- Rapid Application Development for the PIC or AVR microcontroller using the C language (WIZ- C for the PIC, AVIDICY for the AVR)
- Drag and drop your software component selections on to your design
- Included components support timers, serial interfaces, I2C, LCD, 7 Seg displays, keypads, switches, port controls, many bus interfaces including IIC and Dallas iButton, AVR/PIC Hardware, and more.
- Connect software components to MCU pins by point & click
- Parameters set from drop down list boxes, check boxes, or text entry
- Links your code automatically into library events (e.g. Button Pressed, Byte Received etc.)



#### Forest Electronic Developments

01590-681511 (Voice/Fax)



- Automatically generates your base application including full initialisation, interrupt handling and main program loop
- The complete C Compiler and AVR Simulator programs are integrated into AVIDICY - total editing / compilation / assembly / simulation support in one program
- Also includes the Element Editor to enable you to create your own components with ease.
- · Demonstration available from our web site


#### Prices from £45.00 - details & demo from www.fored.co.uk

email : info@fored.co.uk



## www.fored.co.uk

#### Also programmers, ICE, & development systems



RoHS compliant shielding is more economical

Nickel Silver is fast becoming the preferred alloy for the majority of board level shielding tasks according to Precision Micro, the Birmingham-based precision metal components manufacturer. The material is said to be replacing traditional plated steel and yellow metals across the board and certainly for those applications above 15MHz, where shielding effectiveness becomes more of a skin (conductivity) effect than a bulk effect.

Nickel Silver is less conductive than copper and brass but far stronger. It is an alloy of copper, zinc and nickel, the 'silver' terminology being descriptive of its appearance rather than its constituents. Nickel Silver is far more corrosion resistant than either steel copper or brass and exhibits excellent solderability characteristics for ease of assembly.

Although this RoHS compliant material is marginally more expensive, it doesn't need plating to improve its solderability or corrosion resistance, so invariably finished shielding cans manufactured in Nickel Silver are less expensive. There is also a time saving, generated by removing a complete process stage, which can be important when 'time to market' is critical. www.precisionmicro.com

## **Development tool for a variety of 8051 MCUs**

Keil recently announced the availability of its new µVision3 development environment and C51 version 8 optimising compiler for classic and extended 8051 microcontroller (MCU) development. The firms says that together these products provide developers with a feature-rich, integrated development environment, optimised for a wide range of 8051 MCU variants released in the past nine months, including the Analog Devices ADuC83x and ADuC84x and the Infineon XC866.

The µVision3 development environment features source code outlining, function navigator, template editing and incremental search. It also incorporates a configuration wizard, which speeds the generation of start-up code and configuration files. The built-in microcontroller simulator can model supported MCU devices, including the instruction set, on-chip peripherals and external signals used to stimulate it. Application behaviour can be captured using the µVision3 logic analyser, showing the changing state of MCU pins and peripherals alongside program variables.

Customers with valid software maintenance agreements can download the Keil C51 version 8 compiler and  $\mu$ Vision3 update from the Keil web site.

## **CompactPCI power supply**

TECRNOLOGIE

C&D Technologies has expanded its family of CompactPCI power supplies with a 3U x 8HP 325W module that combines fully featured IPMI (Intelligent Platform Management Interface) functionality with the ability to operate at significantly lower airflows.

The new CPCI325D-1 delivers full power across its operating temperature range of 0°C to +50°C with as little as 200Ifm of airflow. Built-in IPMI functionality includes the basic FRU reporting capabilities offered by other CompactPCI modules plus enhanced functionality for reporting output current, output voltage and temperature. An output inhibit function is also provided as standard.

The CPCI325D-1 is designed for compliance with the PICMG 2.11 D1.0 CompactPCI Power Interface Specification. Features such as multiphase conversion, synchronous rectification and output ORing FETs have been used to achieve high efficiency and the lowest airflow requirements of any CompactPCI power supply on the market.

Operating from a wide 36-72VDC input voltage range, this 325W supply supports hotswap, N+1 redundant operation for globally deployed, highavailability (HA) applications.

As a result, the module is ideally suited to the broad range of CompactPCI applications in telecommunications, networking, industrial computing, test and measurement and industrial equipment. www.cd4power.com

## High quality over-moulding in small batch sizes

Quadrant, the Hertfordshirebased component distributor and cable assembly manufacturer, has made a major addition to its cable assembly capability by offering custom overmoulding of cable assemblies using 'D' type sub-miniature and other connectors.

By combining high quality connectors and high performance moulding materials with an extremely flexible manufacturing method, Quadrant can provide a high performance, cost-effective moulded



assembly in batch sizes as small as 100 pieces.

The over-moulding process consists of three stages. The first is a low pressure moulding that encapsulates the terminations, this is followed by an optional EMC foil screen that provides a high degree of EMC shielding and, finally, a high pressure over-moulding, using a thermoplastic elastomer compound (TPE).

Standard connector types supplied are 'D' type sub-miniature in 9, 15 and 25 way shell sizes and RJ 45 8-way screened and unscreened connectors. Other connector types, PCBs and electronic components can be supplied on request as can waterproof connector assemblies meeting IP67.

#### BROADCAST MAINTENANCE TECHNICIAN / LOAN RESOURCE ASSISTANT

£17,000 p.a. Full-time 3 year fixed term contract. Based: Chislehurst, Kent - 25 mins by train from Charing X

This is a new post whose role is to assist the Broadcast Maintenance Engineers and the Stores Supervisor to provide a comprehensive service to staff and students across the Broadcasting Department and the College.

The role is to carry out Electronic and Sytems fault diagnosis, to work on complex faults, and undertake repairs/maintenance of equipment. The successful candidate will have knowledge of Broadcasting engineering techniques and equipment, and a degree or HND in Electronics.

Closing date: 31 January 2006

Further details Skelly.matthews@rave.ac.uk

We welcome applications from suitably qualified people from all sections of the community in our desire to reflect the diversity of the community we serve.

We have a smoking policy: smoking is only permitted in designated areas.



# A QUANTUM LEAP IN EMBEDDED CONTROLLERS Ouick FIRE SUPERCONTROLLERS

#### **Our range provides:-**

• The fastest 68000 based Core up to 66 Mhz.

 Extensive I/O:- Serial, IrDA, SPI, I<sup>2</sup>C, Analogue, Timers/Counters, RTC, etc.

 Large Memory Capacity:-Flash, SRAM, DRAM.

Supports:-Mono & Colour LCD's, Touch Panels & Keypads, Very Low Power.

#### ALSO LOW COST

#### DEVELOPMENT

Target easily & quickly.

ul ANSI 'C' compiler, assembler

Source Level Debug.

Full Driver Support with Libraries.

Real Time Multitasking OS with a free run time licence.

Free Unlimited email support.



CAMBRIDGE MICROPROCESSOR SYSTEMS LTD

Unit 17-18 Zone 'D' Chelmsford Rd. Ind. Est. Great Dunmow, Essex CM6 1XG Telephone: 01371 875644 email: sales@cms.uk.com

# www.electronicsworld.co.uk

# To reserve your web site space phone Reuben Gurunlian 01322 611261 reuben.gurunlian@nexusmedia.com

#### CHYGWYN

#### www.chygwyn.com

Thy	Gwyn tommerson
-	and the second
200	International States of Concession, States of
-	Transmiss
-	and a set of the set o
10	
8	CALL AND COMPANY AND COMPANY
-	
5	

ChyGwyn Limited offers electronic design and embedded software development for remote monitoring, embedded appliances, set-top boxes and similar devices. We are experts in customisation of Linux and write device drivers for custom hardware.

#### COMPONENT TECKNOLOGY

#### www.component-tecknology.co.uk



- PIC microcontroller kits and modules for students and hobbyist.
- 18F45X,16F87X Proto-Boards for ease and fast development of project ideas.
- Infrared Illuminators for CCTVs in low ambient light security areas.
- Analogue 8-channel high voltage isolator. Data logging.
- 5% discount code 'elwwdir2004' for Electronics World readers.
- Consultancy
- TIG control systems REIS interface.
- Real-time X-ray Imaging.

#### CONFORD ELECTRONICS www.confordelec.co.uk



Lightweight portable battery/mains audio units offering the highest technical performance. Microphone, Phantom Power and Headphone Amplifiers. Balanced/unbalanced signal lines with extensive RFI protection.

#### **DB TECHNOLOGY**

#### www.dbtechnology.co.uk/



Anechoic chamber and open area test site.

- Compliance Tests
- Fixes included. FCC Listed.
- Flexible hourly booking available.
- Rapid, accurate pre-compliance tests.

#### DESIGNER SYSTEMS CO www.designersystems.co.uk



Electronic product design company with over a decade of experience promoting it's own product range and designing and manufacturing innovative products for client companies/individuals.

#### IPEVA

#### www.ipeva.com



IPEVA sell FPGA platforms and provide Design Services for Embedded Systems, OpenCores IP, Analogue, Digital, FPGA, ASIC, HDL Translations (e.g. Schematics/C/C++ to VHDL) and Migrations. Altium Nexar and Protel Bureaux. Tel 0870 080 2340

#### MCES LTD

#### Web: www.mces.co.uk



MCES are a specialist electronics company providing a high quality repair, rework and re-manufacturing service to electronic modules and sub assemblies, including handling both large and small volume production and rework for major manufacturers. Established in 1972 we have continued to make large investments in specialised test equipment, surface mount technology and tooling enabling us to diagnose repair and verify a wide range of electronic modules to a very high standard. We also operate a fitting service for surface mount multi pin IC's and BGA's

#### **REDRAT LTD**

#### www.redrat.co.uk

02	These ( miner Services ) Products ( ) (alternate / Support ) Top ( ) Miner
A famore	infrared remote control for your computer
1.00	1
	0-
	Name and Address of the Party Party of the

Infrared remote control input and output for computers – USB and TCP/IP.

Applications areas include:

- Home automation
- PC based multimedia installations
- Consumer electronics test systems
- Broadcast monitoring
- Show and theatre control

#### TEST EQUIPMENT SOLUTIONS www.testequipmenthq.com



Specialising in quality second user Test Equipment sales and rental, all equipment is fully refurbished and tested. We supply manuals and accessories with full certification and a 12 month warranty. Savings greater than 70% can be realised over new prices.

Lineage only will cost £150 + vat for a full year. Lineage with colour screen shot will cost £350 + vat for a full year

111





24 HOUR DELIVERY SERVICE

OLSON ELECTRONICS LIMITED OLSON HOUSE, 490 HONEYPOT LANE, STANMORE, MIDDX HA7 1JX TEL: 020 8905 7273 FAX: 020 8952 1232 e-mail: sales@olson.co.uk web site: http://www.olson.co.uk

CALL OUR SALES HOTLINE



# SPECIAL OFFER - 6 for the price of 5

# ELECTRONICS WORLD CD-ROM 1999 – 2004 £30 each inc p&p (UK only) Add £1 postage for Europe or £5 rest of the world

• easy to use • easy to browse • full text and diagrams of all articles, circuit ideas, letters etc •

Please send the follo CD-ROMs:	wing
<b>1999</b>	Charge my: Visa Mastercard Amex Switch Delta Issue No. (Switch/Delta)
2000	Expiry date:
2001	Name:
2002	Company name:
<b>2003</b>	Address:
<b>2004</b>	Postcode:
CDs @ £30 each = £ add postage £	
Total £	Email:

Post to: Katie Butler, Electronics World, Nexus Media Communications, Media House, Swanley, Kent BR8 8BR

# **ELECTRONICS** WORLD

If you are interested in staying at the cutting-edge of electronic design then Electronics World is the magazine for you. Sign up and be inspired every month. A subscription guarantees your magazine arrives every month promptly and without fail.

# Subscribe nov

1.		2. Your profession:	3. Your interest	4. Your industry	G industrial
A Professional engineer B Serious hobbytist	A Professional engineer	A Management	A Analogue	A Aerospace	H Manufacturing
	B Serious hobbyist	B Design	8 Digital	B Automotive	Medical
		C Purchasing/specifying	C Software	C Broadcast	J Military
		D Service/maintenance	D Project management	D Computing	K Power
		E Research	E EMC	E Communications	L Semiconductors
	F Education	F RF/microwave	F Consumer electronics	M T&M	

If you prefer not to receive promotional mailing from other companies please tick box All subscriptions run for their full term no credit will be given for cancellations during this period

#### Tel Fax Email PLEASE NOTE THAT BY GIVING YOUR EMAIL YOU ARE GIVING US PERMISSION TO CONTACT YOU WITH IT **PAYMENT CHOICE:** I enclose a cheque made payable to Electronics World Please invoice my company Please debit my card Visa Mastercard Amex Switch Solo L Semiconductors Card No

Expiry date

Yes I would like to subscribe to Electronics World magazine for:

One year £45 UK, £76 in Europe (€120) and Worldwide (US\$145)

Two years £80 UK, £140 in Europe (€215) and Worldwide (US\$260) saving 10% Three years £105 UK, £185 Europe (€285) and Worldwide (US\$345) saving 20%

Postcode

Issue No (Switch/Solo only)

Signature

Name

Job Title

Company

Address

Date

Debbie Jenner, Freepost SEA 11436, Electronics World, Media House, Swanley, Kent BR8 8BR (no stamp required) UK only International address: Debbie Jenner, Electronics World, Nexus Media Communications, Media House, Swanley, Kent BR8 8HU United Kingdom

Ref:404

# **Service Link**

## ARTICLES WANTED

#### TOP PRICES PAID

For all your valves, tubes, semi conductors and ICs.

Langrex Supplies Limited 1 Mayo Road, Croydon, Surrey CR0 2QP TEL: 020 8684 1166 FAX: 020 8684 3056

#### FOR SALE

#### PRINTED CIRCUIT BOARDS

- DESIGNED & MANUFACTURED Prototype or production quanhiles Fast tumround available PCBs designed from circuit diagrams Almost all computer files accepted PCB assembly mechanical assembly Full product design-manufacture-test-tepair Unit 5, East Bellast Enterprise Park 200 Altertarized and Definal Dar 402 308 Albertbridge Rd, Belfast BT5 4GX TEL 028 9073 8897 FAX 028 9073 1802

## SERVICES

#### POWER SUPPLY DESIGN Switched Mode PSU

Power Factor Correction designed to your specification Tel/Fax: 01243 842520 e-mail: eugen\_kus@cix.co.uk Lomond Electronic Services

Link Servi

For a FREE consultation on how best to market your products/services to a professional audience ring Reuben on 01322 611261





1

cope 4 5000 Samples Time out 100 50 MHz @ 12 bits (Ch1)

Handy 14013

HS4 (14014) Ch1 Ch2 Ch2 Ch3 Ch3

# 512 CHANNELS IS THE LIMIT COMPLETE PACKAGE STARTING AT £ 440

The Handyscope HS4 (50MHs 12/14/16 bit) is a powerful and versatile four channel measuring instrument with extension

8.0000

6.0000

4.0000

2 0000

2.0000 V

1.5000

1.0000

0.5000

-0.500

0.0000 🕫 0.0000

The Handyscope HS4 starts a new standard for multi channel measuring.

It offers perfect measure qualities and through the USB connection it is easy to connect to every PC. Because of the very versatile software it becomes simple to extend the instrument to 512 channels.

A four channel, 12-16 bit oscilloscope, spectrum analyzer, transient recorder and voltmeter created as a most compact instrument.

- Making virtual instruments (combine maximum of 128 instruments)
- Extension to maximum of 512 channels.
- USB 2.0 connection (USB 1.1 compatible)
- Sample speed up to 50 MHz per channel
- = 12 to 16 bit resolution (6  $\mu$ Volt resolution)
- 25 MHz bandwidth
- Input sensitivity from 200 mVolt up to 80 Volt
- Large memory up to 131060 samples per channel
- Four integrated measuring devices
- Spectrum analyzer with a dynamic range of 95 dB
- Fast transient recorder up to 100 kHz
- Several trigger features
- Auto start/stop triggering
- Auto disk function up to 1000 files
- Auto setup for amplitude axis and time base
- Auto trigger level and hysteresis setting
- Cursor measurements with setup read-outs
- 🚃 Multi window signal display
- Multi channel display

for more information, demo software, software, source code and DLL's visit our internet page: http://www.tiepie.nl



6

6

9

TiePle engineering (NL) Kaperslagersstraat 37 8601 WL SNEEK The Netherlands Tel: +31 515 415 416 TiePie engineering (UK) 28, Stephenson Road, St. Ives Cambridgeshire, PE17 3WJ, UK Tel: 01480 - 300695 Fax: 01480 - 461654

Copyright 2005 TiePie engineering. All rights reserved

# **TEST EQUIPMENT** SOLUTIO

#### Sample Stock List - If you don't see what you want, please CALLI

47

30

32 30

30 32

45

AMPLIFIERS	Sale (GBP)	Ren (GBF
Agilent/HP 8349B 2-20GHz +15dB >50mW Amplifier	2700	10
Agilent/HP 8447E 1.3GHz Power Amplifier	950	4
Agilent/HP 8447F 1.3GHz Pre/Power Dual Amplifier	1250	5
Agilent/HP 8449B 26.5GHz 26dB +7dBm Pre-amplifier	4500	18
Anritsu MH648A 100KHz-1.2GHz Preamplifier	650	3
ENI 2100L 10kHz-12MHz 100W Power Amplifier	6500	26
ENI 240L 20kHz-10MHz 40W RF Amplifier	3950	15
ENI 601L 800kHz-IGHz 1.2W RF Amplifier	850	3
FREQUENCY COUNTERS		
Agilent/HP 5316A 100MHz Frequency Counter	295	I
Agilent/HP 5334A/030 1.3GHz Frequency Counter	495	2
Agilent/HP 5342A/011/002 24GHz Frequency Counter	1150	4
Agilent/HP 5347A/006 20GHz Counter/Power Meter	4050	16
Agilent/HP 5371A 500MHz Frequency/Time Interval Analyser Agilent/HP 5372A 500MHz Frequency/Time Interval Analyser		5
EIP 578 26GHz Microwave Source Locking Counter	2575	7
Marconi 2440 20GHz Microwave Counter	1550	4
Philips PM6670/01 120MHz Frequency Counter Timer	495	3
Racal 1991/04A 160MHz Frequency Counter	395	3
Racal 1992/001 1.3GHz Frequency Counter	575	3
Racal 1992/04C 1.3GHz Frequency Counter	575	3
Racal 1992/55/04B 1.3GHz Frequency Counter	695	3
Racal 1998/04A 1.3GHz Frequency Counter	695	3
Racal 9901 50MHz Universal Counter Timer	275	3
Racal 9906/04C 200MHz Frequency Counter	325	3
Racal 9917A/04B 560MHz Frequency Counter	395	3
Racal 9921/04A 10Hz-3GHz Frequency Counter	550	3
Thandar TF830 1.3GHz Frequency Counter	550	3
FUNCTION GENERATORS		
Agilent/HP 3245A/001 DC-1MHz Function Generator	3650	16
Agilent/HP 3312A 13MHz Function Generator	750	2
Agilent/HP 3314A 20MHz Function Generator	925	3
Agilent/HP 3325A 21MHz Function Generator	775	3
Agilent/HP 3325B 21MHz Function Generator	950	3
Agilent/HP 3335A/001 81MHz Function Generator	1450	4
Agilent/HP 3336C/04 21MHz Function Generator	1125	3
Agilent/HP 8111A 20MHz Function Generator	995 p 1595	3
Agilent/HP 8116A/001 50MHz Function Gen c/w Burst/Swee Agilent/HP 8904A/001/002/003/004 600kHz Func Gen	2250	4
Levell TG303 2MHz Function Generator	190	i
Philips PMS132 2MHz Function Generator	150	1
Philips PM5138/004 10MHz Function Generator	950	3
Philips PM5138/021 10MHz Function Generator	950	3
Philips PM5139/004 20MHz Function Generator	1250	3
Tek AWG2021/02/09 125MHz 250MS/s Dual Output Arb	4950	14
LOGIC ANALYSERS		
Agilent/HP 16500A Logic Analyser Mainframe	1100	4
Agilent/HP 16500C Logic Analyser Mainframe	1650	5
Agilent/HP 1650B 80 Channel Logic Analyser	950	5
Agilent/HP 16510B 100MHz Timing 35MHz State 80 Ch Car	1000	3
Agilent/HP 1651A 80 Channel Logic Analyser	850	4
Agilent/HP 16533A 1GS/s DSO Card For 16500 Series	950	4
Agilent/HP 16550A 500MHz/100MHz Timing/State 102Ch Ca	100 B (100 B)	5
Agilent/HP 1661A 500MHz/100MHz Timing/State 102Ch	2450	8
Agilent/HP 1662A S00MHz/100MHz Timing/State 68Ch	2350 2750	1
Agilent/HP 1662C 250MHz Timing/100MHz State 68Ch Agilent/HP 1670G 500MHz Timing 150MHz State 136Ch	4650	12
Agilent/HP 1680A 800MHz Timing 200MHz State 136Ch	9150	38
Agilent/HP E2423A SCSI Bus Preprocessor	100	1

ŧ	Construction of the Constr	Sale
1	MULTIMETERS	(GBF
1	Agilent/HP 3458A 8.5 Digit System Multimeter	3250
	Keithley 237 Source Measure Unit	399
	Keithley 238 High Current Source Measure Unit	3350
	Keithley 2400 200V Digital Sourcemeter	2850
	Keithley 2410 1100V High Voltage Sourcemeter	4150
0	Kikusui DME1400 4.5 Digit Multimeter	17
	Thandar 1604 4.75 Digit Digital Multimeter	39
6	NETWORK ANALYSERS	
1	Agilent/HP 11500F APC Cable 3.5mm	39
8	Agilent/HP 3575A Gain/Phase Meter	115
D	Agilent/HP 3577A 5Hz-200MHz Vector Network Analyser	395
2	Agilent/HP 4195A 500MHz Vector Network/Spectrum Analyse	695
2	Agilent/HP 85032B/K05 Type N (f) Calibration Kit	75
0	Agilent/HP 8510B 50GHz Microwave Network Analyser	425
B		-
S	100	and the second



	Agilent/HP 8714C 300kHz-3GHz Vector Network Analyser	6950
	Agilent/HP 8720B/001 20GHz Vector Network Analyser	19950
	Agilent/HP 8720C 20GHz Vector Network Analyser	23950
l	Agilent/HP 8753C/006 6GHz Vector Network Analyser	8500
	Agilent/HP 8753D/002/010 3GHz Vector Net Ana c/w S Para	1500
	Agilent/HP 8753D/006 6GHz Vector Net Analyser c/w S Para	13750
	Agilent/HP 8757E 20GHz Scalar Network Analyser	4650
	Agilent/HP 89441A/AY7/8/9/A/B/UFG/UG7 DC-2650MHz VSA	18750
	Anritsu S251B/10A 2.5GHz Dual Port Scalar Network Ana	5250
	Anritsu S331C 4GHz Scalar Network Analyser	3950
	OSCILLOSCOPES	
	Analogue and Digital Oscilloscopes including Agilent/HP,	
	Tek, LeCroy and Fluke prices range from	350
	Fluke 80i-1000S AC Current Probe	75
	Fluke 99 2 Channel 50MHz Handheld Scope	1150
	Tek AM5035/03/A2 Current Probe System (inc.A6302 Probe)	1350
	POWER METERS	
	Agilent/HP 436A/022 RF Power Meter With GPIB	825
	Agilent/HP 438A Dual Channel RF Power Meter	1350
	Various HP/Anritsu/Gigatronic/Marconi power sensorsfrom	525
	Agilent/HP 8991A Peak Power Analyser	10750
	Agilent/HP E4418B/002 Single Channel Power Meter	1700
	Gigatronics 80350A 45MHz-18GHz 200mW Peak Pwr Sensor	1350
	Gigatronics 8541C Single Channel RF Power Meter	1350
	Gigatronics 8542B Dual Channel RF Power Meter	1750
	Marconi 6970/001 RF Power Meter	895
	Marconi 893B AF Power Meter	450
	POWER SUPPLIES	
	ACDC Electronics EL750B 750W Electronic Load	1350
	Wide Range of Agilent Supplies in Stock up to2000W	
	and up to 600V. Prices from	550
	Farnell 3502A 35V/2A Dual Output DC Power Supply	325
	Farnell AP100/90 100V 90A 3KW Power Supply	2550
	Farnell AP60/50 60V 50A Power Supply	1750
	Kikusui PLZ-300W 300W Electronic Load	995

#### **Quality Second User Test Equipment** With 12 Months Warranty

#### The Industry's **Most Competitive Test Equipment Rental Rates**

Rent (GBP)	PULSE GENERATORS	Sale (GBP)	Rent (GBP)
98	Agilent/HP 8012B 50MHz Pulse Generator	695	28
161	Agilent/HP 8112A 50MHz Pulse Generator	1450	44
139	Agilent/HP 8115A 50MHz Dual Channel Pulse Generator	2350	95
86	SIGNAL & SPECTRUM ANALYSERS		
125	Advantest R3261A 2.6GHz Spectrum Analyser	3450	104
18	Advantest R3265 8GHz Spectrum Analyser	5975	247
22	Advantest R9211A 10MHz-100kHz Dual Channel FFT Analyser	2950	89
-	Advantest U3641 3GHz RF Spectrum Analyser	3500	107
32	Agilent/HP 3561A 100kHz Dynamic Signal Analyser	2250	68
59	Agilent/HP 3562A 100kHz Dual Ch Dynamic Signal Analyser	2450	74
209	Agilent/HP 3588A/001 150MHz Spectrum Analyser	4650	140
28	Agilent/HP 53310A/001/030 2.5GHz Mod Domain Analyser	3850	160
170	Agilent/HP 8563E/006/007/008 30Hz-26.5GHz Spec Ana Agilent/HP 8566B 22GHz Spectrum Analyser	14950 6950	450 210
	Agilent/HP 8568B 100Hz-1.5GHz Spectrum Analyser	2950	89
	Agilent/HP 8591A/010/021 1.8GHz Spectrum Analyser	3750	113
	Agilent/HP 8593E/004/041/130 22GHz Spectrum Analyser	10950	329
	Agilent/HP 8594E/041 2.9GHz Spectrum Analyser	4500	135
	Agilent/HP 8595E 6.5GHz Spectrum Analyser	7950	317
	Agilent/HP 8596E/021/101/105 12.8GHz Spectrum Analyser	8550	260
	Agilent/HP 8901A/001/002 1.3GHz Modulation Analyser	950	48
	Agilent/HP 8903B/001/010/051 20Hz-100kHz Audio Analyser	1800	54
	Anritsu 5400-71N50 3GHz RF Detector	350	28
_	Anritsu MS2601B 2.2GHz Spectrum Analyser	2950	90
209	Anritsu MS2602A/01/02 100Hz-8.5GHz Spectrum Analyser	5750	174
802	Anritsu MS2651B 3GHz Spectrum Analyser	3950	120
961	Anritsu MS2661C/2/8 3GHz Spectrum Analyser	4250	128
306	R&S FSEA20/B4/B7/B8 9kHz-3.5GHz Spectrum Analyser	9500	285
345	Racal 9008A Modulation Meter	220	18
413 140	SRS SR760 100kHz Single Channel FFT Spectrum Analyser SIGNAL GENERATORS	1950	71
565	Agilent/HP 83711A/IE1 1-20GHz Synthesised CW Sig Gen	7650	230
158	Agilent/HP 8648A 100kHz-1GHz Synthesised Signal Generator		100
119	Agilent/HP 8648C/1E5/1EA 3.2GHz Signal Generator	5150	206
	Agilent/HP 8648D 9kHz-4GHz Synthesised Signal Generator	5950	179
34	Agilent/HP 8657A IGHz Synthesised Signal Generator	1600	48
37	Agilent/HP 8657D/001 IGHz DQPSK Synthesised Signal Gen	1350	41
8	Anritsu MG3601A/02 1GHz Signal Generator Marconi 2018/GPIB 520MHz Synthesised Signal Generator	1600	48
49	Marconi 2019A IGHz Synthesised Signal Generator	900	45
	Marconi 2031/001/002 2.7GHz Signal Generator	4950	149
38	Marconi 2032 10kHz-5.4GHz Signal Generator	7950	318
45	Marconi 2041/001 2.7GHz Low Noise Signal Generator	6250	189
27	WIRELESS		
439	Agilent/HP 8902A 1.3GHz Measuring Receiver	7950	240
57	Agilent/HP 8920A/103 IGHz Radio Comms Test Set	3250	98
55	Agilent/HP 89208/1/4/13/14/55/102 Radio Comms Test Set	4950	149
-41	Agilent/HP 8922M/001/006/010 IGHz GSM MS Test Set	2950	89
53	Anritsu ME4510B Digital Microwave System Analyser	4750	145
45	IFR 2935 GSM Test Set [TRI BAND]	4950	198
27	IFR 2967/16/17/21 Radio Comms Test Set with GSM	4950	149
40	Marconi 2955 IGHz Radio Comms Test Set	1950	71
49	Marconi 2955B IGHz Radio Comms Test Set Marconi 2966A/12 IGHz Radio Comms Test Set with GSM	3250 4750	103
20	Racal 6103/001/002/014/420/430/04T Mobile Radio Test Set		143
26	Racal 6104/001/002/003/006/014/04T Mobile Radio Test Se		220
n	W&G 4106 GSM/DCS1800/PCN1900 Mobile Phone Tester	2250	70
63	W&G 41075 Mobile Phone Tester	2450	74
40	Wavetek 42015 Triband Digital Mobile Radio Test Set	3650	110

## The only company with the confidence to offer 12 month warranty as standard, with 24 month available!

FREE Palm Zire22 shipped with every order over £5K

Prices shown are for guidance in £UK GBP, exclusive of VAT and Ex-Works. All items subject to prior sale. Rental prices are per week for a rental period of 4 weeks. Free carriage to UK mainland addresses on sale items. Rental or non UK deliveries will be charged at cost. This is just a selection of equipment we have available - if you don't see what you want, please call. All items are supplied fully tested and refurbished. All manuals and accessories required for normal operation included. Certificate of Conformance supplied as standard. Certificate of Calibration available at additional cost. Test Equipment Solutions Ltd Terms and Conditions apply. All E&OE.

## 01753 596000 Fax: 01753 59 6001

www.TestEquipmentHQ.com email: info@TestEquipmentHQ.com